

Manual



Note: This page is blank for convenient double-sided printing.

SAFEDOCK® CHAPTERS AND APPENDICES CONTENTS

Section	Description	Information
Preface	Introduction	Reference
CHAPTER 1.	SYSTEM DESCRIPTION	Reference
CHAPTER 2.	INSTALLATION	Reference
Appendix A.	Operator Panel Softkey Setup	Reference
CHAPTER 3.	OPERATION	Reference
Appendix A.	Operation Procedures	Reference
Appendix B.	Safedock Features	Reference
CHAPTER 4.	MAINTENANCE	Reference
Appendix A.	Stand Configuration Utility	Reference
Appendix B.	Safedock Log Viewer	Reference
CHAPTER 5.	DRAWINGS	Reference



CONFIGURATION SUMMARY

The manual includes chapters/appendices with descriptions for available product options as follows:

- General Options common to most gates/sites.
- More Options specific to gates/sites.

Note: Some information may not be relevant to a specific gate/site. You can also check with project or site management for options included in the specific configuration for a gate/site.

The table is a guide to some of the product options available. The configuration summary column can be used as a reference guide to find option information relevant for a specific gate/site.

Product Options	Configuration Summary
General Options	
Operator Panel	Softkey Note : For 30-key Operator Panel information see Manual version 1.5 or earlier.
Pilot Display Type	T1 -42. T2 -18, or -24. T3 -9 or -15. <i>Note:</i> For other type information see Manual version 1.8 or earlier.
Closing Rate Distance	No digital countdown (closing rate bar only) from 15 m (as default) or Digital countdown (including closing rate bar) configurable from max 30m or 98ft. Note: For type 3 is dig countdown available from max 20m.
Safedock Maintenance Tool - SMT	Yes or No
More Options	
Battery backup (UPS)	Yes or No
Camera	Yes or No
Safedock Log Viewer – SLV	Yes or No
Adjacency Rules (Superior System)	Yes or No
Operation & Maintenance Modes/Operator Panel Key Switches	Yes or No

WARRANTY

Project Warranty

The Contractor (Safegate Group or subsidiary Company) hereby warrants that there shall be no significant failure or substantial reduction in performance in the following product or system, the performance criteria for which are as contained within the Project Contract.

This Warranty shall commence on a specific date, and end on a specific date according to the Project Contract.

The Contractor warrants to the Principal (Customer, agent or sub-contractor) that all work performed and all goods supplied by the Contractor under the above mentioned Project Contract will be:

- at least of the quality and to the standard required by the Contract; and
- of good workmanship and new and of merchantable quality; and
- fit for the purpose or purposes for which they are required

Project Managers Member of the Safegate Group Subsidiary Company

Product/System Warranty

Safegate Group guarantees that the performance of the Safegate Group product/system, when sold by Safegate Group or its licensed representatives, meets the requirements of and is in compliance with standards:

• ICAO Annex 14 - Aerodromes Volume I - Aerodrome Design and Operations - 4th Edition July 2004 [5.3.24 Visual Docking guidance System].

Note: For more information, contact Safegate for compliance with other standards.

Any defect in design, material or workmanship, which may occur during proper and normal use over a period covered by the warranty stipulated in the contract, will be replaced by Safegate Group according the conditions for the project in question. Operational failure resulting from improper installation, damage due to user/operator error, airport maintenance equipment are not considered a result of proper use and is beyond the scope of the warranty.

Any 3rd party products installed or integrated with functionality in a Safegate system without prior consent or support from Safegate causes the warranty to become invalid, as the design specifications can longer be guaranteed.

The above constitutes the limits of Safegate Group liabilities concerning the Safegate Group products/systems.

Product Leaders Member of the Safegate Group Subsidiary Company



COPYRIGHT

© Copyright 2012 by Safegate Group. All rights reserved. This item and the information contained herein are the property of Safegate Group. No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language in any form or by any means otherwise, without the expressed written permission of Safegate Group, Djurhagegatan 19, SE-213 76 Malmö, Sweden.

HISTORY

Version	Date	Description
1.0	January 2008	First Release (Single type option)
1.1	July 2008	Projects (All type options)
1.2	January 2009	Projects (All type options)
1.3	May 2009	General update
1.4	October 2009	Feature update
1.5	January 2010	Feature update
1.6	June 2010	Feature update
1.7	November 2010	Minor update
1.8	April 2011	General update
1.9	June 2011	T2 T3 LED update
1.10	April 2012	Drawings update
1.10.1	October2012	Images update
1.10.2	May 2009	INSTALLATION, OP_Pilots_Guidelines and Drawings update
2.0	Dec 2013	SOS & SMT implementation + General update
2.1	Feb 2014	SMT upgrade + Minor update
2.2	April 2014	SMT upgrade + Minor update
2.3	June 2014	SMT upgrade + Minor update
2.4	September 2014	SMT upgrade + Minor update
2.5	October 2014	SMT upgrade + Minor update
2.6	November 2014	Minor updates
2.7	February 2015	SMT upgrade + Minor update

INTRODUCTION

This manual has been compiled to give the reader an understanding of installation, operation and maintenance (IOM) procedures of the Safedock system, with a focus on safety and efficiency.

The manual includes chapters/appendices with contents for quick access to information as follows:

Introduction

Information about configuration options, warranty, copyright, version history, original documents used to create this manual, a general contents list for quick access to information. Contents are also included at the beginning of each of the main chapters for quick access to information. Safety Information including Laser Safety Information, abbreviations, and a glossary of terms, *Note: It is important to read the General and Laser Safety Information.*

Chapter 1 – System Description

A system overview of the constituent system parts with a detailed technical description. A description of system architecture and the components involved.

Chapter 2 – Installation

Guidance to system installation engineers with references to software programming instructions, calibration procedures and cross references to the Maintenance chapter.

Chapter 3 – Operation

A description of procedures used for system operation and itemized docking.

For example, an Operation Procedures Appendix (with instructions to pilots) gives an explanation of signs and signals in a Safedock system. A Features Appendix provides information about the optional operational features in the system.

Chapter 4 – Maintenance

A system designed to minimize maintenance downtime. The maintenance of equipment is described at assembly level only. For example, if a fault is traced to a defective circuit board, the complete circuit board is replaced. No provision is made in this manual for repair at component level. The chapter also includes high-level maintenance procedures and fault diagnosis information (Appendix B Safedock Log Viewer).

Chapter 5 – Drawings

This chapter contains drawings and parts lists.

Note: Check with project or site management for Safedock options included in the specific configuration for a gate/site.



SAFETY INFORMATION

Safedock system is an Advanced Visual Docking Guidance System, an aircraft parking aid for airport and aircraft safety and efficiency. The design is according to strict airport industry standards for the safety of, and use by authorised airport personnel.

Note: The appendix document, Chapter 3 Operation – Appendix A, Operation Procedures must be distributed to all airlines using the system.

Airport Operations, Maintenance and other Authorised Personnel

This information is a summary of the safety requirements on operation and maintenance personnel based on general electrical and laser safety precautions. **Note**: It is very important for authorised personnel to study this section before any operation or maintenance work on the system is commenced.

Safedock system should only be used by airport operations and maintenance personnel who have been properly trained in the use of the system. Safegate takes no responsibility for incorrect use of the system. All warnings contained in the text of this manual must be strictly observed.

Airport operations and maintenance personnel are strongly advised to observe the following symbols and safety advisories.

Symbol	Safety Advisory
\triangle	Safedock system contains electrical circuits and laser emitting devices, which may be hazardous to operators and maintenance personnel, if proper safety precautions are not observed. Only properly trained personnel should open enclosures or attempt to perform maintenance on these devices. Personnel are cautioned to read and thoroughly understand this manual before attempting to service this device.
	Safedock system contains 100 - 230 VAC electrical circuits that may be hazardous to operators or maintenance personnel if proper safety procedures are not observed. Remove power before attempting to service this device. Power may be turned off at the main disconnect circuit breaker inside the Display cabinet or at the breaker panel supplying AC power to the unit. CAUTION : SOME SYSTEMS ARE SUPPLIED WITH A REMOTE UPS, WHICH MAY CONTINUE TO SUPPLY POWER TO THE SYSTEM, EVEN WHEN THE BREAKER AT THE SUPPLY PANEL IS SWITCHED OFF. BE SURE TO REMOVE ALL POWER, BEFORE SERVICING THIS EQUIPMENT.
	A chassis ground connection is provided inside the cabinet. Be sure to follow all applicable codes in making chassis ground connections.

Symbol	Safety Advisory		
	Laser Safety Information		
	Safedock system is a Class 1 laser product, which means that it is safe under foreseeable conditions of operation, including the use of optical instruments for intra beam viewing.		
EN IEC 60825-1:2007 COMPLIES WITH 21 CFR 1040.10 EXCEPT FOR DEV/ATIONS PURSUANT TO LASER NOTICE NO. 50, DATED JUNE 24, 2007	The Laser Scanning Unit compartment of the Pilot Display unit contains a Laser Range Finder, which is a Class 1M laser product. A Class 1M laser product is safe under foreseeable conditions of operation, but may be hazardous, if the user employs optical instruments within the beam, e.g. binoculars or telescope.		
	Invisible Laser Radiation		
	The laser output from this system is within Class 1 limits (USA FDA 21 CFR $1040.10 - 11$ and IEC 60825-1, 2_{nd} Edition: 2007) as long as the range finder is installed and operated as specified by Safegate. If operated in any other fashion than described, the range finder is capable of emitting radiation up to Class 1M limits.		
	Eye Safety		
	 Safegate accepts no liability for the misuse of its equipment or for the consequences of this misuse. 		
	 Safegate recommends that eye safety procedures be followed in accordance with ANSI Z136.1 – 1993 or IEC 60825-1 during maintenance. 		
	The laser beam exiting the window of the Safedock enclosure is within Class 1 limit for eye safety, when the product is operated as specified by Safegate.		
	4. To provide eye safety the user is advised to treat this laser unit as a Class 1 M laser product. Class 1 M denotes lasers or laser systems that can produce a hazard if viewed through light collecting optics such as binoculars.		
	For the laser the following values apply:		
	Pulse width ~ 10 ns		
	Wavelength 905 nm		
	 If the laser by any reason should be switched on and used outside the docking system, safety procedures may include, but are not necessarily limited to the following: 		
	Do not stare into the laser beam.		
	• Do not view the beam with binoculars or other devices that collect light.		
	Do not point the laser at people.		
	CAUTION: DO NOT POINT THE LASER RANGE FINDER AT THE SUN.		



GLOSSARY OF TERMS

Term	Description
Active state	The Safedock system is scanning the stand area for an approaching aircraft.
Alphanumeric display/ Text display	The upper portion of the Pilot Display. It is used as a text display capable of displaying alphanumeric characters.
Safedock Maintenance Tool	A software system run on a PC connected to the Safedock system. It is used to maintain and configure the Safedock
Azimuth display	The middle portion of the Pilot Display. It is used to indicate the lateral position of the aircraft relative to the centreline.
Block-Off transaction/ Chock-Off transaction	A message sent from Superior System to FIDS when an aircraft has left the stand. The message can be used for billing purposes.
Block-On transaction/ Chocks-On transaction	A message sent from Superior System to FIDS when an aircraft has reached the stop position. The message can be used for billing purposes.
Calibration control	A procedure performed periodically around the clock. It verifies that the system is in operation condition.
Capturing/ Capture Mode	The Safedock system is scanning the stand area for an approaching aircraft.
Chocks-On	A visual message meant for the pilot allowing him/her to know that t the chocks has been applied to the nose wheel.
Closing rate display	The lower portion of the Pilot Display. It is used to indicate the distance remaining to the stop position for the approaching aircraft.
Control Unit	The processing centre for the Safedock system. It is mounted in the same cabinet as the Pilot Display unit.
Docking Guidance System	A system providing visual information to the pilot about an aircraft's position relative the centreline and stop position. It acts as an aid for the pilot to manoeuvre the aircraft to the correct parking position.
Docking log/Safedock log	Each Safedock system will retain a number of logs of the latest docking procedures. These docking logs can be downloaded using the Maintenance PC, or be automatically downloaded to a Superior System.
Docking procedure	The procedure by which a Safedock system leads an incoming aircraft to the predefined stop position. It consists of aircraft selection by operator, system self-test, Capture, Tracking and aircraft verification.
Laser Range Finder/ LRF	A measuring device using laser pulses to measure the distance to an object.
Laser Scanning Unit/ Laser Unit	A device made up of a Laser Range Finder and two mirrors mounted on stepper motors. The device uses the two mirrors to direct the laser pulses from the LRF in two dimensions, resulting in a three-dimensional scan of the stand area.
Pilot Display Unit	The Safedock system uses a display consisting several 8x8 dot 'light emitting diode' boards to display text, azimuth and closing rate information to the pilots.
Maintenance PC	A PC used to run the Safedock Maintenance Tool. It can be a portable PC connected locally to a Safedock system, or a stationary PC connected to the units via LAN or through Superior System.

Term	Description
Operators Panel/ Operators Control Panel	The operator panel is the primary source for operator input to the Safedock system. It consists of an LCD display for status information and function keys for operator input.
Scheduled Docking	A pre-planned incoming flight, consisting of Aircraft type, flight number, stand and scheduled/estimated/actual time of arrival. Superior System can use this information to initiate the docking procedure at the appropriate stand. The Scheduled docking will be presented at the Safedock system, for approval by the Marshal or handling agent.
Stand configuration file	A complete configuration for a Safedock system can be stored on disk in a stand configuration file. This file can be used to review and/or to document the stand configuration. The file can also be used to restore the configuration for a in case of a hardware breakdown.
Stand Setup/ Stand configuration	The process of configuring a stand for operation. This process includes defining the centreline to use and selecting the aircraft types and their stop positions.
Superior System	Gate Operating System or SafeControl – Apron Management System.
Tracking/ Tracking Mode	The Safedock system has found an incoming aircraft, and is in the process of leading it to the predefined stop position.
Walk test	A test procedure used to verify the operation of a Safedock system.

Note: This page is blank for convenient double-sided printing.

CHAPTER 1 SYSTEM DESCRIPTION CONTENTS

Section	Description	Page No.
1.	EQUIPMENT AND SYSTEM DESCRIPTION	3
1.1	BRIEF SYSTEM ARCHITECTURE	3
1.2	DESIGN OBJECTIVES	3
1.3	SAFEDOCK SYSTEM SUB-UNITS	5
1.3.1	Pilot Display Unit	5
1.3.2	Control Unit	5
1.3.3	Laser Scanning Unit	6
1.3.4	Power Unit	8
1.3.5	Battery Backup Unit (Option)	8
1.3.6	Temperature Control System	8
1.3.7	Operator Panel	8
1.4	OPERATION	9
1.4.1	The Docking Process	9
1.4.2	Safety with the Docking Procedure	10
2.	INTERFACES TO OTHER SYSTEMS	14
2.1	SYSTEM AVAILABILITY/LINE REPLACEABLE UNITS	15
2.1.2	Reliability of Reparability of Line Replaceable Units	15
2.1.3	Reliability Calculation	15
2.1.4	Technical Availability	16
3.	TECHNICAL DATA	17
3.1	PERFORMANCE	17
3.2	SAFEDOCK UNITS DIMENSIONS AND WEIGHTS	17
3.2.1	Safedock Main Unit	17
3.2.2	Operator Panel	17
3.3	SUB UNIT CHARACTERISTICS	
3.3.1	Power Unit	
3.3.2	Control Unit	
3.3.3	Laser Scanning System	
3.3.4	Operator Panel (OP softkey)	
3.3.5	Conduit Entry Points (cable glands, nuts, holes)	
3.4	ENVIRONMENTAL LIMITS	19
3.4.1	Dust and Water Protection	19
3.4.2	Installation Environment	19
3.4.3	Temperature and Humidity Limits	19
3.4.4	Storage	19
3.4.5	Wind Load	19
3.4.6	Snow Load	19
3.4.7	Brightness	20
3.4.8	Vibration	20

3.4.9	Acoustic Sound and Noise	20
3.4.10	Pollution Limits	20
3.4.11	Installation Over-voltage Limits	20
3.5	ELECTROMAGNETIC COMPATIBILITY	20
3.5.1	General	20
3.5.2	Generic Standards	20
3.5.3	Basic Standards	20
3.5.4	Product Family Standards	20

1. EQUIPMENT AND SYSTEM DESCRIPTION

1.1 BRIEF SYSTEM ARCHITECTURE

The figure 1.1 is an overview of the Safedock system and the following section is a brief description of the system and its sub units.

- 1. The Safedock main unit consists of a real time Pilot Display Unit, a Control Unit and a Laser Scanning Unit. All these are housed in the same cabinet, except for the T1S model where the Laser Scanning Unit is in a separate enclose.
- 2. The system also includes an Operator Panel, comprising an LCD display screen and an "Emergency-Stop" push-button, or optionally a 'Clear Gate' button. The Operator Panel is mounted at apron level, or in the cabin of the Passenger Boarding Bridge (PBB).
- The Laser Scanning Unit is based on 3D- measuring technology to execute a safe docking procedure, when an aircraft approaches a terminal stand. The Laser Range Finder (LRF) transmits distance data from the approaching or departing aircraft to the Control Unit for processing.
- 4. The Control Unit transmits processed data results for presentation on the Pilot Display Unit, the Operator Panel and to the Superior System (GOS/ SafeControl-Apron Management System).

1.2 DESIGN OBJECTIVES

Important design factors are:

- Commonality of components to reduce customer stock of essential spares.
- Analysis for successful long-term operation.
- Knowledge of aircraft characteristics and the recognition of the unique factors in any airport requirement, responding in a highly cost effective technology.
- Human-Machine-Interfaces of the Safedock system has been designed in cooperation with customers and end-users, and has been developed from the experience of systems, previously delivered, with the objective to achieve a high degree of safety, guidance readability and operational efficiency.



AODB, FIS/GMS CMS etc



Laser Scanner

FIGURE 1.1 SAFEDOCK SYSTEM OVERVIEW

1.3 SAFEDOCK SYSTEM SUB-UNITS

1.3.1 Pilot Display Unit

The Pilot Display incorporates three different indicators for alphanumeric, azimuth and closing rate information, clearly visible from both pilot positions in the aircraft cockpit.

The Pilot Display comprises a set of LED (light emitting diode) indicators, yellow and red indicator boards, each housing a processor board connected in series to the Control Unit.

The upper rows are used for alphanumeric information, the next row for azimuth information and the lower section for closing rate information.



1.3.1.1 Alphanumeric Information

The alphanumeric display, shown in yellow, will present information such as abbreviations for Aircraft type, Airport code and Flight number. Special guiding text information is also displayed to the pilot during the docking phase.

1.3.1.2 Azimuth Guidance Indicators

The azimuth guidance indicator, often displayed as red arrows, gives information on how to steer the aircraft. A yellow vertical arrow shows the actual position of the aircraft in relation to the centreline.

1.3.1.3 Closing Rate Indicator

The closing rate indicator, shown in yellow, comprises of a number of horizontal elements, building a vertical column, the centre-line symbol. Each element represents for T3 0.7, T2 0.4 and T1 0.3 metres. Other resolutions are possible.

1.3.1.4 Legibility of Displayed Information

The displayed information is readable in direct sunlight, reflections and back-light. This is achieved through the use of automatic adjustment of LED light intensity and dark coloured LED-boards.

1.3.2 Control Unit

The Control Unit, located with, or inside the Safedock unit, comprises a motherboard with a microprocessor unit, and two stepper motor drive boards. It continuously monitors and controls the operation of the docking guidance system.

The Control Unit is designed for real time processing of measured distances, handling of communication lines, stepper motors, temperature control, display's light intensity control and safety control of the Laser Range Finder.

Software and parameters are stored in non-volatile memory.

Communication to the Superior System is by means of an Ethernet connection built in at the Control Unit.



1.3.3

Laser Scanning Unit

The Laser Scanning Unit comprises the following sub-units:

- Laser Range Finder
- Vertical scanning mirror and stepper motor
- Horizontal scanning mirror and stepper motor



Vertical mirror and stepper motor





Vertical stepper motor and mirror

FIGURE 1.3 - SAFEDOCK T2/3 LASER SCANNING UNIT

The Laser Scanning Unit is housed in the lower part of the Safedock unit for model T2 & T3, and for T1 in the upper part. It is based on 3D-technology and consists of a Laser Range Finder, comprising both a transmitting and a receiving lens. The unit also incorporates a fixed mirror used with the calibration procedure to facilitate an accurate setting of the Safedock system.



WARNING! INVISIBLE LASER RADIATION.

THE LASER OUTPUT FROM THIS SYSTEM IS WITHIN CLASS 1 LIMITS (USA FDA 21 CFR 1040.10 – 11 AND IEC 60825-1:2007) AS LONG AS THE RANGE FINDER IS INSTALLED AND OPERATED AS SPECIFIED BY SAFEGATE. IF OPERATED IN ANY OTHER FASHION THAN DESCRIBED, THE RANGE FINDER IS CAPABLE OF EMITTING RADIATION UP TO CLASS 1M LIMITS.

1.3.3.1 Functional Description

When a docking process has been started, the Laser Range Finder transmits infrared pulses, scanning both vertically and horizontally via a stepper motor controlled mirror system, to detect an approaching aircraft.

The distance to the aircraft is determined by the elapsed time, taken for the infrared pulse to be transmitted and received by the Range Finder. The Control Unit, which handles the positioning of the scanning mirrors, uses the distance values, obtained from the Laser, to determine the location of the aircraft, in relation to its required stop position.

1.3.3.2 Laser Scanning Area

During capturing mode the scanning area is 20 degrees in a horizontal plane. When an aircraft has been captured, the laser will follow the aircraft in a tracking area according to the Safedock unit type described in following figures.



1.3.3.3	Mirrors and Stepper Motors
	This part of the system comprises a vertical and a horizontal mirror assembly, each controlled by a stepper motor. See Figure 1.2.
1.3.4	Power Unit
	Required power supply: 115/230VAC +10%, 50/60Hz
	The Power Unit generates DC 24V to the Control Unit, the Pilot Display Unit, the Laser Scanning Unit, and to the Operator Panel. The system has surge arrestors built in.
1.3.5	Battery Backup Unit (Option)
	Optionally a battery unit can be installed to back up power line failures to finish off begun operations. Lead-AGM batteries are used, and the maximum capacity is 7.2 Ah. The battery unit is interfaced with the Power Unit above and charges automatically.
1.3.6	Temperature Control System The laser system in the cabinet includes a Climate Control System, comprising a ventilated double wall and de-icing/anti-condensation heater.

Optionally the Pilot Display Unit also has a heater to prevent moisture on the window during cold weather.

1.3.7 Operator Panel

The Operator Panel is used to control the Safedock system from a location close to the Aircraft Loading Bridge. The Operator Panel, controlled by an embedded microprocessor unit, is connected to the Control Unit by a RS485 communication line. Power, 24 VDC, is supplied from the Safedock main unit. The interface to the Aircraft Loading Bridge is via the

Operator Panel printed circuit board, having the input/output ports for that purpose.



FIGURE 1.6 - OPERATOR PANEL (SOFTKEY)

1.3.7.1 Physical Description

The Operator Panel consists of a keyboard with 14 push buttons (4 fixed function keys and 10 context sensitive keys), and a liquid crystal display (LCD). The LCD indicates systems modes of operation, lead text for the context sensitive keys, and gives also diagnostic/error information. The Operator Panel display is backlit.

1.3.7.2 Service Outlets

At the right side of the Operator Panel a connector for a PC serial port, RS485, is installed. This can be used with a Maintenance PC for the local configuration and calibration of each individual Safedock unit.

1.3.7.3 "Emergency-Stop" Button or "Clear Gate" Button

The Operator Panel has an "Emergency-Stop" push-button that is connected to the Safedock Control Unit by a separate line. Optionally a "Clear Gate" button can be installed instead of the "Emergency-Stop" button.

1.3.7.4 Other Pilot Messages

Input ports, 16 in total, are also used for activating messages to the Pilot, after docking has been completed. Such messages are: CHOCKS ON/OFF; PCA ON/OFF; 400Hz ON/OFF etc.

1.4 OPERATION

1.4.1 The Docking Process

This is a brief description of the Safedock system operation. For a detailed description, see Chapter 3 OPERATION.

- a) The individual Safedock unit is operated from the Operator Panel at apron level or from the Superior System. From the Superior System all connected systems can be individually controlled and monitored.
- b) In the Safedock system a number of aircraft types are configured by a set of parameters such as the nose profile etc. At start of docking an aircraft type is assigned by the operator. During the docking procedure the corresponding parameters of the actual aircraft are measured by the laser equipment. Captured data are compared to the safety profile of the assigned aircraft. If the safety margins are not correct, the message "ID FAIL" will be displayed on the Pilot Display and the docking process will be aborted.
- c) The system operates in three modes (see below):
 - (i) Calibration check
 - (ii) Capturing
 - (iii) Tracking

1.4.1.1 Calibration Check

The docking process starts when an aircraft type is selected from the Operator Panel or, optionally, from the Superior System and connected external systems. While the system is idle, a calibration check is done every once per 30 minutes. If the recent calibration check has been successful the docking procedure will start immediately. If not, a calibration check will commence before the docking process starts. If any error occurs, a report will be transmitted. For more information, see Chapter 4 MAINTENANCE.

The calibration check is performed according to the sequence as in the figure below.





FIGURE 1.7 - CALIBRATION CHECK SEQUENCE

Note: The Laser Range Finder (LRF) transmits distance data from the approaching or departing aircraft to the Safedock Control Unit (CU) for processing.

1.4.1.2 Capturing

After successful calibration check, the system is automatically switched over to the capturing mode for distance data collection. In this mode the laser is scanning the predefined docking area to detect an approaching aircraft. The laser is also performing a check to make sure that the aircraft actually can be guided to its defined stop position without being obstructed by any foreign objects.

1.4.1.3 Tracking

When an aircraft is detected and its approximate position is confirmed, the system switches to tracking mode.

The Safedock system checks the graphical profile of the approaching aircraft and compares it to the corresponding parameters of the selected aircraft. If there is no mismatch between these parameters, the docking process will continue by measuring the aircraft nose position. As many aircraft have similar profiles, all types cannot be discriminated. However a safety margin is checked from measurements of the approaching aircraft's geometry. If the safety margin is too small, the display will show **STOP ID FAIL**, and the docking procedure will be automatically interrupted.

The Safedock measures the position of the aircraft in relation to aircraft stand centreline and the defined stop position for the particular aircraft type. During the tracking process the relative position of the aircraft is displayed on the Pilot Display unit, clearly visible from the whole cockpit area.

1.4.2 Safety with the Docking Procedure

Safedock system safety with the docking procedure is based on the approaching aircraft type as identified according to the type selected at start-of-docking. An acceptable physical safety margin between airport stand area equipment such as the Passenger Boarding Bridge (PBB) and the aircraft is also fundamental in a Safedock docking procedure (For more information, see Chapter 3 OPERATION § 5.3.1 Start of Docking with Interlocking Stands).

- 1.4.2.1 Risk factors and Safedock solutions:
 - 1. Operator error: the wrong aircraft type is selected or the operator does not observe that wrong aircraft type is approaching the stand.
 - Safedock aircraft identification and verification monitors the incoming aircraft type and displays information if the safety margin is too small, for example STOP ID FAIL.
 - 2. Pilot(s) error: the pilots do not observe the wrong aircraft type on the docking system display.
 - Safedock aircraft identification and verification monitors the incoming aircraft type and displays information if the safety margin is too small, for example STOP ID FAIL.
 - 3. When the approaching aircraft type does not correspond to the type selected at the start of docking, the docking system must detect or analyse the risk involved. The pilots are in this case instructed with a message to stop the docking procedure and wait for manual assistance.
 - Safedock aircraft identification and verification monitors the incoming aircraft type and displays information if the safety margin is too small, for example STOP ID FAIL.
 - 4. Obstruction in the apron area for example PBB out of position or positioned for an incorrect aircraft type.
 - Safedock monitors the stand area for the selected aircraft type and displays information if there is an obstruction, for example **Gate Blocked** or **STOP ID FAIL**.
 - 5. Fuel/water/sewage pits/foreign objects debris (FOD).
 - Safedock equipped with the surveillance camera option can monitor the stand area; however the aircraft docking procedures are also to be monitored by airport ground personnel on the apron.

1.4.2.2 Aircraft Safety Check

Aircraft Safety Check is based on differences in aircraft geometrical characteristics, for identification and verification in profiles, such as nose height and location of engines.

1.4.2.3 Performance

From a test run at Copenhagen International Airport with 200 docking events, the following results were verified:

- Accuracy for engine position: <u>+</u> 1.1 m (confidence of 99.7 %)
- Accuracy of the nose height measurement: <u>+</u>0.5 m

Limiting factors are:

- reflectivity of the aircraft surface
- speed of the aircraft
- aircraft turning, alignment to centreline
- low visibility
- ground level variations

1.4.2.4 Discrimination Criteria

Nose Height

The measured nose height must be within the tolerance limits \pm 0.5 m of the nose height of the selected aircraft type.

Nose-to-engine Distance

The measured nose-toengine distance must be within the tolerance limits -1m to +3m from the noseto-engine distance of the selected aircraft type. Otherwise the system will show **STOP/ID FAIL** when the aircraft is 15 meters from the stop position.



FIGURE 1.8 – DISCRIMINATION CRITERIA

1.4.2.5 Docking Other Aircraft Types (than the type selected)

If another aircraft type than the selected type is accepted by the Safedock system into the stand, it is stopped with the nose at the same position where the selected type is to stop (alternatively ID FAIL is shown, if the previous nose criteria is not met). The safety margin in this case (the Safety Margin Other Aircraft or A/C) is calculated as shown.



FIGURE 1.9 – DOCKING CALCULATION

Safety Margin Other A/C (worst case) =Safety Margin Selected A/C – Tolerance – Measuring accuracyExampleSafety Margin3 metreTolerance1 metreMeasuring accuracy1.1 metre

Conclusion

The safety margin is therefore be 0.9 m or greater, depending on the layout of stopping positions where the basic safety margin is 3m (to a fixed obstacle) or greater for all aircraft, stopped at the correct stop position.

1.4.2.6 Practical Aspects

If another aircraft type than the type selected is accepted into the stand (discrimination criteria is not met), there is a risk to the normal parking position and stop position accuracy.



FIGURE 1.10 – PRACTICAL ASPECTS

The deviation, "roll-over", from the normal stopping position is calculated as follows:

Roll-over = (Stopbar Other A/C-to-Stopbar Selected A/C) + (Nose-to-wheel Selected A/C) - (Nose-to-wheel Other A/C)

The calculation illustrates the result from a docking procedure, where the aircraft discrimination criteria does not result in a **STOP/ID FAIL** message, as the geometrical deviation was too small to be detected.



2. INTERFACES TO OTHER SYSTEMS

The diagram below describes the general Safedock interfaces to external systems. These might be:

- a) Superior System (GOS/ SafeControl Apron Management System) and related systems, such as FIDS/GMS and Central Maintenance Systems
- b) Maintenance PC
- c) GBMS (optional, an external maintenance system)
- d) AGL (optional)
- e) Passenger Loading Bridge/PBB (optional)



FIGURE 1.11 - INTERFACE STRUCTURE

2.1	SYSTEM AVAILABILITY/LINE REPLACEABLE UNITS	
	The table below contains all Line Replaceable Units (LRU) used in the Safedock system. For more information, see Chapter 5 DRAWINGS.	
2.1.1.1	Availability and Reliability General Definitions	
	The availability of a product depends on the following factors of an LRU:	
	MTBF = Mean Time Between Failures	
	MTTR = Mean Time To Repair	
	MLDT = Mean Waiting Time for Recourses	
	MDT = Mean Down Time (MTTR + MLDT)	

2.1.2 Reliability of Reparability of Line Replaceable Units The calculated MTBF and MTTR figures are according to the table below. Units are in hours. The table includes selected key components from Safedock system.

Note: This information is subject to change. For more information, see

www.safegate.com or contact Safegate.

QTY **MTBF** MTTR Line Replaceable Unit Control Unit Board 1 120 000 0.7 Motor Control Board 2 0.4 120 000 LED Board 9-42 400 000* 0.4 1 0.4 Laser Range Finder 120 000 2 Stepper Motor 150 000 0.4 **Power Supply** 1 120 000 0.4 1 0.4 **Operator Panel Board** 80 000 (Softkey)

*Note: A certain degree of redundancy has been given in these figures.

2.1.3 Reliability Calculation

For a typical Safedock system the below total MTBF_Safedock figure is calculated, not considering the fact that the system has a built-in temperature control system and that the system operation duty-cycle is only some 10 %.

1/MTBF_Safedock = 1/MTBF_Cu + 1/MTBF_Cpu + 2/MTBF_Mcb + 9/MTBF_Led + 1/MTBF_Laser + 2/MTBF_Motor + 1/MTBF_Power + 1/MTBF_OPanel

Values according to the table above give MTBF_Safedock = 9 600 hours.

This value does not correspond to the statistical value, found during a four year period of time. So, if we consider the following facts, a less conservative MTBF figure is being calculated.

- The Laser Range Finder is only switched on during 10% of time. A factor 10 is used for the calculation.
- Figures for the Operator Panel are calculated according to MIL-HDBK-27F. Only a few operations per hour are made. A factor of 4 will be used for the calculation.



- The system will be available for docking even if one LED display board has failed, unless it is one of the two azimuth guidance boards. This will increase operational reliability with a factor of 4.5.
- The Safedock system is temperature controlled, which will increase reliability with a factor 1.5.

1.5/MTBF_Safedock = 1/MTBF_Cu + 1/MTBF_Cpu + 2/MTBF_Mcb + 2/MTBF_Led + 0.1/MTBF_Laser + 2/MTBF_Motor + 1/MTBF_Power + 0.25/MTBF_OPanel

Using this formula, **considering operating temperature and duty cycle**, the calculated MTBF figure for the Safedock system would be **24 800 hours**.

2.1.4 Technical Availability

Suppose that continuous operation is 24 hours a day, and Mean Down Time (MDT) is 6 hours. Then, according to the formula $A_0 = MTBF/MTBF+MDT$, operational availability would be > 99.9%.

3.	TECHNICAL DATA		
3.1	PERFORMANCE		
	Stop position accuracy	0.1 m	
	Stop position distance	2 - 65 m (T1), 8 – 50 m (T2), 8 – 50 m (T3)	
	Note: This depends on configuration.		
	Azimuth accuracy	0.2°	
	Azimuth distance	up to 110 m, depending on configuration	
	Display type	High intensity LED	
	Display visibility angle	approximately 110° (T1), 24° (T2/3)	
	Display visibility distance	approximately 160 m (T1/2), 80 m (T3)	
	Note: This depends on configuration, disp	play number of characters.	
	Display number of characters	Up to 168 (T1), 24 (T2), 16 (T3)	
	Note: This depends on configuration, LED	Ds.	
	LED configuration (typical module totals)	42 (T1), 18, 24 (T2), 9, 15 (T3)	
	Maximum separation - two centre lines	30° (T1), 18° (T2/3)	
3.2	SAFEDOCK UNITS DIMENSIONS AND WEIGHTS		
3.2.1	Safedock Main Unit		
	T1 Main Unit		
	Dimensions, (built-in sun cover)	1858,5 x 1079 x 752+85,5 mm (H x W x D)	
	Note : Height x Width x Depth.		
	Weight	140-150 kg (308-331 lbs)	
	Note: This depends on configuration.		
	Mounting rails/clamps upper-lower distances 1449 mm		
	T2 Main Unit		
	Dimensions, (without sun cover)	1520 x 900 x 422 mm (H x W x D)	
	Dimensions, (with sun cover attached)	1547 x 958 x 650 mm (H x W x D)	
	Weight (depending on configuration)	100-110 kg (220-243 lbs)	
	Mounting rails/clamps upper-lower distances 1046 mm		
	T3 Main Unit		
	Dimensions, (without sun cover)	1370x 600 x 422 mm (H x W x D)	
	Dimensions, (with sun cover attached)	1396 X 656 X 650 mm (H X W X D)	
	Weight (depending on configuration)	90-100 kg (198-220 lbs)	
	Mounting fails/clamps upper-lower distance	es 690 mm	
3.2.2	Operator Panel	200 ··· 400 ··· 00 ······ (11 ···) (1 ··· D)	
	vveignt	Z KY / 4.4 IDS	
	Note: For more information, or more specific hardware configuration options see Chapter 5 DRAWINGS.		

3.3	SUB UNIT CHARACTERISTICS		
3.3.1	Power Unit		
	Power Requirements	100-115/100-230 VAC, 50/60Hz,	
		+-10% fluctuation.	
	Note. UL certification tested with 100-115	5 VAC 60Hz	
	Maximum power consumption	T1: 1000 W	
	(Depending on configuration)	T2: 520 W	
		T3: 400 W	
3.3.2	Control Unit		
	Microprocessor	ETX CPU module	
	Alarm system interface	Relay contact, potential free	
	Power Requirements	24 V	
3.3.3	Laser Scanning System		
	Laser Type:	GaAs semiconductor	
	Wave Length:	0.9 ± 0.1 μm	
	Beam Width:	approximately 30 mm in diameter	
	Beam Divergence:	5 mrad maximum	
		(full angle of circular beam)	
	Laser Class:	Class 1	
	Serial Interface:	RS485, 19200 Baud	
3.3.4	Operator Panel (OP softkey)		
	Micro controller:	Rabbit 2000	
	LCD Display	240 x128 pixel; subdivided into	
		2 lines of 5 soft-keys and	
		3 lines of 20 characters for text; backlit.	
	Serial Interface	RS485 (to Safedock Main Unit)	
	Keyboard	14 keys (10 soft keys + 4 fixed function)	
	PBB Interface	24 VDC, Opto coupled input	
	AGL Interface (lead-in light)	Relay contact, potential free	
3.3.5	Conduit Entry Points (cable glands, nu	its, holes)	
	Safedock (power supply/control) glands:	diameter is 9-13 mm.	
	Safedock (OP communication) nut:	diameter is 9-13 mm.	
	Safedock communication (option such as	GOS): diameter is 4-8 mm.	
	Operator Panel (Safedock communication) nut: diameter is 8-13 mm.		
	Operator Panel (option such as PBB) extra noies: diameter is 20.5 mm.		
	For more information, see Chapter 2 INSTALLATION or Chapter 5 DRAWINGS.		

3.4

3.4.1 Dust and Water Protection

ENVIRONMENTAL LIMITS

Protection against dust and water meets ICAO requirements of IP 54 (IEC 6 052 9).Safedock Display Unit:IP54 (T1/T2/3)Laser Unit:IP54 (T1/T2/3)Operator Panel (Option/softkey):IP 65

Note: UL certification only tested for IPX4.

3.4.1.1 IP classification

Classification of degree of protection provided by enclosure is according to IEC 529, IPXX. The IEC (International Electrotechnical Committee) is the world's leading organization that prepares and publishes International Standards for all electrical, electronic and related technologies. The IEC designation consists of the letters IP (ingress protection) followed by two numerals. The first characteristic numeral indicates the degree of protection provided by the enclosure with respect to persons and solid foreign objects entering the enclosure. The second characteristic numeral indicates the degree of protection provided by the enclosure with respect to the harmful ingress of water.

3.4.2 Installation Environment

The Safedock system is intended to be installed outside, and at an altitude not exceeding 2000m above sea level.

3.4.3 Temperature and Humidity Limits

The Safedock system withstands relatively extreme temperature and humid atmosphere without any adverse effects (corrosion or change of characteristics due to the absorption of humidity).

Ambient Temperature –25°C to +50 and +55°C when cooling aid option is included

Note: Ambient temperature down to -40°C excluding the operator panel

Storage Temperature –20°C to +60°C

Relative Humidity (Operational):

- 95% with a maximum temperature of 35°C
- 60% with a maximum temperature above 35°C

Relative Humidity (Storage):

75% with a maximum temperature of 60°C

Note: The Safedock unit is equipped with internal heating and scanning windowdefrosting elements to ensure proper cold weather operation. The unit can also be equipped with an internal cooling device (option) to ensure proper warm weather operation.

3.4.4 Storage
 It is recommended that units are kept in the shipping box and in a dry covered storage area until installed for operation.

 3.4.5 Wind Load
 The Safedock system is designed to resist damage in wind speed up to 44 m/s (no active operation).

 3.4.6 Snow Load

The Safedock system is designed for a snow load up to 1000 N/m².

Page 19 of 20

3.4.7	Brightness Environmental brightness range from direct sunshine down to an average luminance of at least 10 lux with a uniformity ratio (average to minimum) of not more than 4 to 1 measured at 2 m height.		
210	Vibration		
3.4.0	The Safedock system is tested according to IEC 68-2-64 to meet a level of satisfactory function at acceleration of 0.1G within the frequency range 10 - 100Hz.		
3.4.9	Acoustic Sound and Noise		
	The Safedock system is tested to meet a sound level not exceeding 45 dBA, relative a sound reference pressure of 2x10 ⁻⁵ Pa.		
	Note: This information may be subject to change for T1 with a Supercooler option.		
3.4.10	Pollution Limits	ollution Limits	
	Tested to pollution degree 2 (IEC 664)		
3.4.11 Installation Over-voltage Lin		ge Limits	
	Tested to Category II (II	=C 664)	
3.5	ELECTROMAGNETIC COMPATIBILITY		
3.5.1	General		
	The Safedock system is tested to fulfil all relevant requirements for EMI/EMC immunity as stated by FCC part 15 (47 CFR Part 15).		
	Also, the Safedock system is tested to fulfil all relevant requirements for EMC immunity as stated by EMC Directive 89/336/EEC and standards as in next section.		
3.5.2	Generic Standards		
	EN 50081-1:1992	Generic Emission Standard; Part 1: Residential, Commercial & Light Industry Environment	
	EN 50082-2:1995	Generic Immunity Standard Part 2: Industrial Environment	
3.5.3	Basic Standards		
	ENV 50140	EMC - Basic Immunity Standard Radiated RF electromagnetic fields immunity test	
	ENV 50204	EMC - Basic Immunity Standard Radiated RF electromagnetic fields immunity test (pulse modulated)	
	EN 61000-4-4	EMC, Part 4: Testing & measurement techniques.	
	Sect 4:	Transient immunity test	
	EN 61000-4-2	EMC, Part 4: Testing & measurement techniques.	
	Sect 2:	Electrostatic discharge immunity test.	
3.5.4	Product Family Standards		
	EN 55022	Limits and methods of measurement of radio interference characteristics of information technology equipment.	
	EN 55024	Immunity requirements for information technology and communications equipment. Only parts as Surges, Voltage Dips and Voltage Interruptions is tested.	

CHAPTER 2 INSTALLATION CONTENTS

Section	Description Pa	age No.
1.	SCOPE	3
1.1	INSTALLATION SCHEDULE	3
1.2	REQUIRED TOOLS AND EQUIPMENT	3
2.	INSTALLATION CONSIDERATIONS	
2.1	MOUNTING HEIGHT	4
2.2	STOP-POSITION	4
2.3	CENTRELINES	5
2.3.1	Aircraft Safety Check	6
2.4	TRACKING	6
2.5	CURVED CENTRELINE	6
2.6	FREE SPACE ON THE APRON	7
2.7	VIEWING RANGE	7
2.7.1	System without ID-Verification	8
2.7.2	System with ID-Verification	8
3.	MECHANICAL INSTALLATION	10
3.1	INSTALLATION PROCEDURE	10
3.1.1	General	10
3.1.2	Height Calculation	12
3.1.3	Offset Calculation	13
3.1.4	Mounting of Support Fixture	13
3.1.5	Installation of the Safedock Unit	15
3.1.6	Installation of the Operator Panel	16
3.1.7	Calibration Check (Auto Calibration)	16
4.	ELECTRICAL INSTALLATION	18
4.1	GENERAL	18
4.2	EARTHING THE SAFEDOCK HOUSING	19
4.3	SAFEDOCK CONNECTION TO MAINS	19
4.3.1	Main Switch Specification	19
4.4	CONNECTION OF COMMUNICATION LINES	19
4.4.1	General	19
4.4.2	Communication Cable	20
4.4.3	Cable Requirements, Solutions and Glands	20
4.4.4	Cable Connection to Operator Panel, Emergency and Chocks 20	Button
4.4.5	Cable Connection to Safedock Unit	21
4.5	OTHER CONNECTIONS (OPTIONS)	22
4.5.1	PBB Interlock	22
5.	SYSTEM CONFIGURATION	23
5.1	GENERAL	23

SAFEDOCK® Manual Chapter: 2 INSTALLATION

CONFIGURATION PHASES	23
PREPARATION	23
Prepare the Stand for Aircraft Stop-positions	23
Prepare the Maintenance Computer	25
Connect the Maintenance Computer to Operator Panel	25
COMMUNICATION	26
Configuration of Ethernet Converter Build In on Control Card	
Configuration of Camera (Option/Axis M1144L)	26
	CONFIGURATION PHASES PREPARATION Prepare the Stand for Aircraft Stop-positions Prepare the Maintenance Computer Connect the Maintenance Computer to Operator Panel COMMUNICATION Configuration of Ethernet Converter Build In on Control Card Configuration of Camera (Option/Axis M1144L)



WARNING! INVISIBLE LASER RADIATION

THE LASER OUTPUT FROM THIS SYSTEM IS WITHIN CLASS 1 LIMITS (USA FDA 21 CFR 1040.10 – 11 AND IEC 60825-1:2007) AS LONG AS THE RANGE FINDER IS INSTALLED AND OPERATED AS SPECIFIED BY SAFEGATE.

IF OPERATED IN ANY OTHER FASHION THAN DESCRIBED, THE RANGE FINDER IS CAPABLE OF EMITTING RADIATION UP TO CLASS 1M LIMITS.

CLASS 1 M DENOTES LASERS OR LASER SYSTEMS THAT CAN PRODUCE A HAZARD IF VIEWED THROUGH LIGHT COLLECTING OPTICS SUCH AS BINOCULARS.

1.

SCOPE

Installation of the Safedock System is performed in three phases and often by three different personnel categories:

- 1. Mechanical installation
- 2. Electrical installation
- 3. System configuration

Note: This document is focused on the mechanical and electrical installations with system configuration, for example software set-up procedures briefly described with references to other sections or chapters in the manual.

1.1 INSTALLATION SCHEDULE

The schedule presented in the table below should be used with the appropriate installation drawings.

ltem	Task	
1	Attach the support fixture to the wall or mast	
2	Mount the Safedock Unit on the support fixture	
3	Install the Operator Panel	
4	Mount the calibration plate	
5	Install interconnecting cables	
6	Connect a PC, with the Safedock Maintenance Tool, SMT, to the Operator Panel and perform the following:	
	- Calibrate the Safedock and define a centreline	
	- Set operating parameters	
	- Configure the Stand	
7	Carry out a functional check of the system	

Note: It is recommended to paint permanent or temporary centreline(s) and stopposition(s) on the apron before a Safedock installation, to aid proper alignment, calibration and configuration.

1.2 REQUIRED TOOLS AND EQUIPMENT

Tools and equipment needed for the installation are according to the table below:

Hand Tools	Equipment
Screwdrivers, standard sizes	Lap top PC computer, with SMT software
Pliers: regular, needle nose and diagonal	Multi-meter (U, I, R)
Adjustable end wrenches	Portable lift for 1 to 2 people:
Wire strippers	 Lifting height for standard installation: minimum 6 m (17 feet)
Level	Light crane:
Tape measure, > 10 m	 Lifting height for standard installation: 10 m (33 feet)

2.1

2. INSTALLATION CONSIDERATIONS

MOUNTING HEIGHT

Minimum mounting height, recommended, is 4.0 metres. This figure depends on the following factors:

- Maximum vehicle height on the service road
- Maximum nose height of the aircraft to be docked to the particular stand

Maximum mounting height, recommended, is 8.0 metres. This figure depends on the following factors:

- Minimum nose height of the aircraft to be docked to the particular stand
 - Maximum pilot eye viewing angle towards display is 15 degrees

Note: The minimum distance to the stop-position for a particular aircraft depends on the maximum downward viewing angle allowed. For more information, see § 2.2 Stop-Position.



FIGURE 2.1 MOUNTING HEIGHT

Note: A Safedock unit overlooking a PBB or walkway may have operational constraints, which requires an adjusted mounting height and/or re-positioning of aircraft stop-positions to create an obstacle free scanning area.

2.2 STOP-POSITION

The longest recommended stop-position is 65.0 metres (T1) or 50 metres (T2/3). Within this distance the lateral accuracy is \pm 0.2 metre. If the clip distance is 100 metres, 23 metres of tracking on the centreline are available for aircraft verification.

The shortest recommended stop-position is 2.0 metres (T1) or 8 metres (T2/3), but the angle to the aircraft nose shall never be more than 24 degrees, according to the picture below.



FIGURE 2.2 STOP-POSITION
Note: A stop-position must be less than a 24 degree angle from the Laser Scanning unit to the aircraft nose. A high mounting height may limit the shortest allowed stop-position. The shortest recommended stop-position may be as close as twice the difference between the mounting height and the aircraft nose height, but never shorter than 2.0 metres (T1) or 8 metres (T2/3).

For nose-distances that are set at the edge or outside the recommended range, it is important to always review each Safedock position individually for correct operation.

For the T1 model, having its Pilot display below the Laser Scanning unit must careful attention be paid in conjunction with short stop-position distances. Consideration of pilot viewing angle and vertical operational sector of the laser to see the nose at stop-position must be proven to be fulfilled. If not, can either the T1 model be ordered as a "split" assembly in 2 separate enclosures, Pilot display and Laser Scanning unit, or reconsideration of the gate layout and it's stop-positions be made.

2.3 CENTRELINES

The Safedock system can handle up to three centrelines, convergent or parallel. For an accurate guidance the centrelines must be placed within the laser's aircraft scanning range of the system. The limits for centreline position are defined according to the image below. The display reading sector is \pm 55 degrees (for all models).



FIGURE 2.3 CENTRELINES

Note: The nose of aircraft while at stop-position must be within the scanning range. It is recommended that the Pilot Display is in view for both pilot and co-pilot to allow docking from both positions.



2.3.1 Aircraft Safety Check

For systems using the "Aircraft Safety Check" feature, the engine of the aircraft must be within a \pm 30 degrees view area of the system. The aircraft must have been aligned to the centreline for at least 4 seconds, when more than 15 metres remain to the stopposition. Failure to obtain this condition will lead to an ID-FAIL situation.



FIGURE 2.4 AIRCRAFT SAFETY CHECK

2.4 TRACKING

When the Safedock system successfully locates an approaching aircraft within the far clip distance, tracking with azimuth guidance starts. The system can give azimuth guidance to a fuel truck, but it will eventually end with an ID fail. Therefore, azimuth guidance begins when the system acquires a lock onto an object (possibly but not necessarily an aircraft).

Identification (or verification) is the next part of the process, independent from tracking, where the physics of the incoming aircraft is verified vs. the physics of the aircraft expected. It is recommended to consider where aircraft tracking is to be started based on the following:

- 1. Distances to the countdown area, to stop-position(s) and the Safedock unit.
- 2. A frontal view of the approaching aircraft from the Safedock unit which is unobstructed (laser scanning view).
- 3. The distance from the Safedock unit from which the incoming aircraft will appear while entering the stand area.
- 4. Presence of service roads and/or crossing taxiways.

For more information, see 4A Stand Configuration Utility, § 4.5 Centreline.

Note: The Safedock system is capable of tracking an approaching aircraft from a distance of 110 m. However in most cases, the distance depends on site configuration, such as the approach to gate.

2.5 CURVED CENTRELINE

For a curved centreline, the angle between the optical axis of the system and the approaching aircraft may not exceed 20 degrees.



FIGURE 2.5 CURVED CENTRELINE

2.6 FREE SPACE ON THE APRON

Foreign obstacles might disturb the docking process. Therefore a specified area between the Safedock unit and the approaching aircraft must be cleared before the docking is started.

During the docking process, the system is tracking the aircraft nose and the vertical scan is \pm 5 degrees. The level of this scanning sector depends on laser height, aircraft position and aircraft size. High vehicles on a service road must not enter this sector once the Safedock system has been started.



FIGURE 2.6 FREE SPACE ON APRON

From the illustration above, the angle $\boldsymbol{\alpha}$ is calculated as it follows:

 $\alpha = \arctan L_S / (h_L - h_A) - 5$

This is the maximum angle for a sector where foreign objects are allowed.

VIEWING RANGE

2.7

The Safedock unit must have an unobstructed view of the aircraft nose throughout the docking procedure. For additional features (such as ID-verification) to work properly, the viewing range must be extended so that it covers the particular needs of the feature.

The system supports sideways clipping on both sides of the centreline. Using this feature, the system can be instructed to ignore objects beyond the side clipping limits, such as the Passenger Boarding Bridge (PBB). However, the side clipping should never be used to reduce the view of the system below what is specified in the sections below.

2.7.1 System without ID-Verification

A system without ID-verification will only need an unobstructed view to the nose of the aircraft in order to operate properly. Thus, the sideways clipping limits can be set as close to the centreline as defined by the width of the widest aircraft intended for docking at the stand. The minimum clipping angle to each side of the centreline can be defined by finding a line from the Safedock unit to a point half the aircraft width from the centreline at the stop-position (nose) for the aircraft.



FIGURE 2.7 VIEWING RANGE WITHOUT ID

The minimum viewing range is defined by finding the aircraft that needs the widest view according to:

 $\alpha = \text{ArcTan}((\text{aircraftWidth/2}) / \text{aircraftNosePos})$

Example: A B777-200 with stop-position (nose) 30m from the Safedock unit

aircraftWidth = 6.2m aircraftNosePos = 30.0m

 $\alpha = \text{ArcTan}(3.1 / 30.0) = 5.9^{\circ}$

The minimum viewing range without ID-verification is 5.9 degrees to either side of the centreline.

Note: A system using a centreline that is not perpendicular to the mounting of the Safedock unit will require a wider viewing range as the entire nose of the aircraft must be fully visible throughout the docking procedure.

2.7.2 System with ID-Verification

A Safedock system that uses the extended ID-verification feature needs a larger viewing range, as it must be able to find the location of the aircraft engine. The system will always prefer the away-from-bridge side engine in the verification procedure, unless this engine is found to be beyond the side clip limit. If the engine is found to be beyond the side clip limit. If the engine is found to be beyond the side clip limit.

Thus, one side (normally the bridge side) can use the same limit as for the above case. The view on the side selected for engine measurement, must be extended to allow the system a clear view of the engine.

Stand area, top view:



FIGURE 2.8 VIEWING RANGE WITH ID

The minimum viewing range that allows engine measurement is defined by finding the aircraft that needs the widest view according to:

 β = ArcTan(engineToCentre / (aircraftNosePos + 15 + engineToNose))

Example: A B777-200 with stop-position (nose) 30m from the Safedock unit

aircraftNosePos = 30.0m engineToCenter = 9.7m

engineToNose = 20.3m

 $\beta = \text{ArcTan}(9.7 / (30.0 + 15.0 + 20.3)) = 8,44^{\circ}$

The minimum viewing range with ID-verification is 8.4 degrees away from bridge and 5.9 degrees towards the bridge.



3. MECHANICAL INSTALLATION

This section provides installation engineers with instructions on how to install the Safedock system. Each installation is unique due to location, sighting and mounting of the equipment as well as local engineering practices.

Every installation should refer to a set of drawings for the proposed site. To install the system safely and efficiently, the drawings and the information in this manual are to be used. The installation must be carried out in accordance with NEC (if applicable) and other local electrical codes.

3.1 INSTALLATION PROCEDURE

3.1.1 General

The way in which the Safedock unit is installed varies from airport to airport. For example, it may be mounted on the wall of the terminal building, or on a mast, situated away from the terminal building.

When installed, the Safedock unit is usually mounted from 4 to 8 metres (12 to 24 feet, related to bottom edge of the unit) above ground. The actual mounting height depends on local conditions and the type of aircraft that will be docked to the terminal gate, taking for example into consideration if it is a wide-bodied or narrow-bodied aircraft. Where possible, the Safedock unit should be mounted such as it is centred over the aircraft stand centreline.

All Safedock units mounted to the terminal-wall at the same approximate height should use a sightline on the building, for example x-metres above ground, as the grading can vary from gate-to-gate. This is for aesthetic purposes only and at this stage, there is the flexibility to do so.

CAUTION: WHEN DETERMINING THE MOUNTING HEIGHT, THE POSSIBLE PRESENCE OF HIGH VEHICLES ON THE SERVICE ROAD IN FRONT OF THE DOCKING SYSTEM SHALL BE TAKEN INTO CONSIDERATION. SEE CHAPTER 2 INSTALLATION § 2.1 MOUNTING HEIGHT.

Clamp fasteners (5 ½" or 139.7 mm diameter) for attaching and mounting the Safedock unit to a support fixture, are included in the installation package. For T2/T3, there is also a tilt bracket included in the installation package allowing the cabinet (Pilot Display) to be directed slightly downwards avoiding most sun reflection from the display surface. For T1, there is no need for a tilt bracket as the angle is built-in with the display door.

A support fixture, for example a 5 ½" or 139.7 mm diameter pole, is not supplied as standard as local requirements may differ. Furthermore, fasteners and fixtures must often be furnished locally, since local building codes and engineering practices vary.

The figure below shows the Safedock unit rear view examples and the mounting hardware for a typical support fixture for mounting the unit.

Note: For more information, for example Safedock types with other/more specific configuration options, see Chapter 5 DRAWINGS.



FIGURE 2.9 SAFEDOCK T1 INSTALLATION MATERIAL



FIGURE 2.10 SAFEDOCK T2/3 INSTALLATION MATERIAL

3.1.2

Height Calculation

The installation height depends on the actual situation at each stand:

- The laser view toward aircraft must be unobstructed. Possible obstructions may include a PBB or vehicles on a service road.
- The aircraft at the stop-position must be visible in vertical range of the laser view. The aircraft types (mix) to be used and the range of stop-positions (to nose) affect the mounting height.
- Comfortable pilot view angles towards the Safedock unit throughout the docking must be considered.

If no acceptable mounting height at the desired position can be used, an alternative location for the Safedock may be necessary, for example a free standing pole.

Note: It is important to always check with the Project Manager for the location, height and alignment requirements, for each Safedock installation.

The following variables may be used as a guideline for height calculation:



FIGURE 2.11 HEIGHT CALCULATION

General recommendations:

- Mounting height of laser from 4 to 8 metres.
- Height of aircraft nose(s) are less than the height of laser.
- Stop-position(s) from 2 to 65 metres (T1) or 8 to 50 metres (T2/3).

Offset Calculation 3.1.3

The Safedock installation can also be installed according to an offset calculation, depending on the actual situation at each stand.

Note: It is important to fulfil requirements for an offset installation calculation as described in the table below. The Safedock unit angle of alignment (perpendicular or other) must also be carefully considered in relation to the centreline, for example for system aircraft identification on approach to the stand.



3.1.4 **Mounting of Support Fixture**

A support fixture is required for the Safedock unit to be attached to with clamps, for example a steel pipe Ø139.7 mm or 5 $\frac{1}{2}$ " in diameter. Clamps are supplied for these dimensions.

Make sure the support fixture is positioned according to recommendations, for example up to 3 parallel or convergent centrelines at:

- ± 15 degrees, minimum 2 metres to maximum 65 metres (T1) or
- ± 9 degrees, minimum 8 metres to maximum 50 metres (T2/3)

from the aircraft nose stop-position, at an angle of maximum 24 degrees from the unit to aircraft nose stop-position.

The support fixture shall be checked as described below:

- a) Using a level, check that the support fixture is vertical.
- b) Tighten all fasteners that hold the support fixture in place, for example to the wall or mast.

Page 13 of 26

3.1.4.1 Maximum Allowable Deflection in Mounting

The table below is a guideline to deflection when mounting on a support fixture.



3.1.5 Installation of the Safedock Unit

- (a) Check with the Project Manager for the exact height and alignment for every installation, as the stand requirements may differ. For example, verify alignment if mounted off-centre or if more than one centreline are to be used.
- (b) Attach appropriate lifting straps to the unit at suitable positions.
 - For T1, use a lifting strap and lift the unit via the build in eyebolt at the top. Lift carefully and do not jerk the unit while lifting.



FIGURE 2.14 T1 LIFT EXAMPLE

- For T2/3, use a lifting strap with load support from underneath:
 - Place a lifting strap around the sides/bottom of the unit.
 - Attach the sunshade sides as temporary lifting strap holding plates to the unit (side brackets/upper) to secure the lifting strap in place.

Note: Do not install the entire T2/3 sunshade until after the unit is fastened to the support fixture, to avoid lift damage!



FIGURE 2.15 T2/3 LIFT EXAMPLE

- (c) Lift the unit into position using a crane.
- (d) Position 2 clamp bolts in each rail, so that they are on opposite sides of the centre bolt hole in rail.
- (e) Fasten the unit to the support fixture with the clamps. The clamps (supplied) are for a steel pipe Ø139.7 mm or 5 ½" in diameter.
 Note: Tilt brackets (supplied for T2/3) are required if the pilot display is in direct sunlight at sunrise/sunset.
- (f) Using a level, check that the sides of the unit are vertical.
- (g) **Conduit** cable entry points (power and control wiring).
- (h) For T2/3: Assemble the sunshade and attach it to the unit using the M5 x 20 stainless steel screws and lock washers.
 Note: Install the T2/3 sunshade after the unit is fastened to the support fixture, to avoid damage when lifting!
- (i) For T1: Make sure all screws for the factory mounted sun shades are firm and tight.

Page 15 of 26

3.1.6 Installation of the Operator Panel

The Operator Panel is enclosed in a standard aluminium box and can be installed as it follows:

- Mount it on flat surfaces or posts using standard mounting equipment and fasteners.
- It can also be mounted on a pulpit, as the display provides a 6 o'clock view.

Note: Mount at normal shoulder height for best display readability.

The figure below shows the positions of the mounting holes, located on the rear of the Operator Panel. Conduit cable entry points ("Dead man grip" or "Emergency Stop" button) are located on the bottom of the Operator Panel.



FIGURE 2.16 OPERATOR PANEL MOUNTING HOLES

Note: Measurements are in mm.

3.1.7 Calibration Check (Auto Calibration)

A Safedock system must be configured with two reference points. The system checks the calibration automatically for each docking or at regular intervals, according to the references and system settings. If fixed equipment at the aircraft stand cannot be used to obtain reference points (for example a fixed PBB section), a calibration plate can be installed to obtain reference points.

3.1.7.1 Reference Points

Reference points to fixed equipment may be used for a calibration check. For more information, see Chapter 4A Stand Configuration Utility § 4.4.

3.1.7.2 Reference Points Using a Calibration Plate A calibration plate can be installed to obtain reference points. It can be mounted within the forward or the side scanning areas. The table below lists the scanning angles of the Safedock unit for the forward and the side scanning areas.

Scanning Area	Vertical Scanning Angle	Horizontal Scanning Angle
Forward area	+15°; -24° + means upward	+30°; -30° (T1) or +13°; -13° (T2/T3)
Side area	+ 5°; - 5 °	+2°; +8° (forward)

The calibration plate must also be mounted at least 3 metres from the Safedock unit, and there should not be any objects behind it for at least two metres.

The calibration plate must be sized as per below table for good performance. The minimum distance for the calibration plate is 3m from the Safedock unit. The maximum distance for the calibration plate is 30m.

Recommended minimum dimensions of a calibration plate:

Distance	Size
3-10m	0.3m
10-20m	0.4m
20-25m	0.5m
25-30m	0.6m

The calibration plate must be located within the Safedock unit's field of vision.

The field of vision is:



FIGURE 2.17 CALIBRATION CHECK



4. ELECTRICAL INSTALLATION

4.1 GENERAL

Cables for powering and operating the Safedock system must be run between the various sub-units of the system.

It is also recommended to use UPS to avoid any power-down while a docking procedure commences, which is a critical time.

A power budget, for UPS sizing requirements, should include typical idle current/KVA requirement and the maximum during docking.

The figure below gives an overview on how the different sub-units are to be connected.



Wiring Type 2

FIGURE 2.18 SAFEDOCK SYSTEM INTERCONNECTION CABLES

Note: GOS/SAM is an optional system that may not exist at your airport.

4.2 EARTHING THE SAFEDOCK HOUSING

It is supposed that the support fixture, used for mounting the Safedock unit, is connected to construction ground/earth for the current drain from lighting induced voltage surges. Alternatively, a copper cable of minimum 25 mm² connected to earth, must be available.

The Safedock unit shall be connected to earth (the earth connection point is delivered by a third party), using an "earth bonding strap" with a conductor area of 25 mm², which shall be connected to the ground point on the rear of the Safedock housing.

4.3 SAFEDOCK CONNECTION TO MAINS

The mains supply should be routed from its conduit entry point via the routing channel to the pole circuit breaker (mains disconnect device). Route it away from other conductors and components. A cable, $3 \times 1.5 \text{ mm}^2$, shall be used (or dimensions acc to local standard). It shall be connected to the Safedock unit or see Chapter 5 DRAWINGS. The protect earth (PE) wire shall be connected to chassis directly, as it enters the cabinet, to the yellow/green terminal. The cable inside the cabinet shall be as short as possible.

The PE/cable gland hole is located at the rear/lower area, in the Safedock unit, as in the figure.

Note: If the PE hole is not used, it is important to seal it using the rubber plug/bolt supplied in the Operator Panel package.



4.3.1 Main Switch Specification

A main switch shall be installed near the Safedock unit and shall be easily accessed by service personnel. The switch should have following specifications:

- Minimum Voltage Rating: 240 VAC
- Minimum Amperage Rating: 10 A
- Disconnects all phases and neutral simultaneously
- Marked/labelled as the main switch for the Safedock system

4.4 CONNECTION OF COMMUNICATION LINES

4.4.1 General

The following signals, associated with the Operator Panel, are to be connected to the Safedock main unit:

- 24 VDC power.
- Operator Panel communication lines.
- Emergency Stop line.
- Dead-man-switch line (option).
- Maintenance COM line.

Page 19 of 26

Note: It is recommended that the support fixture, used for mounting the Operator Panel, to be connected to construction ground/earth for the current drain from lightning induced voltage surges. Alternatively a copper cable, minimum 25 mm², connected to earth, should be available. The screws used for fastening the Operator Panel to the support fixture shall give the electrical connection to earth.

4.4.2 Communication Cable

A CAT 5 network patch cable shall be used for connection to Superior System. The cable length to nearby located network switch shall not exceed the current network standard.

4.4.3 Cable Requirements, Solutions and Glands

For the connection of the Operator Panel, a shielded twisted-pair (STP) cable, $6 \times 2 \times 0.5 \text{ mm}^2$ or 20 AWG, shall be used, thus with 2 spare pairs. The cable area is needed especially for the power supply. The cable should have a braided shield to obtain optimal noise immunity.

Note: Check with the Project Manager for any field-wiring diagrams that may override these instructions and/or include any additional work.

4.4.3.1 Cable Solutions

Cabling may depend on local supply or alternative requirements. It is recommended to discuss alternative cable category requirements with Safegate, as communication problems may arise in the field. Communication is dependent on the quality/category of the cable used. A general guideline is to use a cable with a length as short as possible (less than 100m) and with at least 2 spare wires, for example if any I/O points are connected into the Operator Panel, as in Safedock/PBB interlocks.

4.4.3.2 Cable Glands

The Operator Panel unit includes three Ø20.5 mm holes, one with a cable gland for connection to the Safedock unit and two plugged holes for other connection options, if required.

The Safedock unit includes two Ø20.5 mm holes with cable glands, one for connection to the Operator Panel and one for power. There is also one Ø12.5 mm hole with a cable gland, for communication to Superior System or other external systems.

In summary, the connection between the Operator Panel and the Safedock unit is designed with pre-drilled Ø20.5 mm holes with cable glands in each respective unit, for a cable between 8 mm and 13 mm in diameter.

4.4.4 Cable Connection to Operator Panel, Emergency and Chocks Button The cable shall be connected to terminals in the Operator Panel.

Note: It is important to connect all shields to the Operator Panel housing. The shield wire must be as short as possible. Alternatively EMC type cable glands shall be used for connecting cable shields directly to the chassis.

The line/pair for the external "Chocks On" button, if used, shall be installed according to sites specific drawings. Even an additional "Emergency Stop" button may be included, and this shall be installed in series with the emergency stop button circuitry of the Operator Panel.

Cables to the external "Emergency Stop" or "Chocks On" buttons shall also be shielded. The shield shall be connected to the Operator Panel housing.

4.4.5

Cable Connection to Safedock Unit

The cable from the Operator Panel shall be connected to terminals in the Safedock unit according to the drawings.

Note: It is important to connect the shields directly to the chassis, where it enters the Safedock housing - or to a ground terminal. Alternatively EMC type cable glands shall be used for connecting cable shields directly to the chassis.



FIGURE 2.20 CONNECTION OPTIONS - SAFEDOCK SIDE





FIGURE 2.21 CONNECTION OPTIONS - OPERATOR PANEL SIDE

4.5 OTHER CONNECTIONS (OPTIONS)

4.5.1 PBB Interlock

The Operator Panel can be connected to a Passenger Boarding Bridge (PBB) for interlock functionality. For example if the PBB is in a safe position/parked away from aircraft approach to gate area then a docking procedure can be started using the Operator Panel. Otherwise, if the PBB is not in a safe position there is a damage risk obstruction and a docking cannot be started.

And the other way around, when the docking procedure is started can the PBB be prevented from moving until the docking procedure has ended (aircraft parked).

Note: It is assumed that the PBB in question is capable to signal PBB location safe as well as to make use of the signal from Safedock that docking is in progress.

It is recommended to use shielded twisted pair cabling (2x2x0.5 mm²) for the connection, 2 dry contacts (potential free contacts) with the shield connected to the Operator Panel housing.

5. SYSTEM CONFIGURATION

5.1 GENERAL

After the installation of the Safedock unit, Operator Panel(s) and calibration plate, the system must be set-up to meet the demands or characteristics of the particular stand.

The set-up procedure at each stand is carried out using the Safedock Maintenance Tool. The Safedock Maintenance Tool can also be used to document each stand setup. A copy per installed stand shall be stored for the customer's approval during commissioning. The file shall also be maintained throughout the system life cycle.

For configuration and commissioning guidelines and in-depth description of these software utilities, see Chapter 4 MAINTENANCE and 4A Stand Configuration Utility.

5.2 CONFIGURATION PHASES

The Safedock system is set up by the following procedures:

- If applicable, define network details (IP settings). See Chapter 4 Maintenance
- Setting and definition of functionality
- Defining the gate area
- Setting calibration check points
- Configuration (setting aircraft types and their stop-positions and so on)
- Defining the centreline(s)
- Removing Echoes from Fixed Object
- Storing Stand Configuration Files

5.3 PREPARATION

This information is for airport Operations and Maintenance personnel to use as a reference for configuration and/or commissioning of a Safedock system, via an Operator Panel and a maintenance computer, at a stand with a single centreline. Text and image references may not depict the actual system being configured and commissioned.

Note: If any error occurs during system configuration and commissioning you can find supporting information in Chapter 4 MAINTENANCE § 5. Troubleshooting.

5.3.1 Prepare the Stand for Aircraft Stop-positions

Aircraft stop-positions are specific to each stand due to a number of different variables, for example aircraft type, PBB type and centreline length.

It is recommended for airport personnel to prepare each stand for Safedock configuration and commissioning works with stop distance/ aircraft type information from design drawings or actual aircraft dockings at the stand:

- Enter stand/gate, stop distance, aircraft type information in the table below, for future reference.
- Make sure ground markings are painted along the centreline for the aircraft type stop-positions to be used at the specific stand.
- This information is to be made available for Safegate and/or other airport personnel before commissioning or changing configuration settings in a Safedock system.

Aircraft Stop-Positions

Stand/Gate Name/Number:				
Stop Distance - nose wheel (unless noted)	Aircraft Type(s)	Stop Distance - nose wheel (unless noted)	Aircraft Type(s)	
Note: If notes are made	on this page, please f	orward a copy to site manag	ement for safe kee	

5.3.2 Prepare the Maintenance Computer The following are required for a local connection to a Safedock system via an Operator Panel (supplied by Safegate, if requested):

- Maintenance Computer a portable computer
- Configuration Software Safedock Maintenance Tool (SMT)
- Communication Cable a cable with an Operator Panel service outlet connector
- Interface Converter USB to RS-232-485 adaptor, if required

Make sure that the Safedock configuration software (SMT) is installed on the computer, supplied on the software CD. **Note**: If a Maintenance Computer is supplied by Safegate, the software is pre-installed.

Make sure the laptop battery is fully charged before use in the field (airside).

5.3.3 Connect the Maintenance Computer to Operator Panel

- a) Connect the communication cable to the Operator Panel service outlet.
- b) Connect the cable to the computer, via the interface converter USB adaptor, if required.



5.4 COMMUNICATION

5.4.1 Configuration of Ethernet Converter Build In on Control Card
 If communication to Superior System is required, each Safedock must be given an IP address and the corresponding network parameters.
 This is manually edited directly in the Operator Panel under the Test menu. See Chapter 2A Operator Panel Softkey Setup.

5.4.2 Configuration of Camera (Option/Axis M1144L) Each camera must be configured uniquely to its Safedock (IP Address, Subnet mask etc.). Two programs are required to configure the camera: Axis IP_Installer and a web browser (it is recommended to use Internet Explorer). A LAN connection must also be available between the computer and the camera: it is

A LAN connection must also be available between the computer and the camera; it is recommended to use an Ethernet Cross-over cable is used between computer and the camera.

The software to configure the M1144L camera does not need to be installed. It can be run from the directory: *Software/Common/Axis/IpUtility.exe*.

Camera set up and tools to configure: http://www.axis.com/files/manuals/um_m1144_I_45408_en_1206.pdf

CHAPTER 2 INSTALLATION - APPENDIX A OPERATOR PANEL SOFTKEY SETUP (OPTION) CONTENTS

Section	Description	Page No.
1.	SCOPE	3
2.	CONTRAST ADJUSTMENT	3
3.	NAVIGATING MENUS	4
3.1	ENTERING SETUP MODE	4
3.2	EXITING SETUP MODE	4
3.3	ACCESSING SETUP FUNCTIONS AND NAVIGATING THE MENUS	S4
3.4	RETURNING TO SETUP MAIN MENU AND SAVING SETTINGS	4
3.5	SETUP FUNCTION PARAMETERS	4
3.5.1	LCD Contrast	5
3.5.2	Com1 Address	5
3.5.3	Com2 Address (not in use)	5
3.5.4	Key Form	5
3.5.5	Default	5
3.6	TEST FUNCTIONS	5
3.6.1	Keyboard Test	5
3.6.2	Com1 Test	5
3.6.3	Com2 Test (not in use)	6
3.6.4	Output Test	6
3.6.5	Input Test	6
3.6.6	Display Test	6
3.6.7	Temperature Sensor	6
4.	EXTRA OPERATOR PANEL (OPTION)	7
5.	OPERATION AND MAINTENANCE MODES	8
5.1	OPERATION MODES	8
5.2	MAINTENANCE MODE	8
5.3	SET AN OPERATION OR MAINTENANCE MODE	8



Note: This page is blank for convenient double-sided printing.

1. SCOPE

This document explains different setup procedures for a Softkey Operator Panel. Configuration of the Operator Panel requires the power to the unit to be cut. An exception is for contrast adjustment, which can be adjusted while Safedock software is running.

2. CONTRAST ADJUSTMENT

The display contrast can be adjusted when the system is in "Emergency Stop" mode. Press the right arrow button to access the contrast adjustment menu and the display shows the following:



Use **+/-** keys to adjust the contrast; when the contrast is adjusted, the current value is be shown, replacing the **Emergency Stop** message. When the contrast is as desired, press the **Save** key to store the value to non-volatile storage.

If there are multiple Operator Panels connected to the same Safedock system, they all display the same text. However, each unit is managed separately; for example a contrast change only affects the unit on which keys are being pressed and settings are saved.

Note: It is not recommended to adjust the contrast for multiple Operator Panel units at the same time, as the text on all units is the result of the last key press, no matter which Operator Panel unit key is pressed. In other words, the Operator Panel unit which sends the last key press is in control of the contrast change menu for all Operator Panels. If the Safedock system receives commands from alternating Operator Panel units, it only requests and displays the current contrast value without making any changes.

For more information, see § 4 Extra Operator Panel (option) in this chapter.



3. NAVIGATING MENUS

3.1 ENTERING SETUP MODE

To enter the setup menus:

- (a) Open the Operator Panel box and disconnect the J1 connector, to power off the unit. If J2 is connected, it must also be disconnected until the setup is completed.
- (b) Press and hold the CANCEL button and reconnect J1. The display shows the setup main menu with version info and two keys: Setup func and Test func.



(c) Release the **CANCEL** button.

Note: When the setup is completed, J2 may be reconnected.

3.2 EXITING SETUP MODE

When all the settings are completed, the Operator Panel is put back into operation by pressing the **ENTER** key from the setup main menu.

3.3 ACCESSING SETUP FUNCTIONS AND NAVIGATING THE MENUS

- (a) While in the setup main menu, press the **Setup func** key to access the setup functions.
- (b) Press a designated key to access the desired setup function.
- (c) Press the **CANCEL** button to leave a setup function and return to the setup function menu.

3.4 RETURNING TO SETUP MAIN MENU AND SAVING SETTINGS

Press the **CANCEL** button to return to the setup main menu. If the current menu is the setup functions menu, the unit prompts to save the settings or not. Press **YES** to save or **NO** to discard any changes made.

3.5 SETUP FUNCTION PARAMETERS

Following parameters are available to be set up in the Operator Panel unit:

			-	+
LCD Contr	Com1 Addr	Com2 Addr	Key Form	Deflt

Press a designated key to select a parameter and then use the + and – keys to modify each parameter.

3.5.1 LCD Contrast

The default value is 25. Adjust the contrast as required so that the background is not too dark and the display texts are easy to read.

3.5.2 Com1 Address

A communication Com1 address is used for Operator Panel to Safedock communication. Valid addresses use variables: 1-4 (the default value is set to 1).

Note: Each Operator Panel must have its own unique address. Using the same address in two or more units (extra Operator Panels) connected to a Safedock system gives unpredictable results. This parameter only affects Operator Panel units with software version 1.2 or later.

For more information, see section 4 Extra Operator Panel (option) in this Chapter.

3.5.3 Com2 Address (not in use)

Note: The Com2 address is not currently in use or supported by software.

3.5.4 Key Form

There are three key forms available in the Operator Panel unit software. Key form two must be used as it shows information texts for selection using adjacent softkeys, as intended in the software design.

Note: Do not use key form zero or one as they wrongly give an impression of a touch display. If key form is changed, the selected key form is not shown until the Setup functions menu is shown.

3.5.5 Default

The **Defit** key sets all parameters to their default values as follows: LCD contrast = 25. Com1 address = 1, Com2 address = 1 and Key form = 2.

3.6 TEST FUNCTIONS

There are several test functions available to diagnose an Operator Panel unit as follows:

	OFF	ON	-	+
Keyb Test	Com1 Test	Com2 Test	Out Test	Displ Test

3.6.1 Keyboard Test

If **Keyb Test** is selected, press each key to verify a unique number appears in the display.

Note: The **CANCEL** key does not display a number, it returns to the test functions menu.

3.6.2 Com1 Test

If **Com1 Test** is selected, the display shows data sent and received on Com 1 (J1). The sent (out) and received (in) character must always be the same.



Note: Com1 Test can only be performed when the Safedock software is not running as Safedock data interferes with the test. A connection to the Loader using SMT is required before starting this test.

3.6.3 Com2 Test (not in use) Note: Com2 test is not currently in use or supported by software.

3.6.4 Output Test

Connect a cable specifically designed for testing the outputs to connector J9 to test outputs 1-6. Connect the cable to J10 for test of outputs 7-11. Use the +/- keys to select the output and then the **On/Off** keys to toggle the current output.

To test output 12 (Maintenance relay), using an ohm-meter connected to J1 pin 3 and J3 pin 1. Toggle the output and verify that the ohm-meter indicates this.

The status of output 13 (heater) is indicated by LED D17 on the circuit board. Toggle the output and verify that the LED is lit only when the output is active.

3.6.5 Input Test

The input test is automatically enabled. Whenever a change is detected on the inputs the display shows the current status of all inputs.

To test the inputs, connect to the outputs with a specific cable design. To test inputs 0 to 7, connect the cable between J9 and J8. This makes outputs 1-5 control inputs 0-4 and output 6 controls all three inputs 5, 6 and 7.

Connect the cable between J9 and J7 to test inputs 8 – 15. This makes outputs 1-5 control inputs 8-12 and output 6 controls input 13, 14 and 15.

3.6.6 Display Test

If selected, a pattern appears in the display.

3.6.7 Temperature Sensor

When entering the test functions menu the temperature measurement from a sensor appears on the display, for example **Temp: 26**. To test this sensor, chill IC11 and check the temperature value in the display falls.

4. EXTRA OPERATOR PANEL (OPTION)

The Operator Panel can be connected to an extra Operator Panel, to control Safedock from another place.

The extra Operator Panel must also be set with a unique Com1 address. For example, if Operator Panel1 Com1 address is 1 (default) then Operator Panel2 Com1 address is to be set to 2.

Note: The system only accepts input via the first Operator Panel (Com1 address 1). Outputs on all connected Operator Panels are always in the same state.

Connect and set and extra Operator Panel as follows:



Page 7 of 8

5. OPERATION AND MAINTENANCE MODES

The Safedock system can be equipped with several operation/ maintenance mode options, if required. Modes are set via key switches built into the Operator Panel.

5.1 OPERATION MODES

The Safedock system operation modes include:

- REMOTE Aircraft related commands are only allowed from Superior System. The test menu on a local Operator Panel is blocked. The Operator Panel does not allow any aircraft related commands, such as Park On and Start Docking.
- OFF Both Operator Panel and Superior System commands are blocked.
- **LOCAL** Aircraft related commands are only allowed from the local Operator Panel. All incoming commands from Superior System are ignored.

Note: The operation mode status appears in the Operator Panel and is reported to Superior System.

5.2 MAINTENANCE MODE

The Safedock system includes a normal or a special maintenance mode:

- **NORMAL** The system is not in maintenance mode.
- **MAINT.** The system is in maintenance mode, but remains fully functional for local operations. Only maintenance status is reported to the Superior System. *Note: Maintenance mode status appears in the Operator Panel.*

5.3 SET AN OPERATION OR MAINTENANCE MODE

From the Operator Panel, use a key to set a mode.

- a. For operation modes, use the right key:
 REMOTE turn left.
 OFF vertical position.
 LOCAL turn right.
- b. For maintenance modes, use the left key: NORMAL – vertical position.
 MAINT. – turn right.



FIGURE 2A.1 OPERATOR PANEL MODES

CHAPTER 3 OPERATION CONTENTS

Section	Description	Page No.
1.	INTRODUCTION	3
1.1	SYSTEM OVERVIEW	3
1.2	OPERATIONAL STATES	3
2.	OPERATING DETAILS	4
2.1	THE DOCKING PROCEDURE IN REGULAR CONDITIONS	4
2.2	THE DOCKING PROCEDURE IN ABNORMAL CONDITIONS	6
2.3	DOCKING SAFETY FEATURES	8
2.3.1	Test Functions Before Docking	8
2.3.2	Aircraft Profile Check	9
2.3.3	Continuous Test Procedure	9
2.3.4	Indication of Power Failure	9
2.4	SAFEDOCK STATISTICS	9
2.4.1	View Safedock Statistics	9
2.5	SUPERIOR SYSTEM CONNECTIVITY STATUS	11
2.5.1	View Superior System Connectivity Status and Activity	11
3.	TECHNICAL DESCRIPTION	12
3.1	SYSTEM UNITS	12
3.1.1	Control Unit	12
3.1.2	Laser Scanning Unit	12
3.1.3	Operator Panel	13
3.1.4	Pilot Display	13
3.1.5	Superior System Interface (Option)	13
3.2	PERFORMANCE CHARACTERISTICS	13
3.2.1	Scanning Area	13
3.2.2	Guidance Performance	13
3.2.3	Display Unit	14
3.3	ELECTRICAL SUPPLY	14
3.4	OPERATION	14
3.4.1	Calibration Check	14
3.4.2	Scanning	14
3.4.3	Tracking	14
4.	SOFTWARE PROGRAMMES	15
4.1	DEVELOPMENT ENVIRONMENT	15
4.2	SOFTWARE ITEMS	15
4.3	SOFTWARE FUNCTIONS	15
4.4	SOFTWARE FLOWCHART	16
4.	SAFETY PROCEDURES	18
4.1	CHECK OF ACCESS RIGHTS	18



4.2	DISCREPANCIES FROM THE DESCRIBED DOCKING ROUTINE	18
4.3	GENERAL WARNING	18
4.4	MANUAL EMERGENCY-STOP	18
4.5	ITEMS TO CHECK BEFORE ENTERING THE STAND AREA	19
4.6	THE SBU MESSAGE	19
4.7	ERRORS OR MALFUNCTIONS	19
4.8	CHECKS BY GROUND PERSONNEL FOR AIRCRAFT DOCKING	19
5.	STAND ADJACENCY RULES	20

1. INTRODUCTION

This document is describing the general operation of the Safedock system. Illustrations are given for a generic system or a variation on this, which means that they may deviate slightly from the system actually delivered.

1.1 SYSTEM OVERVIEW

The Safedock system is designed to provide fast and safe guidance during the aircraft's approach into the stand area. It is based on laser scanning and distance measuring technology, and it tracks the lateral and longitudinal position of the aircraft. This 3-dimensional technique ensures that the pilot is provided with the correct stop indication for the aircraft.

All necessary information, such as azimuth guidance, distance to stop, aircraft type, etc. is shown on an alphanumeric LED display that is clearly visible for both pilots.

Each individual Safedock system is controlled from the local Operator Panel or from Superior System (Option). From Superior System all connected Safedock systems can be individually controlled and monitored.

The Superior System is also the gateway to the airports database system, FIS, which optionally provides information on scheduled and active flights.

1.2 OPERATIONAL STATES

The Safedock system has the following possible operational states and also a maintenance mode:

- 1. READY- the system is idling, waiting for a command; Stand can be cleared.
- 2. SCHEDULED an initiate-docking command has been received from Superior System, if applicable.
- 3. PREPARED an initiate-docking command has been received from Superior System (if applicable) and the stand has been cleared.
- 4. ACTIVE docking has been started:
 - (i) Self-test
 - (ii) Scanning for aircraft
 - (iii) Tracking aircraft
 - (iv) Aircraft check
- 5. PARKED the docking procedure has been completed.

During the maintenance mode, the following functions can be performed:

- 1. Program Load
- 2. Stand Configuration and Calibration
- 3. Dump of Safedock configuration data
- 4. Dump of Safedock docking log

2. OPERATING DETAILS

2.1 THE DOCKING PROCEDURE IN REGULAR CONDITIONS

The following section is a step-by-step description of a docking routine, how it is started, performed and completed. Some figure examples are given below with different Safedock display variations illustrated.

- 1. The docking procedure can be activated from any one of the following three options:
 - (i) Safedock operator selecting the aircraft type to be docked from the Operators Panel.
 - (ii) Remote selection of aircraft type by operator from the Superior System. The selection can require confirmation at the local Operator Panel, or directly activate the docking procedure (option).
 - (iii) Automatic selection of stand and aircraft type, via Superior System, based on FIS flight information available to Superior System by means of a database interface. The selection can require confirmation at the local Operator Panel, or directly activate the docking procedure (option).
- 2. At start of docking an aircraft type is assigned. A profile for the selected aircraft has previously been set up using parameters such as nose outline, height and optionally engine position. During the docking procedure the laser equipment measures the corresponding parameters of the actual aircraft. The captured data are compared to a safety profile of the assigned aircraft. If the safety margin related to the aircraft type concerned is too small, the docking procedure will be aborted with an **ID Fail** condition.
- 3. (Option) Before a docking procedure is activated, the operator must confirm his action by pressing a four-digit password. When the password is confirmed the system is activated.
- 4. Before the docking can be commenced, a self-test is carried out by the Safedock system. The correct position and distance of 2 reference points is checked. A failed test will abort the docking procedure with a **Calibration Fail** condition.
- 5. (Option) The apron area is also checked for foreign objects, using the Apron scan feature. If any blocking objects are detected, the docking procedure will be paused with an Apron blocked condition (showing the message APRON BLOCKED on the Operator Panel and WAIT APRON on the Pilot Display). The docking procedure will resume when the blocking object leaves the area.
- 6. The selected aircraft type is then shown on the Pilot Display and on the Operator Panel. The pilot display will show a WELCOME indicator, consisting of floating arrows on the closing rate display indicating that the system is ready for docking. The laser scanning unit is now activated. In bad weather conditions, the downgrade mode shows AIRCRAFT TYPE and SLOW and the floating arrows are disabled. This is a message to the pilot to take extra care. The "closing rate" bar will light up, as is normal, when the aircraft is detected by the system.
- 7. When the laser scanning unit is activated, the Operator Panel will show the aircraft type and status **ACTIVE**. The system is now scanning for an approaching aircraft.
- The pilot display will switch to "Lead in" mode, consisting of closing rate and azimuth guidance indication. When the aircraft is caught by the laser, usually > 50 metres before the stop-position. The Operator Panel will now show TRACKING.

- 9. During the approach the aircraft type assigned will be verified by the Safedock system. When the aircraft type has been verified, the Operator Panel will show **IDENTIFIED**.
- 10. If the aircraft speed exceeds the configured maximum value, the message SLOW will be displayed to the pilot. The speed limit is configurable per aircraft type out to 10m prior to the stop-position, fixed at 3m/s out to 20m and 4m/s outside 20m. Software configuration options are further described in Chapter 4A Stand Configuration Utility.
- 11. The closing rate indicator will indicate the distance to go by shortening distance bar from a distance of 15m prior to stop-position as the aircraft approaches.
- 12. If aircraft type verification is not established within 15 metres from the stopposition, the docking procedure will be aborted with an **ID FAIL** condition.
- 13. When the stop-position is reached, the Pilot Display will show **STOP**, with a red stop symbol. All closing rate LED indicators will extinguish.
- 14. As long as the aircraft keeps moving the STOP message remains on the display. When the aircraft has been standing still for a configurable period of time, the message on the Pilot Display will change from STOP to OK or TOO FAR, if the roll distance is larger than the configured value. This will also be indicated on the Operator Panel.
- 15. After a configurable period of time, the status will change to **PARKED** which is displayed on the Operator Panel.

2.2 THE DOCKING PROCEDURE IN ABNORMAL CONDITIONS

If an object is blocking the view from the Safedock laser scanning unit toward the stop-position of the selected aircraft type, the system will be unable to perform the docking procedure. When an object is detected between the laser scanning unit and the stop-position, the system will halt the docking procedure and display a **GATE BLOCK** warning and a **WAIT** message. When the blocking object is removed, the docking procedure will be resumed.

When objects are detected close to the Safedock system and its laser window the system will halt the docking procedure and display a **VIEW BLOCK** warning and **WAIT** message. When the disturbing objects are removed, for example by cleaning the laser window, or when the aircraft is found approaching, the docking procedure will be resumed.

If an unrecoverable error occurs during a docking procedure, a **SBU** (Safety Back Up) condition exists. In this case an alternate method to guide aircraft to the stop-position must be used, as the docking procedure cannot be completed. SBU stop conditions are:

- 1. A hardware failure
- 2. Aircraft far off the centreline and less than 2m to the stop-position.
- 3. View from laser scanning unit to aircraft blocked with less than 2m to the stopposition.



FIGURE 3.1 – CRITICAL ZONES

(Option)

Note: The SBU event can occur after the pilot has got the **STOP** message, but the aircraft is still rolling. In this case a manual **Park On** command must be done in order to complete the docking sequence with a **Blocks On** message to Superior System and external systems.


2.3 DOCKING SAFETY FEATURES

2.3.1 Test Functions Before Docking

- Errors and their solutions are described in Chapter 4 MAINTENANCE.
 - 1. When the Safedock system is started, a built-in error detection program checks the system for correct operation.
 - If an error should occur within the system, at initial start-up, the Pilot Display will show ERROR or ERR depending on display type (see below figure 3.3). The type of the system error will be shown on the Operator Panel in clear text. The Safedock cannot be activated, if the system is not fully functional.





3. If a fault occurs, after the system has been activated, and an aircraft is approaching the terminal stand, the Pilot Display will show a **STOP** message.

A detailed list of error messages and their appropriate rectification procedures are included in *Chapter 4 MAINTENANCE*, § 5. *Troubleshooting*.

4. The figure below is an example of an error displayed on the Operator Panel.



FIGURE 3.4 – ERROR MESSAGE AT OPERATOR PANEL

2.3.2 Aircraft Profile Check

During the docking procedure the nose profile of the approaching aircraft is roughly checked with the nose of the aircraft selected at start-of-docking.

- 1. If the aircraft nose profile has not been verified within 15 metres of the stopposition, the Pilot Display will show **STOP/ID FAIL**.
- 2. The figure below illustrates the message **ID FAILED** on the Operator Panel.



FIGURE 3.5 – OP STATUS INFORMATION

- 3. (Option) The docking procedure can be restarted with engine verification temporarily suspended by using the **Override** function.
- 2.3.3 Continuous Test Procedure

The system undertakes a continuous self-test procedure, even when the system is in the idle mode. If an error occurs during the continuous test procedure, the error will be registered in the Error Log.

The system automatically performs auto calibration test at regular time intervals (every thirty minutes). Before the Safedock system gets activated, it checks if the latest auto calibration test was successful or not. If successful, the system starts-up without performing a new test, thus, reducing start-up time. If unsuccessful, a new auto calibration test is performed before the system is activated. If the test is not passed, the system will not be activated, and an error message will be displayed on the Operator Panel, Pilot Display and Superior System, if connected.

2.3.4 Indication of Power Failure

In case of a power failure, the Pilot Display turns black and the docking procedure is interrupted. If the option of UPS is included, the current on-going docking procedure commences (max 20min) and **Blocked by UPS** is displayed in the Operator Panel.

2.4 SAFEDOCK STATISTICS

Safedock (software version 0.9.01 or later) includes some basic statistics, for example events such as the number of dockings or "ID fail" messages and more. Statistics are viewed using the Operator Panel.

2.4.1 View Safedock Statistics



From the Operator Panel, select Test key.	Test SAFEDOCK SYSTEM READY Park Start
	FIGURE 3.6 – OPERATOR PANEL TEST
Press the right arrow button \rightarrow for the next Test menu page.	Walk TestView LogsOP TestLight
	FIGURE 3.7 – OPERATOR PANEL TEST MENU
Select Statistics.	Set Re- IP Program version SOS 1.1.2 Com Stati stics Cal Test
	FIGURE 3.8 – OPERATOR PANEL STATISTICS
From the Statistics menu, press the softkey for the specific statistics you'd like to see.	Reset Back laser STATISTICS Laser Total Ok time dock ID- time dock fails
	FIGURE 3.9 – OPERATOR PANEL STATISTICS
Select Laser time for run time in seconds.	Reset Back laser Back Laser run time: <xx> seconds Since : <yyyy-mm-dd> Laser Laser Total Ok time dock. ID- time dock. fails</yyyy-mm-dd></xx>
	FIGURE 3.10 – OPERATOR PANEL LASER TIME
Select Total dock for the number of dockings.	Reset laser Back Number of dockings: <x> Laser Total Ok time dock. ID- fails</x>
	FIGURE 3.11 – OPERATOR PANEL TOTAL DOCKINGS
Select Ok dock for the number of successful dockings.	Reset laser Back Successful dockings: <x> Laser Total Ok ID- time dock. fails</x>
	FIGURE 3.12 – OPERATOR PANEL SUCCESSFUL DOCKINGS
Select Id fails for the number of aircraft identification problems.	Reset Back laser Number of ID-Fail: <x> Laser Total Ok ID-</x>
	time dock. dock. fails
	FIGURE 3.13 – OPERATOR PANEL ID FAIL EVENTS
Select Reset laser and Confirm to reset the laser time. Note : This operation is to be performed whenever a laser unit is replaced.	Confirm laser time reset Reset on : <yyyy-mm-dd> Accept</yyyy-mm-dd>

2.5	SUPERIOR SYSTEM CONNECTIVITY ST Safedock can display Superior System cor	ATUS nnectivity status.
2.5.1	View Superior System Connectivity Stat	tus and Activity
	From the Test menu, press he right arrow button → Select Com Info .	Set IP Re- start Program version SOS 1.1.2 Start Com Stati Info Stati Test FIGURE 3.15 – OPERATOR PANEL SUPERIOR SYSTEM CONNECTIVITY
	The IP field displays the IP address of the Safedock system. The ID field indicates the communication ID for the system. The Rec.ID field indicates the ID on incoming communication data from the superior system (if available).	FIGURE 3.16 – OPERATOR PANEL SUPERIOR SYSTEM CONNECTIVITY STATUS
	If Superior System communication data is received, an animation cycle repeats with symbols appears (to show there is activity): / then - then \ then I (appear repeatedly) or until Back is selected.	FIGURE 3.17 – OPERATOR PANEL SUPERIOR SYSTEM CONNECTIVITY ACTIVITY
	When Safedock receives communication data from Superior System but the address is incorrect, for example the ID is configured to another COMM ID, Rec.ID is the (incorrect) address of the data received from Superior System.	Comminfo IP 192.168.2.101 ID 1 Rec.ID 2 FIGURE 3.18 – OPERATOR PANEL SUPERIOR SYSTEM CONNECTIVITY ADDRESS

3. TECHNICAL DESCRIPTION

The Safedock system uses a scanning Laser Distance Meter (LDM) to measure the location of an approaching aircraft. Information of the aircraft position relative to the pre-selected stop-position is presented by means of a display to both pilots.

3.1 SYSTEM UNITS

The Safedock system consists of five major system units:

- 1. Control Unit
- 2. Laser Scanning Unit
- 3. Operator Panel
- 4. Display Unit
- 5. Superior System Interface



3.1.1 Control Unit

The Control Unit is the processing heart of the Safedock system. It will accept user input commands from the Safedock Operator Panel or via the Superior System Interface.

Alphanumeric information and aircraft position data are presented on the Pilot Display. The control unit is also responsible for positioning of the mirrors in the Laser Scanning Unit and processing of the distance data provided by the Laser Scanning Unit. The Control Unit maintains a database of information about the aircraft types configured for docking by the system and their stop-positions.

3.1.2 Laser Scanning Unit

The Laser Scanning Unit comprises a Laser Distance Meter (LDM) and two mirrors mounted on the shafts of motors.

The LDM uses laser pulses to measure the distance to any object the laser beam is directed toward. The motor mounted mirrors are used to direct the laser beam in the horizontal and vertical plane, respectively. This design gives the system the ability to make a 3-dimensional scan of the stand area.

3.1.3 Operator Panel

The Operator Panel is the primary source of user input to the system. It comprises a 14 key keyboard and a LCD display.

The keyboard is divided into 10 menu selection keys and 4 special function keys. The menu selection keys are also used for numeric input, such as user verification of commands. The display is used to give the operator visual feedback of the systems operation.

3.1.4 Pilot Display

The Pilot Display is constructed using a set of Light Emitting Diode matrices. The display is divided into two parts:

- The top part is used as an alphanumeric display capable of displaying one or two lines of text.
- The lower part of the display is used to indicate the aircraft's position relative to the centreline and the stop-position during a docking procedure.

3.1.5 Superior System Interface (Option)

The Superior System Interface is the optional link between the Safedock system and a central control and monitoring system, the Superior System. It is also used as a gateway to other external systems and to receive information about scheduled arrivals and departures from FIS.

Different types of information can be presented on the Pilot Display: flight number, estimated time, next/previous port-of-call and time remaining to departure. The information about a scheduled arrival can be also presented on the Operator Panel for easy activation of the docking procedure.

The Safedock system uses the Superior System Interface to report **Block-ON/OFF** times to the central control system for statistics and billing purposes. All Safedock events and errors will also be sent to the central system, where they will be stored in a log file.

3.2 PERFORMANCE CHARACTERISTICS

3.2.1 Scanning Area

3.2.2

Safedock (Options)	Туре 1	Туре 2/3
Horizontal range during capturing mode:	<u>+</u> 10°	<u>+</u> 10°
Horizontal range during docking:	<u>+</u> 30°	<u>+</u> 13°

The vertical scanning range is relative to the Safedock system horizon.Vertical scanning range above the horizon: $\pm 15^{\circ}$ $+ 5^{\circ}$ Vertical scanning range under the horizon: $- 24^{\circ}$ $- 24^{\circ}$ Guidance Performance $+ 0.2^{\circ}$ $+ 0.2^{\circ}$ Stop Position Accuracy:+ 0.1 m



3.2.3	Display Unit	
	Visibility/Readability CAT3A:	160m (T1/2) 80m (T3)
	Display Type:	Alphanumeric, LED
3.3	ELECTRICAL SUPPLY	

The Safedock system is power supplied from the 115/230VAC mains, using an internal power supply unit to generate the 24 VDC power used by the system.

3.4 OPERATION

This section is a brief description of the Safedock system operation. A detailed description of the operating procedures is found in the Chapter 3 Appendix A Operating Procedures.

- 1. In the Safedock system a number of aircraft types are defined by a set of parameters such as: nose, height and optionally aircraft geometry. At start of docking the operator assigns an aircraft. During a docking procedure the laser equipment measures the corresponding parameters of the actual aircraft.
- 2. The individual Safedock system is operated from the Operator Panel at apron level or from the Superior System. From Superior System all connected systems can be individually controlled and monitored.
- 3. During the docking process, the system operates in three modes: Calibration Check, Scanning and Tracking.

3.4.1 Calibration Check

The docking procedure starts when an aircraft type is selected from the Operator Panel or from the Superior System/FIS. If the previous automatic auto calibration test was not successful, then the system automatically makes a new calibration check which must be successful, before the system changes over into Scanning mode. If this test is not successful, the error message **AUTOCAL FAILED** appears on the Operator Panel and **STOP** on the Pilot Display (for information on diagnose and rectification, see *Chapter 4 MAINTENANCE, § 5. Troubleshooting.*

3.4.2 Scanning

After successful calibration check, the system is switched over to the Scanning mode for distance data collection. In this mode the laser is scanning the pre-defined docking area to detect an approaching aircraft. When an aircraft is detected, and its approximate position is confirmed, the system switches to Tracking mode.

3.4.3 Tracking

The Safedock system checks the nose height and optionally the outline of the approaching aircraft and compares it to the corresponding parameters of the selected aircraft. If there is no mismatch between these parameters, the docking process will continue by measuring the aircraft nose position. As many aircraft have similar profiles, all types cannot be discriminated. However a safety margin is always checked from measurements of the approaching aircraft's geometry, if this option has been included.

If the safety margin is too small, the display will show **STOP ID FAIL**, and the docking procedure will be automatically interrupted. The Safedock system measures the position of the aircraft in relation to aircraft stand centreline and the defined stopposition for the particular aircraft type. During the tracking process the relative position of the aircraft is displayed on the Pilot Display, clearly visible for both pilots from the aircraft cockpit.

4. SOFTWARE PROGRAMMES

4.1 DEVELOPMENT ENVIRONMENT

Software development has been done using C++ compiler on a Microsoft Windows PC platform.

4.2 SOFTWARE ITEMS

Software items and the actual versions being used are apparent from the Software Configuration List. How to handle and install these items is described in Chapter 4 MAINTENANCE.

The following software items are related to the Safedock system:

System parts:

- 1. SgBoot.rta.- start-up process for the system software.
- 2. SgShell.rtb automated shell process for the software system.
- 3. Loader.rtb fallback program loader process of the Safedock System.
- 4. SgApp.rtb main application of the Safedock. This software item controls the Safedock System, i.e. laser measuring equipment, Pilot Display, Operator Panel and interfaces to external systems.
- 5. <various>.edb system data including the system calibration and configuration data, aircraft physics database and configuration history.
- 6. Folder: Profiles a folder containing a set of data files with aircraft physical profiles, one for each aircraft type used by the system.
- 7. Folder: Dgs<various> folders containing log files from the system.

Supporting tools:

- SMT.exe maintenance software package for Safedock. The software is executed on the Superior System for making Program Load, Parameter Load, Calibration and Stand Configuration etc. It can also be used locally on a maintenance PC, connected to the Operator Panel's service outlet or via the network.
- 9. SLV utility program, Safedock Log Viewer is used to view log files from the system.

SOFTWARE FUNCTIONS

This section is a brief description of functions performed by software.

- 1. Acquisition of data from:
 - (i) Laser Distance Meter
 - (ii) Motor Position
 - (iii) Operator Control Panel (commands)
 - (iv) Superior System (commands)
- 2. Output data to:
 - (i) Laser Scanning Unit (scanner positions)
 - (ii) Display Unit (guidance information)
 - (iii) Operator Control Panel (status information)
 - (iv) Superior System (status information)
- 3. Menu-driven man-machine interface
- 4. Real time calculation and presentation of parameters such as:
 - (i) Aircraft type verification
 - (ii) Tracking positioning
 - (iii) Closing Rate data
 - (iv) Azimuth Guidance data

4.3

4.4

- 5. Calibration Control function
- 6. Storage of data
 - (i) Aircraft parameters
 - (ii) Stand parameters
 - (iii) Log files etc

SOFTWARE FLOWCHART

The software state diagram on next page illustrates the docking process from state READY to state PARKED.

The different states are described in the following table.

State	Description
IN OPERATION	The system is available for normal operation.
READY	The system is idling and awaiting a command.
MAINTENANCE	The system is taken out of operation for maintenance purpose.
SCHEDULED	A docking procedure has been initiated by Superior System and
	the system is awaiting confirmation by the local operator.
PREPARED	A docking procedure has been initiated by Superior System and the operator has cleared the stand. The system is awaiting activation.
ABORT	The local operator has aborted the docking, suggested by
SCHEDULED DOCKING	Superior System.
DOCKING	A docking procedure has been started.
TESTING	A system self-test is performed. This test includes verification of configured parameters, aircraft profile and data. It also includes an extensive test of the system hardware and a calibration check.
ERROR	An error has been encountered during system self-test.
ACTIVE	The system is active and scanning the stand area for an approaching aircraft.
DOCKING	An aircraft has been detected approaching the stand area.
TRACKING	The system is tracking an incoming aircraft. The aircraft is continuously compared to a set of stored parameters, attempting to verify the type of the incoming aircraft.
ID VERIFIED	The system is tracking an incoming aircraft. The aircraft type has been verified within specified limits.
ABORT DOCKING	An operator has aborted the docking procedure.
ID FAILED	The aircraft is closer than 15m to the stop-position, and has not been identified.
SBU STOP	A non-recoverable error has occurred during the docking due to one of the following causes:
	Aircraft too far off centreline close to the stop-position.
	System failure.
	Hardware failure.
PARKED	The aircraft is parked at the stop-position. The system will continually scan for departure of the aircraft.
EMERGENCY STOP	The Emergency-Stop function has been activated. The system is unavailable for further operation until the Emergency-Stop function is deactivated. The system will revert to the ready state upon release of the Emergency-Stop button. Optionally, the system can be configured to resume the last docking procedure upon release of Emergency-Stop button.



4. SAFETY PROCEDURES

4.1

CHECK OF ACCESS RIGHTS

For security reasons, Safedock commands can be password restricted, if required.

WARNING! PASSWORD INFORMATION SHALL ONLY BE GIVEN TO AUTHORIZED PERSONNEL. IT IS ADVISED TO NEVER KEEP CODES IN WRITING THAT COULD BE ASSOCIATED WITH THE SYSTEM.



DISCREPANCIES FROM THE DESCRIBED DOCKING ROUTINE

WARNING! IF THE PILOT DISPLAY UNIT OR THE OPERATOR PANEL INDICATES ANYTHING OTHER THAN WHAT IS DESCRIBED IN THE DOCKING ROUTINE, THE OPERATOR MUST ACTIVATE THE EMERGENCY-STOP BUTTON TO PREVENT DAMAGE TO THE AIRCRAFT, GROUND EQUIPMENT OR INJURY TO PERSONNEL.

REASONS FOR SPURIOUS INDICATIONS ON EITHER DISPLAY MUST BE RECTIFIED BEFORE THE DOCKING PROCEDURE CAN RECOMMENCE.

The following should be checked during the docking procedure:

- A. When the **Aircraft Type** is shown on the Operator Panel and Pilot Display unit, the Safedock system is ready for docking.
- B. Ensure that the **Aircraft Type** displayed is the same as the actual aircraft type approaching the stand.
- C. When the aircraft turns from the taxiway onto the terminal stand centreline, ensure the Operator Panel message changes from **ACTIVE** to **TRACKING**, and then to **IDENTIFIED** as the aircraft approaches the gate.
- D. Ensure the Pilot Display indicates the azimuth lateral position and the closing rate LED indicators are activated.
- E. As the aircraft is approaching the stop-position, ensure the closing rate LED indicators are gradually turned off from the bottom.
- F. When the aircraft has reached the stop-position, ensure the Operator Panel shows **DOCKING OK** and the Pilot Display shows **STOP** (in red).

GENERAL WARNING

The Safedock system has a built-in error detection program to inform the aircraft pilot of impending dangers during the docking procedure.



WARNING! IF THE PILOT IS UNSURE OF THE INFORMATION BEING SHOWN ON THE PILOT DISPLAY UNIT, HE MUST IMMEDIATELY STOP THE AIRCRAFT AND OBTAIN FURTHER INFORMATION FOR CLEARANCE.

GROUND OPERATORS SHALL PRESS THE EMERGENCY-STOP BUTTON IF, FOR ANY REASON, THERE IS A NEED TO INFORM THE PILOT TO STOP THE AIRCRAFT.

4.4 MANUAL EMERGENCY-STOP

When an Emergency-Stop button is operated, the Operator Panel will show **EMERGENCY-STOP** and the alphanumeric display will indicate **STOP**.

4.3



FIGURE 3.21 – OPERATOR PANEL EMERGENCY STOP BUTTON

4.5

ITEMS TO CHECK BEFORE ENTERING THE STAND AREA

The Safedock system has a built-in error detection program to inform the aircraft pilot of impending dangers from large objects within the docking area during the docking procedure.



WARNING! THE PILOT SHALL NOT ENTER THE GATE AREA, UNLESS THE DOCKING SYSTEM IS SHOWING THE VERTICAL RUNNING ARROWS. THE PILOT MUST NOT PROCEED BEYOND THE BRIDGE CAB, UNLESS THESE ARROWS HAVE BEEN REPLACED BY THE CLOSING RATE BAR. ADDITIONALLY, THE PILOT SHALL NOT ENTER THE STAND AREA UNLESS THE AIRCRAFT TYPE AND ANY OTHER DISPLAYED INFORMATION IS

THE AIRCRAFT TYPE AND ANY OTHER DISPLAYED INFORMATION IS CORRECT FOR THE AIRCRAFT THEY ARE DOCKING.

4.6 THE SBU MESSAGE

The message **STOP SBU** means that docking has been interrupted and has to be resumed by manual guidance. DO NOT RESUME DOCKING UNDER SAFEDOCK GUIDANCE!

4.7 ERRORS OR MALFUNCTIONS

If for any reason the Safedock system fails or reports an error, please take note of any details that may have caused the problem and report the error and supporting details to the appropriate maintenance personnel.

4.8 CHECKS BY GROUND PERSONNEL FOR AIRCRAFT DOCKING

Below there are some general checks that the head Marshall or ground crew should perform as a part of the aircraft docking procedure when using the Safedock system:

- 1. The Gate/Docking area cleared of obstacles prior to aircraft arrival.
- 2. The Safedock unit view is not obstructed by vehicles or other equipment.
- 3. The Passenger Boarding Bridge is safely parked away from the approaching aircraft.
- 4. The selected aircraft type and sub-type are shown on Operator Panel and Pilot Display and correct for the arriving aircraft. If not, abort the current aircraft selection and re-activate for the proper aircraft type.
- 5. Be ready to press the **Emergency-Stop** button if an unsafe condition should arise during the aircraft docking.

Page 19 of 22

5. STAND ADJACENCY RULES

Standalone Safedock operations can be enhanced with a Superior System to further improve safety and efficiency.

Safedock units connected in a Superior System network with adjacent gate status provide:

- Overall status for connected gates.
- Information based upon aircraft already parked or actively scheduled and awaiting to be parked at adjacent gates.
- An awareness of specific aircraft types parked at each gate compared to adjacent gates.
- Adjacent gate information and rules determine if each Safedock can park a selected aircraft type at the target gate.
- Rules/decisions for Safedock operation.

Superior System manages gate adjacency rules with an Interlock function.



(c) Operator Panel display

Airport personnel can start an aircraft docking locally at the gate, from an Operator Panel, or from a Superior System workstation.

When an aircraft docking is started, the selected aircraft type detail is provided for Superior System. Superior System checks adjacent gate status for aircraft parked or actively awaiting to be parked and any adjacency rules imposed on the selected aircraft type.

If the rules do not allow for an aircraft type to dock, the docking request is denied and an information message appears, for example

- in Superior System: **Blocked** with stand and aircraft information
- in the Operator Panel display: INTERLOCKED BY:

<Aircraft type> **AT** <Stand>.



Note: This page is blank for convenient double-sided printing.

CHAPTER 3 OPERATION – APPENDIX A OPERATING PROCEDURES CONTENTS

Section	Description F	² age No.
1.	LOCAL START OF DOCKING – REGULAR CONDITIONS	3
1.1	AIRCRAFT DOCKING ACTIVATION	3
1.2	SELF-TEST	4
1.3	CAPTURE	4
1.4	TRACKING	5
1.5	CLOSING RATE	6
1.6	ALIGNED TO CENTRE	7
1.7	SLOW (DECREASE SPEED)	8
1.8	AZIMUTH GUIDANCE	9
1.9	STOP POSITION REACHED	10
1.10	DOCKING COMPLETED	11
1.11	STATUS INFO	12
1.12	PARK ON	12
1.13	PARK OFF	14
2.	LOCAL START OF DOCKING – ABNORMAL CONDITIONS	15
2.1	LOST AIRCRAFT DETECTION	15
2.2	BAD WEATHER CONDITIONS	16
2.3	OVERSHOOT	17
2.4	STOP SHORT	18
2.5	FAILED AIRCRAFT VERIFICATION (ID FAIL)	19
2.5.1	Override ID FAIL	19
2.5.2	Event or Fault Diagnosis	20
2.6	POWER FAILURE	21
2.7	SYSTEM BREAKDOWN	21
2.8	EMERGENCY-STOP	22
2.9	SBU STOP	22
2.10	GATE BLOCKED	23
2.11	VIEW BLOCKED	23
2.12	CONFIGURATION ERROR	24
2.13	REMOTE START OF DOCKING – FROM SUPERIOR SYSTEM (OP	ΓΙΟΝ) 25
2.13.1	Start of Docking with Interlocking Stands	25
2.13.2	Start of Docking with Activation	26
2.14	REMOTE START OF DOCKING – FROM FIDS (OPTION)	29
2.14.1	The Schedule Command	29
2.14.2	Automatic Docking	29
2.14.3	Docking Abort Command	30

Note: This page is blank for convenient double-sided printing.

The following description covers both the local control procedures of Safedock and the optional operation of Safedock on commands from Superior System.

For security reasons some Safedock systems are configured with a password feature for the authorisation of commands. For more information, see Chapter 4A Stand Configuration Utility.

1. LOCAL START OF DOCKING – REGULAR CONDITIONS

1.1 AIRCRAFT DOCKING ACTIVATION

Description				Pos	ition
Aircraft docking activation Safedock system is read SYSTEM followed by a side docking procedure can be START DOCKING mess AIRCRAFT. Instructions to Operators • Determine aircraft for • Press the arrows the arrows the system of the system.	on is performed a by to operate, the status message. be initiated by pr sage appears, fo s: or docking: desired aircraft exact sub-type o show all listed	at the Operator Pa e panel will show: If the status is RI essing the Start I ollowed by the opti type key. key, if required (p sub-types).	ress left-right	Gate area: En (The aircraft is en route to gat	npty on the ground e).
continue the aircraft doc the switch cover.	king activation v	with the help of the	0-9 digits on		
Image Operator Papel		Ima	age Pilot Displa	у	
Operator Faller	T1-42	T2-18	T2S-24	Т3-9	T3-15
System Idle menu					
6 7 8 9 0 ENTER PASSWORD: <td></td> <td></td> <td></td> <td></td> <td></td>					

SELF-TEST

1.2 SELF-T	EST				
	Description	on		Posi	ition
After selecting the aircraft for docking, a self-test and reference point check is carried out by the Safedock system to confirm docking accuracy.				Gate area: Em (The aircraft is en route to gate	npty on the ground e).
Failing the self-test will r the Operator Panel and reference point check wi	esult in an error an ERR x on the ill result in an Al	code displayed in e Pilot Display. Fa JTOCAL ERROR	text format on ailing the or ERR 3 .	_	
Image Image Pilot Displa			у		
Operator Paner	T1-42	T2-18	T2S-24	Т3-9	T3-15
<aircraft type=""> <flight> TESTING Shut down</flight></aircraft>					

1.3

I <Aircraft type> <Flight> ACTIVE

Shut down

CAPTURE

	Positi	ion					
The system is activated approaching aircraft and WARNING BEYOND T HAVE BEE RATE BAR	and in Active mo this is indicated THE PILOT MI THE BRIDGE, U N SUPERSEDE	ode, scanning for I by floating arrow UST NOT PROCE NLESS THE ARF ED BY THE CLOS	an s. EED COWS SING	Gate area: Empty (The aircraft is on t route to gate).	the ground en		
 Instructions to Operators Check that the correption Display. The lead-in 	s: ect aircraft type is line is to be follo estem is still in A	s displayed on the owed.	Pilot				
nose reaches the Passe Emergency-Stop button	nger Boarding E immediately!	the					
Image Image Image Pilot D				play			
	T1-42	T1-42 T2-18 T2S-24 T3-9 T3-15					

1.4 TRACK	ING				
	Descriptio	on		Posit	ion
The system has capture verifying it. The floating indicator and floating an	ed the aircraft ar arrows are repla row.	nd is actively track aced by a yellow o	ing and centreline	Sys	king ten
 A flashing red and/c for azimuth guidanc 	or yellow arrow i e.	ndicates the direc	tion to turn		STOP
The yellow arrow inclusion centreline.	dicates the aircr	aft position in rela	tion to the	CAI	3 22 15m
The centreline "dista arrows to a filled clo the aircraft nears its	ance-to-go" indio sing-rate bar. 7 configured stop	cator changes from The closing-rate b p-position.	m floating ar shrinks as	Â	idance
Instructions to Operator	s:			(†*)	rrea uth Gu
 Check that the correct Display. When the states the message IDENT 	ect aircraft type selected and the FIFIED appears	is displayed on th e verified aircraft ty on the Operator F	e Pilot /pe match, Panel display.	Service road	toon the second
Image		Im	age Pilot Displa	ay	
Operator Panel	T1-42	T2-18	T2S-24	T3-9	T3-15
<aircraft type=""> <flight> TRACKING Shut down <aircraft type=""> <flight> IDENTIFIED Shut down</flight></aircraft></flight></aircraft>					



1.5 CLOSING RATE



1.6 ALIGNED TO CENTRE



1.7 SLOW (DECREASE SPEED)

	\	,			
	Description	on		Posi	ition
The Safedock system is The limit speed for slow in the 0-10m range from The limits further out are Note: A speed of 2 m/s If the aircraft is approach will show SLOW as a wa	configured with down indication the stop-positio fixed:10-20m 3 <i>is approximately</i> hing faster than arning to the pilo	a slowdown active is configurable pe n, with a default s m/s; more than 2 v 7 km/h, 4 mph or the accepted spee ts.	e zone. er aircraft type etting of 2m/s. 0m 4m/s r 3 knots. ed, the system	Aircraft continu into gate.	ies approach
Image Operator Papel		Ima	age Pilot Displa	у	
Operator Paner	T1-42	T2-18	T2S-24	Т3-9	T3-15
<aircraft type=""> <flight> TRACKING Shut down</flight></aircraft>	No Digital Count	No Digital Count	BAG NDC	NDC	NDC

1.8 AZIMUTH GUIDANCE

	Descriptio	on		Posit	ion
The aircraft is at the dis aircraft is not aligned to position to the centreline direction to turn.	played distance centre, a yellow e, and a red flas	from the stop-pos arrow indicates a hing arrow indicat	sition. If the in aircraft's les the	Service road	copture 8 Casing and a land
	Image Pilot Display				
Image Operator Bapol		Im	age Pilot Displ	ay	
Image Operator Panel	T1-42	lm T2-18	age Pilot Displ T2S-24	ay T3-9	T3-15
Image Operator Panel	T1-42	Im T2-18	age Pilot Displ	ay T3-9	T3-15



1.9

STOP POSITION REACHED



1.10 DOCKING COMPLETED





Page 11 of 30

1.11 STATUS INFO

Description				Posit	ion
If the Safedock system ON, GPU On (for Grour or other status message upon Operator Panel ke conditions (if connected and is parked. The CH on the Operator Panel of displayed one after the expires.	ock system is provided with optional support of CHOCKS n (for Ground Power Unit or 400Hz), PCA ON (for PC-Air) us messages, they will be displayed on the Pilot Display for Panel key selection, external button or actual sensed f connected) after the aircraft reaches the stop-position d. The CHOCKS ON status is provided via button press ator Panel or a separate button. Status messages will be the after the other and continue until a programmed timeout				king teen STOP Data UD oreo Azimuth Guidance Azimuth Guidance
Image	Image Pilot Dis			lay	
Operator Panel	T1-42	T2-18	T2S-24	Т3-9	T3-15
<aircraft type=""> <flight> PARKED Shut down</flight></aircraft>	CHOCK				

1.12 PARK ON

	Description	Position
If a docking procedure cannot automatically come to a PARKED state, the Marshal can manually set this from the Operator Panel. (It is required for enabling the following PARK-OFF procedure.)		Docking System
The sequence is started with the Safedock system in the quiescent state and the Operator Panel showing the message SAFEDOCK SYSTEM READY .		
Instructions to Operators:		
To initiate the operation press Park On key.		
Determine aircraft for docking:		
i.	Press the desired aircraft type key.	uidonc
ii.	Press the exact sub-type key, if required (press left-right arrows to show all listed sub-types).	Copture (D area (Azimuth G
iii.	(option) Enter the 4-digit operation-level password	Service road
System enters Parked state:		$\overline{\Lambda}$
i.	The system verifies that an object matching the selected aircraft is present at the stand.	

ii. Check that t Operator Pa	the PARKED me anel display	essage is displaye	d on the			
Image Operator Papel	Image Pilot Display					
	T1-42	T2-18	T2S-24	T3-9	T3-15	
(a) Test						
(b) (i) (b) Select aircraft Air- bus ing Brit- AeroS raer ker						
(b) (ii) (ii) (ii) (ii) (ii) (ii) (ii) (ii) (ii) (iii) ((iii)) (iii) (iii) ((iii)) ((iii)) ((iii)) ((iii)						
$(C) \begin{bmatrix} 6 & 7 & 8 & 9 & 0 \\ ENTER PASSWORD: \\ \\ \\ 1 & 2 & 3 & 4 & 5 \end{bmatrix}$						
(d) <arrest type=""> (i) VERIFYING PRESENCE</arrest>						
(d) (ii) (iii)						



PARK OFF

Description				Posi	tion	
When an aircraft has de by the Marshal, if the Sa the departure of the airc The sequence is started PARKED message. <i>Instructions to Operators</i> (a) To initiate the opera (b) (option) Enter the 4- (c) Check that the SAF I displayed on the Op	Service road	Stew Capture 8 Capture 8 Capture 8 10 10 12 12 12 12 12 12 12 12 12 12				
Image Image Image Pilot Disp			ige Pilot Displa	lay		
Operator Panel	T1-42	T2-18	T26 24			
			125-24	Т3-9	T3-15	
(a) Test Aircraft type> PARKED Park Off Off			123-24	T3-9	T3-15	
(a)			123-24	T3-9	T3-15	

2. LOCAL START OF DOCKING – ABNORMAL CONDITIONS

If an object is blocking the view from the Safedock laser scanning unit toward the stop-position of the selected aircraft type, the system will be unable to perform the docking procedure. When an object is detected between the laser scanning unit and the stop-position, the system will halt the docking procedure and display a **GATE BLOCK** warning message. When the blocking object is removed, the docking procedure will be resumed.

If an unrecoverable error occurs during a docking procedure, a SBU (Safety Back Up) condition exists. In this case an alternate method to guide aircraft to the stop-position must be used, as the docking procedure cannot be completed. SBU stop conditions are:

- (a) The aircraft is far off the centreline and less than 2m to the stop-position.
- (b) The view from the laser scanning unit to the aircraft is blocked with less than 2m to the stop-position.
- (c) A hardware failure has occurred.



WARNING! AN OBJECT MUST NEVER BE PLACED IN FRONT OF THE SAFEDOCK UNIT AND CLOSER THAN 1.5 METRES TO THE LASER WINDOW. SUCH AN OBJECT WOULD VIOLATE PROPER DOCKING PERFORMANCE!

2.1 LOST AIRCRAFT DETECTION

Description					Position	
If the detected aircraft is lost during docking, before 15m to stop-position, the display shows WAIT . The docking continues as soon as the system detects the aircraft again.				Aircraft stops and waits as directed by the Pilots Display.		
During penetration into the stand, the aircraft geometry is checked. If, for any reason, aircraft verification is not made 15m before the stop-position, the Pilot Display shows STOP and WAIT .						
Note : This may only be a system event and not a fault. The system requires time for safety checks, apron sweeps, aircraft capture and ID checks before the closing rate to stop-position (to analyse the possible cause of the incident, see § 2.5.2 Event or Fault Diagnosis in this Chapter).						
Image	Image Pilot Display					
Operator Panel	T1-42 T2-18 T2S-24 T3-9 T3-1					T3-15
<aircraft type=""> <flight> ACTIVE Shut down</flight></aircraft>						



2.2 BAD WEATHER CONDITIONS

Description				Position	
During heavy fog, rain o be reduced. When the system is acti- disables the floating arro- soon as the system deter rate bar appears. If the system has been of verification (check of en- blinks to give attention. Note: THE PILOT MUS UNLESS THE CLOSING ground operator must pri docking.	or snow, the visibility for the docking system can tivated and in Capture mode, the Pilot Display rows and shows SLOW and the Aircraft type. As tects the approaching aircraft, the vertical closing- configured in this mode, to make a shortened ID ngine position excluded), the aircraft symbol <i>IST NOT PROCEED BEYOND THE BRIDGE,</i> <i>NG-RATE BAR IS SHOWN. Failing this, the</i> press the Emergency-Stop button to abort the			Aircraft proceeds into the gate area at a reduced speed as directed by the Pilot Display.	
Image Operator Banal	Image Image Pilot Displa			у	
Operator Patier	T1-42	T2-18	T2S-24	Т3-9	T3-15
<aircraft type=""> <flight> DOWNGRADE Shut down</flight></aircraft>					

2.3 OVERSHOOT



2.4 STOP SHORT



2.5

FAILED AIRCRAFT VERIFICATION (ID FAIL)

Description	Position
After capture of the aircraft, its geometry is checked against a stored profile. If, for any reason, aircraft verification is not confirmed 15m before the stop-position, the Pilot Display will show STOP followed by ID FAIL .	Gate area: Empty (aircraft is on the ground en route to gate).
Below there is a list of errors that can be displayed on the Operator Panel and a short description:	
Geometry failed - Geometry check failed within ID Fail limit	
Nose height failed - Nose height check failed	
Engine verification - Engine verification failed	
Profile failed - Profile check failed	
Lost track - Lost track close to stop	
Note : (option) Dockings can be resumed without verification; however it is important to follow the information below. Alternatively, the aircraft shall be marshalled-in or towed-in to the gate.	
WARNING! THE PILOT MUST NOT PROCEED BEYOND THE BRIDGE WITHOUT MANUAL GUIDANCE, UNLESS THE WAIT MESSAGE HAS BEEN SUPERSEDED BY THE CLOSING RATE BAR.	
Note : This may be a system event or a fault (to analyse the possible cause of the incident, see § 2.5.2 Event or Fault Diagnosis in this	



2.5.1 Override ID FAIL

The override function is designed to resolve an aircraft verification problem during an active docking procedure.



WARNING! THE OVERRIDE FUNCTION GIVES THE OPERATOR RESPONSIBILITY FOR AIRCRAFT VERIFICATION, AS A TEMPORARY SOLUTION TO AN EVENT/FAULT RECOGNISED BY THE SYSTEM.

When using the override function, these instructions must be followed:

- Make sure the stand area is clear of any obstructions such as vehicles, apron or other objects which may obstruct the aircraft, including wings or engines.
- Check for the correct stop-position (ground markings).

- Observe the aircraft docking.
- Make sure pilots approach at a cautious speed.
- Be prepared to push the "Emergency-Stop" button, if required or unsure. If the "Emergency-Stop" button is pushed, arrange for the aircraft to be marshalled-in or towed-in to the gate.
- After a docking is complete, always diagnose/resolve an **ID FAIL** message as soon as possible.

2.5.2 Event or Fault Diagnosis

The system requires time for safety checks, apron sweeps, aircraft capture and ID checks before the closing rate to stop-position appears on the Pilot Display.

Examples of events are:

- The aircraft was selected too late.
- An incorrect aircraft type was selected.
- An incorrect aircraft was on approach to the wrong gate.

• There was a temporary obstruction (such as a service vehicle).

Frequent events may also be due to configuration or hardware problems.

- Check log files as soon as possible after an **ID FAIL** to interpret the cause of the message.
- Resolve the cause of an **ID FAIL** message (event or fault) before future aircraft docking.

Diagnosis/resolution of an event/fault improves:

- operational efficiency (future docking procedures)
- safety (understand/avoid potential risks)
- maintenance (pro-active troubleshooting)

For more information, see:

- the Maintenance, Troubleshooting or Configuration sections
- the Safedock Manual
- <u>www.safegate.com</u> or contact support.
2.6 POWER FAILURE

Description				Posi	tion
In case of a power failure, the display will be completely black. A manual backup procedure must be used for docking guidance.				Aircraft stops a directed by Airp Authorities.	nd waits as port
Image Operator Papel	Image Pilot Display				
Operator Faher	T1-42	T2-18	T2S-24	Т3-9	T3-15

2.7 SYSTEM BREAKDOWN

Description				Posi	ition
In case of a severe syste for a red stop indicator (used for docking guidan	em failure, the di T2/3). A manual ce.	isplay will go blac backup procedur	Aircraft stops a directed by Airp Authorities.	ind waits as port	
Image Operator Papel	Image Pilot Display				
	T1-42	T2-18	T2S-24	Т3-9	T3-15
Communication failure					



2.8 EMERGENCY-STOP

Description				Pos	ition
When the Emergency-S the Pilot Display shows Note : Additional Emerge Operator Panel) may be	op button on the Operator Panel is activated, STOP (with red border/bars). ncy-STOP buttons (other than that on the connected to the system at the apron level.			Aircraft stops a directed by Air Authorities.	nd waits as port
Image Operator Papel	Image Pilot Display				
Operator Faher	T1-42	T2-18	T2S-24	Т3-9	T3-15
<aircraft type=""> <flight> EMERGENCY STOP</flight></aircraft>	(STOP)		STOP	STOP	STCP

2.9 SBU S	ГОР				
	Position				
Any unrecoverable error during the docking procedure generates a Safety Backup (SBU) condition. The display shows the text STOP . A manual backup procedure must be used for docking guidance.				Aircraft stops a directed by the	and waits as Pilot Display.
Below there is a list of errors that can be displayed on the Operator Panel and a short description:					
No scan reque	st - Geometry ch	neck failed within I	D Fail limit		
Scan failed - S	canning attempt	failed			
Scan too slow	- No scanning re	eply within reason	able time		
Positioning er	ror - Mirror positi	ioning error			
Scanner not re	r not ready - Scanner not ready				
Lost track - Lo	 k - Lost track close to stop 				
Too far from C	Too far from CI - Too far from centreline				
Image Image Image Pilot Displa				у	
operator raner	T1-42 T2-18 T2S-24			Т3-9	T3-15
<aircraft type=""> <flight> SBU STOP Scanner failed Shut down</flight></aircraft>	(STOP) SBU			STOP	STOP

2.10 GATE BLOCKED

Description				Pos	ition
If an object is found to b towards the aircraft, and reported as a blocking o WARNIN BEYOND GUIDAN	und to be blocking the view from the Safedock unit raft, and closer than the stop-position, this will be ocking object and the Pilot Display enters a WAIT state. VARNING! THE PILOT MUST NOT PROCEED EYOND THE BRIDGE WITHOUT MANUAL BUIDANCE, UNLESS THE WAIT MESSAGE HAS				nd waits as Pilot Display.
BEEN SU	JPERSEDED B	Y THE CLOSING	RATE BAR.		
Image Operator Papel	Image Image Pilot Displa			ıy	
	T1-42	T2-18	T2S-24	Т3-9	T3-15
<aircraft type=""> <flighb GATE BLOCKED Shut down</flighb </aircraft>					

2.11 VIEW BLOCKED

Description				Pos	ition
If the view towards the approaching aircraft is hindered, for example by dirt on the Pilot Display window (<2.5 m to the laser), the Safedock system reports a VIEW BLOCK condition. Once the system is able to see the aircraft through the dirt, the message is replaced with a closing rate display. WARNING! THE PILOT MUST NOT PROCEED BEYOND THE BRIDGE WITHOUT MANUAL GUIDANCE, UNLESS THE WAIT MESSAGE HAS BEEN SUPERSEDED BY THE CLOSING RATE BAR.				Aircraft stops a directed by the	nd waits as Pilot Display.
Image Operator Papel		Ima	y		
Operator Paner	T1-42	T2-18	T2S-24	Т3-9	T3-15
<aircraft type=""> <flight> VIEW BLOCKED Shut down</flight></aircraft>					

Page 23 of 30

2.12 CONFIGURATION ERROR

	Descriptio	on		Pos	ition
Any error related to syste operation generates and error in the Pilots Display will also light-up (general	em configuratior error message ir y. If it occurs du Ily an SBU-Stop	n that occurs durir in the Operator Pa iring docking, the in such cases).	Aircraft stops a directed by the (if the error occ docking).	nd waits as Pilot Display curs during	
Below there is a list of errors that can be displayed on the Operator Panel and a short description:					
Aircraft data - Failed to load aircraft data					
Centreline data	i - Nose height c	heck failed			
Centreline points - Failed to create aiming points along centreline					
Ground data -	Ground data - Failed to create ground level data				
 System integrit 	stem integrity - System integrity failure				
Apron scan dat	a - Failed to loa	d apron scan data			
 Walk-test requi 	red - Walk-test	required			
Clip too short -	Clip too short				
Image	Image Pilot Display				
Operator Panel	T1-42 T2-18 T2S-24			T3-9	T3-15
<aircraft type=""> <flight> ERROR TEXT Shut- down</flight></aircraft>					

2.13 REMOTE START OF DOCKING – FROM SUPERIOR SYSTEM (OPTION) Basic docking procedures are complemented with Superior System. All basic docking commands can be controlled remotely via Superior System or locally, if required.

2.13.1 Start of Docking with Interlocking Stands

	Descriptio	on	Position		
A docking procedure car interlocking adjacent sta will take place:	n be preceded by nds. If this option	y a check for one n is enabled, the f	or more ollowing steps		
(a) Any steps performed	d before the dock	king normally star	ts will be		
 (b) When the docking is about to start, the system will ask for confirmation from Superior System. If the system receives a confirmation the docking will start normally. The message Awaiting Confirm will be shown, when the request is sent to Superior System. 					
(c) If there are any inter halted, and the infor shown. This blockad	locking adjacent mation about the le cannot be ove	stands, the docki first interlocking rridden.	ng will be stand will be		
 (d) If Superior System is stands, the first two overridden by pressi 	s unable to verify stands will be sh ing the Accept k	/ the state of one nown. This blockad rev.	or more de can be		
 (e) If the system is unab a message is shown System confirmation 	ble to contact Su h. The docking ca h, by pressing the	perior System for an be initiated, wit e Accept key.			
Image		Ima	y		
Operator Panel	T1-42	T2-18	Т3-9	T3-15	
(b)					
(C) INTERLOCKED BY: <aircraft type=""> AT <stand> Shut down</stand></aircraft>					
(d)					
(e) Shut Accept					

2.13.2 Start of Docking with Activation

2.13.2.1 Preparing a Docking

Description	Position
A docking procedure is prepared by sending the aircraft information to Safedock, and to have the Safedock operator confirming that the stand is ready to accept an aircraft.	
 (a) If the Safedock operator confirms the stands readiness before the aircraft information is available: 	
 When the Safedock operator confirms the stands readiness by pressing the Open Stand key, the message Ready-Open will be displayed on the Operator Panel. Note: A system set in the Ready-Open state automatically returns to a Ready state after 30 minutes. 	
ii. When the scheduled flight information is made available from the Superior System the message Prepared will be displayed on the Operator Panel.	
iii. The system is now awaiting activation of the docking procedure. The only operation available to the local operator at this time is to abort the prepared flight. The activation command must come from the Superior System.	
 (b) If the aircraft information is made available from the Superior System before the Safedock operator confirms the stands readiness: 	
i. When the scheduled flight information is made available from the Superior System the message Scheduled will be displayed on the Operator Papel	
 ii. When the Safedock operator confirms the stands readiness by pressing the Open Gate key, the message Prepared will be displayed on the Operator Panel. If the Safedock operator presses the Start Dock key, the docking procedure will be started for the scheduled flight 	
 iii. The system is now awaiting activation of the docking procedure. The only operation available to the local operator at this time is to abort the prepared flight. The activation command must come from the Superior System. 	

SAFEDOCK® Manual Chapter: 3A Operating Procedures

Image		Image Pilot Display					
	Operator Panel	T1-42	T2-18	T2S-24	Т3-9	T3-15	
(a) (i)	SAFEDOCK SYSTEM READY-OPEN Shut Park Start down On Dock						
(a) (ii)	PREPARED <aircraft type=""> <flight> Shut down</flight></aircraft>						
(b) (i)	SCHEDULED <aircraft type=""> <flight> Shut Park Open Start down On Gate Dock</flight></aircraft>						
(b) (ii)	PREPARED: <aircraft type=""> <flight> Shut down</flight></aircraft>						

2.13.2.2 Docking Abort Command

Description				Posi	tion
 The Safedock operator may abort the scheduled/prepared docking, when the operator understands that the approaching aircraft is not according to the type assigned. (a) The Abort docking command is initiated by pressing the Shutdown key. (b) The message ABORTING will appear on the Operator Panel and STOP on the Pilot Display. (c) Now a new docking process can be started as described in § 1 Local Start of Docking – Regular Conditions (or § 2 Local Start of Docking – Abnormal Conditions, if applicable). 					
Image Operator Bapel		Ima	у		
	T1-42	T2-18	T2S-24	Т3-9	T3-15
 (a) <aircraft type=""> </aircraft> ACTIVE Shut down divide <	STOP				

2.14 REMOTE START OF DOCKING – FROM FIDS (OPTION)

Basic docking procedures are complemented with both Superior System and FIDS. All dockings can be managed and controlled based on information from FIDS as well as basic docking commands controlled remotely via Superior System or locally, if required.

Note: <Flight> indicated in the windows below, will be displayed at Safedock only if available from FIS, and if docking is not started locally.

2.14.1 The Schedule Command

	Description				ition		
 Normally scheduled flight database by FIS. At a trip database by FIS. At a trip be issued to Safedock s (a) When the Superior S flight, the Operator F (b) The operator now has process. (c) The docking of the pressing the Start F level password, (if compared to the pressing the start for the password, (if compared to the pressing the start for the password, (if compared to the pressing the start for the password). 	The prior to arrival a Scheduled command will system from Superior System. System has initiated docking for a scheduled Panel will display a SCHEDULED message. as two options: to abort or confirm the docking e scheduled flight is confirmed by the Marshal Dock key. This operation requires an operation- configured, option).						
(d) (Option) A correct p	assword will start a docking.						
Image	Image Image Pilot Displa				y		
Operator Paner	T1-42	T2-18	T2S-24	Т3-9	T3-15		
(a) SCHEDULED: <aircraft type=""> <flight> Shut Park Start down On Dock 6 7 8 9 0</flight></aircraft>							

2.14.2 Automatic Docking

Normally scheduled flights are inserted into the Superior System database by FIS. At a configured time prior to arrival, the docking procedure can be set to start automatically.



2.14.3 Docking Abort Command

Description				Posi	ition
 The Safedock operator may abort the scheduled/prepared docking, when he understands that the approaching aircraft is not according to the type assigned. (a) The Abort docking command is initiated by pressing the Shutdown key. (b) The message ABORTING will appear on the Operator Panel and STOP on the Pilot Display. (c) Now a new docking process can be started as described in § 1 Local Start of Docking – Regular Conditions (or § 2 Local Start of Docking – Abnormal Conditions, if applicable). 					
Image Operator Papel		Ima	age Pilot Displa	у	
Operator r aner	T1-42	T2-18	T2S-24	Т3-9	T3-15
(a) <pre></pre>					
C) READY Open Park Start Stand On Dock					

CHAPTER 3 OPERATION - APPENDIX B SAFEDOCK FEATURES (OPTIONS) CONTENTS

Section	Description Page N	lo.
1.	SAFEDOCK OPTIONS	3
2.	DATA ENTRY	4
2.1	PASSWORD ENTRY	4
2.1.1	Operator Password	4
2.2	SYSTEM ACCESS	4
2.3	THE "OPEN STAND" COMMAND	4
3.	PARK OFF SCAN	5
4.	DISPLAYED INFORMATION DURING AND AFTER DOCKING	6
4.1	DIGITAL CLOSING RATE (OPTION)	6
4.2	CHOCK ON (OPTION)	6
4.3	CHOCK OFF (OPTION)	6
4.4	STAND SIGN	6
4.5	PCA/GPU STATUS	6
5.	UNINTERRUPTABLE POWER SUPPLY	7
6.	CENTRELINE	8
6.1	MULTIPLE CENTRELINES	8
6.2	CURVED CENTRELINES	8
7.	AIRCRAFT SAFETY CHECK	9
7.1	EXTENDED ID FAIL LIMIT	9
8.	INTERACTION WITH EXTERNAL EQUIPMENT	10
8.1	DEAD MAN'S GRIP	10
8.2	STAND EQUIPMENT INTERLOCK	10
8.3	ALARM SIGNAL	10
8.4	DOCKING IN PROGRESS SIGNAL	10
8.5	PUSHBACK DATA TRANSMISSION	10
8.5.1	Manual Activation	11
8.5.2	Automatic Activation	11
9.	APRON SCAN	12
9.1	APRON SCAN OPERATION	12
9.1.1	Operation during Start-up	12
9.1.2	Operation during Capture	13
9.2	APRON SCAN SPECIFICATIONS	13
9.2.3	Scan area	13
9.2.4	Operational scan	15
9.2.5	Scan sequence	15
9.2.6	Detectable object size	15

Note: This page is blank for convenient double-sided printing.

1. SAFEDOCK OPTIONS

This Appendix is a summary of all optional operational features, available with the Safedock system. In sections describing a feature, it is usually stated that the Safedock system "is equipped" or "is configured" in a particular way. However, not all these statements may be relevant for a particular customer system. They are merely options and/or alternatives.

A Safedock system normally includes only the features that are specified for a particular customer's requirements. This appendix covers all features and options that <u>may</u> be delivered in a system, and is a subset of Chapter 3 OPERATION.

For more information, contact site or project management, Safegate or see <u>www.safegate.com</u>.

The features described are related to the following categories:

- (a) Data entry
- (b) Displayed information during docking
- (c) Centreline
- (d) Safety procedures
- (e) Interaction with optional or external equipment
- (f) Apron Scan (for T1 only).



2. DATA ENTRY

To control the Safedock system, the following options for manual data entry are available:

- (a) User passwords
- (b) System access
- (c) The 'Open Stand' command

2.1 PASSWORD ENTRY

The Safedock system can be equipped to use password protection for operations. How to create users and passwords is described in Chapter 4A Stand Configuration Utility.

Safedock system would require a four-digit password at the following commands:

- (a) Local Start-of-Docking (by assigning an aircraft type)
- (b) Local Park ON or Park OFF (creating Blocks On and Blocks Off transactions)
- (c) Confirmation of a Scheduled Flight Start-of-Docking Command from Superior System
- (d) Diagnostic Test Procedure (requires a maintenance operator password; will be described elsewhere)

Activities that do not require a password are:

- (a) Emergency Stop
- (b) Shutdown
- (c) Chocks On message to pilot

2.1.1 Operator Password

The system can be configured with operator level password protection. The Safedock system will then require all operator interactions except Shutdown and Emergency-Stop to be confirmed using a four-digit confirmation code. The confirmation codes are configurable per Safedock system. Password configuration is described in Chapter 4A Stand Configuration Utility.

2.2 SYSTEM ACCESS

The system can be configured to require activation of a hardware signal in order to allow local operation of the system. This hardware signal can for instance be generated by a key switch or a card-swipe access control system.

2.3 THE "OPEN STAND" COMMAND

The **Open Stand** command is issued by a local operator to acknowledge that the stand area is empty and ready to accept an aircraft. This command can be used to accept a scheduled docking, initiated by the Superior System, or to set the stand status to **Free-Open**, allowing remote start of a docking procedure from a Superior System. The **Open Stand** command can be assigned to a button on the Operator Panel or to an external button.

A system set in the **Ready-Open** state automatically returns to a **Ready** state after 30 minutes.

3. PARK OFF SCAN

Once every minute (unless changed by a connected Superior System) while in **PARKED** status the system will perform a Park OFF scan.

During the Park OFF scan, the system will try to match the profile for the currently parked aircraft with the aircraft in front of the system. If the system doesn't see any aircraft, it performs a Park OFF operation. Note that parking vehicles, such as a truck, might cause the system to consider the aircraft being still present.



4. DISPLAYED INFORMATION DURING AND AFTER DOCKING

Displayed information during the docking procedure is related to variants of the following functions:

- (a) Slow
- (b) Digital Closing Rate
- (c) Chocks On
- (d) Chocks Off
- (e) Stand Sign
- (f) PCA/GPU status

4.1 DIGITAL CLOSING RATE (OPTION)

The Safedock system can be equipped/ configured to display the distance remaining to the stop-position using a digital distance display.

The digital distance display is only active for the last part of the docking procedure. On a two-line text display, the aircraft type will be displayed on the top line and the distance to stop, on the bottom line. On a single-line display, the aircraft type will be replaced by the distance-to-stop information.

4.2 CHOCK ON (OPTION)

The Safedock system can be equipped/configured to use the display to give a **CHOCK ON** message to the pilot, when the chocks have been placed on the wheels.

The message can be activated either from the Operator Panel, or from an external switch mounted at apron level. The message will remain on the display for a configurable period of time (default: 2 minutes).

4.3 CHOCK OFF (OPTION)

The Safedock system can be equipped/configured to use the display to give a **CHOCK OFF** message to the pilot, when the chocks have been removed from the wheels.

The **CHOCK OFF** message uses the same activation method as the **CHOCK ON** message. The two messages will alternate on pressing the dedicated button. The duration of the message is as for the **CHOCK ON** message.

4.4 STAND SIGN

The display of the Safedock system can be utilised as a general-purpose Stand Sign display between docking procedures.

The information that can be displayed includes: *Stand ID*, *Current Time* and alternating *Time/Stand ID*.

4.5 PCA/GPU STATUS

The Safedock system can be equipped to present text messages on the Pilot Display in response to hardware signals. This can be used to give for instance information messages on connection/disconnection of PCA and GPU systems.

The messages will remain on the display for a configurable period of time.

5. UNINTERRUPTABLE POWER SUPPLY

The Safedock system can be equipped with an Uninterruptable Power Supply (UPS) unit. The purpose and capacity of UPS is to finish off initiated activities (only) during loss of main power.

The UPS is designed to keep the system running for at least 20 minutes without external power when fully charged.

When the system is running on UPS, the following conditions apply:

- Any docking operation in progress is allowed to continue to completion.
- An information message will be displayed Blocked by UPS
- No more docking operation can be activated until mains power is restored.
- After running on UPS while Safedock is idle is the default setting 5 min.



6. CENTRELINE

6.1 MULTIPLE CENTRELINES

The Safedock system is configured to use multiple centrelines. Up to three centrelines per system can be defined and used. The centrelines need not be parallel. The centreline to be used is determined individually per aircraft type. This configuration is described in Chapter 4A Stand Configuration Utility.

6.2 CURVED CENTRELINES

The Safedock system is configured to also use curved centrelines. Up to three centrelines per system can be defined and used. The centreline to be used is determined individually per aircraft type. This configuration is described in Chapter 4A Stand Configuration Utility.

7. AIRCRAFT SAFETY CHECK

The Safedock system includes the Aircraft Safety Check feature, which is a further enhancement of its safety performance. Aircraft geometry is analysed by means of a true 3D measuring technique, thus bringing safety risk to a minimum.

When a particular aircraft type has been assigned with the start-of-docking command, and another type of aircraft is approaching the stand in reality, there is a risk for a collision with fixed ground equipment, the Passenger Boarding Bridge or the terminal building. However, several mistakes should have been made before such an accident would occur:

- the correct type of aircraft has not been assigned by the operator
- the pilot has not discovered that an incorrect aircraft type is displayed on the docking system
- the incoming aircraft geometry differs from the assigned one in a negative and dangerous way

With the Aircraft Safety Check feature the approaching aircraft's geometry is analysed and compared to parameters of the aircraft type that was assigned with the start-ofdocking command.

If the aircraft geometry has not been verified within 15 metres from the stop-position, the Pilot Display will show **STOP/ID FAIL**.

As the requirements for permitting the aircraft to enter the stand are more restricted by a Safedock system using this feature, the **STOP/ID FAIL** message may be shown also if the aircraft is approaching diagonally or too fast.

7.1 EXTENDED ID FAIL LIMIT

Each aircraft can individually be configured to use an extended ID Fail limit of up to 25 metres to the stop-position. This option is described in more details in Chapter 4A Stand Configuration Utility § 4.7.1.



8. INTERACTION WITH EXTERNAL EQUIPMENT

The following operational features are available as options:

- (a) Dead Man's Grip
- (b) Bridge In Position
- (c) Alarm Signal
- (d) Docking in Progress Signal
- (e) Push-Back Data Transmission

8.1 DEAD MAN'S GRIP

The Safedock system can be equipped to use a 'dead man' grip function. This function forces the operator of the Safedock system to keep a switch depressed throughout the docking process, when the aircraft is present. If the 'dead man' switch is deactivated at any time during the docking procedure, and the aircraft is present, the docking will be aborted, displaying **ABORTING/DEADMANS GRIP RELEASED** on the Operator Panel and **STOP** on the Pilot Display, as if the operator had activated the "OFF" key.

Once the aircraft has reached the stop-position, the operator can release the 'dead man' switch without affecting the operation of the system. If the 'dead man' grip is released before the aircraft appears at the stand, Safedock will display **WAIT** until the 'dead man' grip is pressed again.

8.2 STAND EQUIPMENT INTERLOCK

The Safedock system can be configured to require confirmation from relevant stand equipment such as PBB, fuel pits etc. in order to prevent hazardous situations. If any equipment is found to be in the incorrect position, the message **Stand Equipment Interlock** will be displayed on the Operator Panel and a warning message on the Pilot Display. The confirmation can be enabled per aircraft type at the stand. The equipment interlock logic is configurable per aircraft type, allowing for any combination of bridge settings at a single stand.

8.3 ALARM SIGNAL

The Safedock system can be equipped with a potential free alarm output for connection to an external alarm system. The alarm output will be activated on any error detected by the Safedock system. Alternatively, a Superior System can be used to collect error messages from the Safedock systems and forward them to a central alarm handling system.

8.4 DOCKING IN PROGRESS SIGNAL

The Safedock Operator Panel is equipped with a potential free output used to indicate that a docking procedure is in progress. A "docking in progress" signal can be used by external systems when there's a need to know that a docking procedure is activated.

- (a) A light control system can use the "docking in progress" signal to automatically activate the lead-in lights at the stand when a docking procedure is activated.
- (b) The bridge control system can use the "docking in progress" signal to inhibit any outward movement of the bridge during a docking procedure.

8.5 PUSHBACK DATA TRANSMISSION

The Safedock system can be equipped with a feature to track an aircraft during the pushback procedure. The distance information gathered during pushback is forwarded

to a ground radar system (via Superior System), allowing the radar system to start tracking the aircraft, where it would normally be unable to track because of the radar shadow in the proximity of the terminal building.

8.5.1 Manual Activation

The bridge operator can start the pushback procedure manually by activating the **Park ON/OFF** button.

8.5.2 Automatic Activation

The bridge and GPU supply systems are connected to the Safedock system, allowing the Safedock system to automatically start the pushback procedure when it detects that the bridge is retracted and the GPU supply is disconnected.



9. APRON SCAN

The purpose of the apron scan functionality is to enhance normal Safedock T1 A-VDGS stand safety verification by scanning the stand area for unidentified or foreign objects. The function detects and locates objects before a docking is about to be initiated and an aircraft arrives at the stand. This automated functionality also minimizes the risk of human error by ensuring that the stand is clear from objects before opening it for a docking procedure.

Note: This function is applicable for T1 model only.

9.1 APRON SCAN OPERATION

The apron scan function is designed for two different phases of the docking: during start-up and capture.

9.1.1 Operation during Start-up

When the docking is initialized, the system performs a full and detailed scan of the specified scan area. The sequence starts at a distance away from the stand towards the taxiway. It then works its way in closer to the stop position. The current position of the scan appears in both the Pilot Display and Operator Panel.

Pilots Display	Operator Panel		
WAIT Scanning at 52m	A380 LH144 Scanning at 52 m Shut- down Acc- ept		

If any object is detected, the system locks on to it and continues to track it until it is removed or disappears. When the system locks on to an object, this is communicated to the ground crew and pilots in the Pilot Display and Operator Panel as in the figures below.

When the object is removed, the scan re-starts and continues until it manages to scan the apron without object detection. If an object detection occur during the apron scan, two different options become available for selection in the Operator Panel:

- Shut Down: press to shut down the docking.
- Accept: press to accept the existence of the detected object in the area and the scan aborts (an override) and the docking sequence starts without any further scan being performed.

Note: These functions are also available even if no object is detected so the scan can be aborted (accept object) to speed up the start of the docking.

WARNING! RESPONSIBILITY FOR USE OF THE ACCEPT FUNCTION MUST BE GIVEN BY AN AUTHORIZED PERSON.

Pilot Display example Image: Second sec

9.1.2 Operation during Capture

During capture mode, the system is waiting for the aircraft to arrive and it shows the **Welcome in** screen in the Pilot Display. During this period, the defined area will be scanned with a lower scanning rate, as the main focus now is to detect an incoming aircraft. If an object is detected, this is communicated in the same way as the initial scan.

Operator Panel example There are two different options available in the Operator Panel: • Shut Down: Press the softkey to shut down the docking. • Accept: Press the softkey to accept the detected object and abort the scan for the docking sequence to start without any further scan being performed.

9.2 APRON SCAN SPECIFICATIONS

9.2.3 Scan area

The areas where the apron scan functionality is available for use are defined as: the Primary scanning area and the Secondary scanning area.

During operation, the area being scanned corresponds the area from the nose position of the expected aircraft type when parked and further out. The boundaries from the stop position and further out, length and width are defined in the Safedock Maintenance Tool per configured centreline.

The minimum detection distance is twice the laser height. For example, for a laser installed at 6 meters above ground this will be equal to a minimum detection distance of 12 meters. Objects closer than the minimum detection distance cannot be detected. The primary scanning area is defined by the minimum detection point and the by maximum recommended stop position with +- 30° from Safedock center of view.



9.2.4 Operational scan

A scan is only done in the area between the configured nose stop-position for the selected aircraft type and the configured clip distance or 100 m, whichever is the shortest.

9.2.5 Scan sequence

A full scan is performed during the start-up of a docking.

A reduced scan is performed when the system is in capture mode, while waiting for the aircraft to arrive to the gate.

9.2.6 Detectable object size

Object size detection in primary area:

- Full scan during start-up, before Safedock goes to ACTIVE: 1.0 m x 1.0 m.
- Reduced scan during capture, before **TRACKING**: 1.0 m x 1.0 m.

Object size in secondary area:

- Full scan during start-up, before Safedock goes to ACTIVE: 1.5 m x 1.5 m.
- Reduced scan during capture, before **TRACKING**: 1.5 m x 1.5 m.

Note: This page is blank for convenient double-sided printing.

CHAPTER 4 MAINTENANCE CONTENTS

Section	Description	Page No.
1.	INTRODUCTION	5
1.1	SCOPE	5
2.	SAFEDOCK SET-UP	5
2.1	SET-UP PROCEDURES	5
3.	PLANNED MAINTENANCE	6
3.1	MAINTENANCE SCHEDULE	6
3.2	WEEKLY CHECK	6
3.2.1	Laser Unit Windows	6
3.3	MONTHLY CHECK	6
3.3.1	Display Unit Front Glass	6
3.4	SIX MONTHLY CHECK	7
3.4.1	Laser Scanning Unit Door	7
3.4.2	Laser Scanning Unit Mirrors	7
3.4.3	Operator Panel Emergency-Stop Buttons and Keys	7
3.4.4	Temperature Sensor	7
3.5	ANNUAL CHECK	7
3.5.1	Pilot Display/ Laser Unit	7
4.	CORRECTIVE MAINTENANCE	8
4.1	FAULT FINDING AND RECTIFICATION	8
4.2	TEST EQUIPMENT	8
4.3	DIAGNOSTIC TEST FUNCTIONS	8
4.3.1	Mirror Position Detector Test	9
4.3.2	Mirror Test	9
4.3.3	Laser Test	9
4.3.4	Scan Test	10
4.3.5	Display Test	10
4.3.6	Walk-Test	11
4.3.7	View Logs	12
4.3.8	Operator Panel Test	12
4.3.9	Light Sensor Test	12
4.3.10	Temperature Sensor Test	13
4.3.11	Comm info	13
4.3.12	Statistics	13
4.3.13	Cal Test	13
4.3.14	Set IP	14
4.3.15	Restart	14
4.4	OPERATOR PANEL SETUP AND TEST FUNCTIONS MENU	15
4.4.1	Operator Panel Contrast Intensity Adjustment	15
5.	TROUBLESHOOTING	16

5.1	FAULT EVALUATION	16
5.2	ERRORS AND WARNINGS	17
6.	REPLACEMENT OF MALFUNCTIONING UNITS	22
6.1	RENEWAL OF STEPPER MOTOR	25
6.1.1	Motor Disassembly	25
6.1.2	Inspection	26
6.1.3	Assembly	27
6.1.4	Testing	27
6.2	RENEWAL OF CALIBRATION MIRROR	28
6.2.1	Mirror Disassembly	28
6.2.2	Inspection	29
6.2.3	Assembly	29
6.2.4	Testing	29
6.3	RENEWAL OF SCANNING MIRROR	30
6.3.1	Mirror Disassembly	30
6.3.2	Inspection	31
6.3.3	Assembly	31
6.3.4	Testing	31
6.4	RENEWAL OF LASER RANGE FINDER	32
6.4.1	Range Finder Disassembly	32
6.4.2	Inspection	33
6.4.3	Assembly	33
6.4.4	Testing	33
6.4.5	Reset Laser Statistics	33
6.4.6	Scan Test	34
6.5	RENEWAL OF CONTROL UNIT	34
6.5.1	Preparations before Maintenance	34
6.5.2	Dumping Stand Set-Up Parameters from the Control Unit	34
6.5.3	Control Unit Disassembly	35
6.6	RENEWAL OF POWER SUPPLY	41
6.6.1	Power Supply Disassembly	41
6.7	RENEWAL OF STEPPER MOTOR DRIVERS	43
6.7.1	Stepper Motor Driver Disassembly	43
6.7.2	Assembly	44
6.7.3	Testing	44
6.8	RENEWAL OF LED MODULE	45
6.8.1	LED Module Disassembly	45
6.8.2	Inspection	45
6.8.3	Assembly	45
6.8.4	Testing	45
6.9	RENEWAL OF OPERATOR PANEL FILM (SOFTKEY)	
6.10	RENEWAL OF SURGE ARRESTORS	
6.11	RENEWAL OF DISPLAY FAN AND/OR FILTER (T1 ONLY)	
7.	SUPPORT	
7.1	SAFEGATE WEBSITE	

SAFEDOCK® Manual Chapter: 4 MAINTENANCE

RE-CYCLING	51
Local Authority Re-cycling	51
Safegate Re-cycling	51
Packaging	51
SPARE PARTS	
E	RE-CYCLING Local Authority Re-cycling Safegate Re-cycling Packaging SPARE PARTS



Note: This page is blank for convenient double-sided printing.

1. INTRODUCTION

1.1 SCOPE

This document is a description of the maintenance of an individual Safedock system, being a part of the parking system at an airport. In this perspective the main tool for stand set-up and Safedock configuration is a laptop computer, which can be connected to each docking system at the apron.

The description includes:

- (a) Safedock set-up
- (b) Planned maintenance
- (c) Corrective maintenance
- (d) Troubleshooting
- (e) Replacement of malfunctioning units

When Safedock units are integrated with a Superior System, any Maintenance Workstation on the LAN can be used as a configuration tool.

2. SAFEDOCK SET-UP

The Safedock system has to be set up and configured at mainly the following events:

- (a) After initial installation at a stand (configuration and calibration)
- (b) After certain corrective activities/ maintenance (recalibration)
- (c) After the system by some reason has been forced out of its position (recalibration)
- (d) When a centreline is changed or added (calibration)
- (e) When a new aircraft type is added (configuration)
- (f) When a stop-position is changed (configuration)

2.1 SET-UP PROCEDURES

The Safedock system is set up by the following procedures:

- (a) Defining centrelines
- (b) Verifying a centreline definition
- (c) Setting calibration check points
- (d) Configuration (setting aircraft types and their stop-positions and so on)
- (e) Removing echoes from fixed object
- (f) Storing stand configuration files
- (g) Set-up validation, the Walk-Test

For carrying out these procedures, please refer to Chapter 4A Stand Configuration Utility.



3. PLANNED MAINTENANCE

The Safedock system has been specifically designed to minimise maintenance downtime. The following maintenance schedules detail the maintenance requirements on a weekly, monthly, six monthly and twelve monthly basis. The system does not require any further scheduled maintenance, as proving operations are always done automatically prior to any start-of-docking procedure.

Before commencing maintenance the following precautions must be considered:

CAUTION: PROTECTION AGAINST ELECTROSTATIC DISCHARGE

The transfer of static electricity causes electrostatic discharge (ESD) damage when electronic components are handled. It's essential to protect components from electrostatic discharge to avoid damage and extra costs in connections with service and production. Therefore:

- (a) All ESD- sensitive materials must be stored in ESD- safe area.
- (b) All ESD- sensitive components must be stored in protective packages.
- (c) Apply a conductive band around your wrist and connect it to ground before touching any electronic component.

WARNING! ISOLATE THE POWER SUPPLY PRIOR TO UNDERTAKING ANY MAINTENANCE ACTIVITY!

IF A BATTERY BACKUP IS INSTALLED, ALSO THE 24-VOLT DC CURRENT TO THE ELECTRONICS HAS TO BE SWITCHED OFF!

3.1 MAINTENANCE SCHEDULE

Planned or preventive maintenance per time interval is carried out according to the maintenance task lists below. Time intervals are:

- (a) Per week
- (b) Per month
- (c) Per six months
- (d) Per year

3.2 WEEKLY CHECK

3.2.1 Laser Unit Windows

- (a) Inspect the Laser Scanning unit cabinet front/side windows and Operator Panel for cleanliness.
- (b) Clean as required with mild soap and water and a soft rag.

3.3 MONTHLY CHECK

- 3.3.1 Display Unit Front Glass
 - (a) Inspect the Pilot Display unit front glass cover and Operator Panel for cleanliness.
 - (b) Clean as required with mild soap and water and a soft rag.

- 3.4 SIX MONTHLY CHECK
- 3.4.1 Laser Scanning Unit Door
 - (a) Examine the Laser Scanning unit door seal for signs of perishing and security of attachment.
 - (b) Renew carefully the seal if required. Use a sharp knife and clean with alcohol after removal. Adapt a new rubber gasket, closed cell type (EPDM-SBR), size 15 x 5 mm, available from Safegate.
- 3.4.2 Laser Scanning Unit Mirrors
 - (a) Examine the Laser Scanning unit calibration and scanning mirrors for signs of dust, or damage.
 - (b) Renew mirror if required.
 - (c) Clean the laser lenses and mirrors with a camera lens cleaning wipe and alcohol.
- 3.4.3 Operator Panel Emergency-Stop Buttons and Keys
 - (a) Check the correct function of all Emergency-Stop buttons. Ensure that the Pilot Display indicates **STOP** when the Emergency-Stop button is pressed.
 - (b) For stands with multiple Emergency-Stop buttons, the above test shall be performed individually for each button.
 - (c) For adjacent system that share common Emergency-Stop buttons, ensure that both systems Pilots Displays indicates **STOP** when the Emergency-Stop button is pressed.
 - (d) Check there are no visible signs of wear on the Operator Panel cover (film) and check all keys react with a normal press. For example, press all keys: softkeys (option/function), scroll left/right, CANCEL and ENTER.
 Note: Press the Back softkey before confirming any option/function selection.
- 3.4.4 Temperature Sensor
 - Check the function of the Temperature Sensor, using the Operator Panel **Test** utility.

3.5 ANNUAL CHECK

- 3.5.1 Pilot Display/ Laser Unit
 - (a) Vacuum clean the inside of the Pilot Display unit.
 - (b) Check fans in the system to make sure they are running properly. Every five year the fans shall be exchanged. Refer to purchase information below.
 - (c) For T1 only. Change the filters at the air in- and outlets for the display ventilation. Note: the local environments and level of dust may require more or less frequent exchange intervals of these filters.
 - (d) If the system is equipped with a Battery Backup unit, the batteries must be exchanged every five year. Contact Safegate or see the Spare Parts list.

4. CORRECTIVE MAINTENANCE

The Safedock system has a built-in diagnostic test program that is activated prior to any start-of-docking command. Errors are reported with a code, identifying the kind of fault. Corrective maintenance of the Safedock system is carried out on the basis of these reports.

4.1 FAULT FINDING AND RECTIFICATION

Possible causes of each error and the recommended actions to be taken are presented in § Troubleshooting in this Chapter.

During rectification the procedures described in § 6 Replacement of Malfunctioning Units shall be followed.

4.2 TEST EQUIPMENT

The test equipment used for the set-up of the Safedock system is the Server of the Safedock Central Computer System, provided that the connection to Superior System is established. The software SMT.EXE shall be used for this purpose.

An alternative is to use any laptop computer, which shall be connected to the service outlet of the Operator Panel. Note that the service outlet is an RS-485 port, which means that an interface converter must be used, when connecting to the RS-232 COM port of the laptop computer.

Optionally, a laptop computer can also be connected to a 10BaseT/RJ-45 outlet in the Pilot Display unit. This option also gives the computer access to the Central Configuration Database.

4.3 DIAGNOSTIC TEST FUNCTIONS

The Safedock is equipped with a set of test/ diagnostics functions. To access these functions from the Operator Panel main menu, select **Test** key, enter a password (if configured) and press ENTER. A menu containing all available test functions will then be presented.

Pressing the softkey associated with the desired test function activates the test function. The arrow keys can be used to switch between menu pages. Pressing the **CANCEL** key will bring the system back to normal operation.



The available test and set-up functions are according to the following sections.

4.3.1 Mirror Position Detector Test

This function is used to test the Stepper Motor Driver circuit. If it is functioning properly and the mirrors are in correct position, **OK** will be displayed. Otherwise **FAIL** will be displayed.

Walk Test	View Logs	OP Test	Light Sens	Temp Sens		
Program version						
SOS 1.0.0						
P: OK						
Mirr	Mirr	Laser	Scan	Disp		
Pos	Test	Test	Test	Test		

FIGURE 4.2 – MIRROR POSITION DETECTOR TEST

4.3.2 Mirror Test This function is used to test the home positions for the mirrors.

Both mirrors will be sent to their home positions and a message will display the result.

Walk	View	OP	Light	Temp	
Test	Logs	Test	Sens	Sens	
Program version					
SOS 1.0.0					
M: Hor OK Ver OK					
Mirr	Mirr	Laser	Scan	Disp	
Pos	Test	Test	Test	Test	

FIGURE 4.3 – MIRROR TEST

4.3.3 Laser Test

This function is used to test for range data from the LRF and mirror motion detection. A laser scan operation will be performed using each of the mirrors and a message will display the result.



4.3.4 Scan Test

This function is used to test the entire scanner subsystem with mirrors, LRF and monitoring functions.

A full scan operation will be performed using each of the mirrors and a message will display the result including monitor time indicators for each mirror.

Walk Test	View Logs	OP Test	Light Sens	Temp Sens	
Program version					
SOS 1.0.0					
S: OK H nn V mm					
Mirr Pos	Mirr Test	Laser Test	Scan Test	Disp Test	

FIGURE 4.5 – SCAN TEST

The time indicators for the mirrors, nn and mm, shall be in the range 100 – 600.

4.3.5 Display Test

There are three available tests for the Pilot display: Board test, Address test and Line test.



FIGURE 4.6 – DISPLAY TEST

(a) Board Test

This is an automatic test. Each LED board of the Pilot Display will be tested one by one, and the result will be displayed at the Operator Panel. If any LED board is found to be faulty, it will be displayed as a major or minor (individual LEDs) error with its id 'RC' where R is row number and C is column number:

			Back
BOARD	TEST		
FAILED)		
Major:	11 34		
Board	Addr	Line	
Test	Test	Test	

FIGURE 4.7 – BOARD TEST

(b) Addr Test

In address test, a unique character is displayed on each of the display boards, starting with 'A' at the top left and continuing in sequence left-to-right and top-to-bottom.

Thus the addressing of the boards can be checked:


(c) Line Test

The line test is used to light up all the LED's on the display boards, one line at a time. This allows for visual inspection of the individual LED's.

				Back
LINE TEST				
Line: 1 Color: 1				
	_			
Prev	Next			
lino	Line			

Use the Prev Line and Next Line keys to step through the lines of the display.

4.3.6 Walk-Test

Walk-test is a system wide test function that exercises all the major features of the Safedock system. It is used to verify the operation of the system, and shall be performed whenever a modification to the system has been made.

In walk-test, an entire docking procedure is performed, docking a person walking in along the centreline in place of an aircraft. When walk-test is activated, a stop-position must be chosen by selecting one of the configured aircraft types. The stop-position for walk-test will be the nose wheel position for the selected aircraft type. In this way, walk-test can be used both to verify the operation of the system, and the configured stop-positions for each aircraft type.

The procedure for performing a walk-test is:

(a) Enter system TEST functions and select WALK TEST.

If the configuration has been updated for individual aircraft types, the system will suggest an aircraft type to be tested. Walk-test for the suggested aircraft type can be started by pressing the **ENTER** button.



FIGURE 4.10 - WALK TEST

At every entrance to the walk-test function the system will continue to suggest aircraft types until all updated aircraft types have been tested successfully.

- The test of any aircraft type's stop-position can be done as described below:(b) Select an aircraft type using the aircraft selection menu. The selected aircraft type
- will determine the stop-position for walk-test.(c) Walk to the start position for 'walk-test', which should be at least 20 metres from the stop-position along the centreline.

- (d) Walk toward the system, following the centreline. The system will activate azimuth guidance and closing rate display, as soon as the person is seen by the system.
- (e) Follow the guidance information provided by the system, verifying that it closely matches the centreline.
- (f) When **STOP** is given, verify that the stop-position matches the desired stopposition (nose wheel position) for the selected aircraft type.
- (g) After a successful walk-test the system will automatically terminate the test functions and return to normal operation without further user input.

Note: No **SLOW** or **TOO FAR** messages are available during walk-test. As walk-test is looking for a person, a much smaller object than an aircraft, it cannot reliably be used in adverse weather conditions such as rain or snow.

4.3.7 View Logs

This function is used to display data about the latest docking procedures.

Data from the latest docking procedures are stored on non-volatile memory, and are available for later review.

 The date/ time and aircraft, for the latest logged docking will be displayed as below:



Date/time for the docking Aircraft type

FIGURE 4.11 - NAVIGATE AMONG STORED LOGS

The **Prev** and **Next** keys can be used to navigate among the stored logs. The **Down** key displays the next line of the log sequence while the **Rewind** key is used to restart the sequence from the beginning. The **Back** key can be used to get back to the test function menu.



FIGURE 4.12 – DOCKING EVENT

- Use the **Down** key to go through the events that have been saved for this docking. Data saved are: aircraft type, date/time, error during docking, speed at the last slow message, capture distance, ID-verified distance, stop distance, and roll after stop.
- The **Rewind** key will provide a jump back to the beginning of the selected docking.
- By pressing the **CANCEL** button, the test is aborted.
- 4.3.8 Operator Panel Test

Test of the inputs on the Operator Panel(s) can be performed. The statuses of the 16 digital inputs of the selected operator are displayed as 1 or 0. Use the **Prev Panel** and **Next Panel** keys to select which panels input should be displayed.

4.3.9 Light Sensor Test

This test function is used to check the function of the light sensor that controls the intensity of the Safedock display.



'kk' is the light intensity measured, and 'nn' is the control parameter used. (3 < nn < 99; 0 < kk < 60000).

FIGURE 4.13 - LIGHT SENSOR TEST

4.3.10 **Temperature Sensor Test**

> This test function is used to check the temperature of the display unit (D) and the scanner unit (L). The display shows the measured temperature, according to the format below:



'nn' is the temperature, in degrees Celsius.

FIGURE 4.14 - TEMPERATURE

4.3.11 Comm info

This test indicates the status of the communication with the superior system.



FIGURE 4.15 - COMM INFO

4.3.12 **Statistics**

This function displays some basic statistics about the system operation.



FIGURE 4.16 - STATISTICS

The keys Laser Time, Total Dock, Ok Dock and ID Fails switch between the different statistics.

The function Reset Laser is used to reset the running time counter for the laser unit. This time should be reset whenever the laser unit is replaced in the system.

4.3.13 **Cal Test**

This key will activate the system calibration procedure and report the result.

Walk	View	OP	Light	Temp	
Test	Logs	Test	Sens	Sens	
Program version					
SOS 1.0.0					
AutoCal: OK					
Mirr	Mirr	Laser	Scan	Disp	
Pos	Test	Test	Test	Test	

FIGURE 4.17 - CAL TEST

4.3.14 Set IP

The Set IP function is used to inspect and modify the network settings for the system.



Press the Set xxx key to modify the IP-address, network mask and Gateway address respectively.



FIGURE 4.19 – IP ADDRESS SETTING

Enter new digits for the setting. The input position is marked by an input cursor, \land . Move the input cursor with the \leftarrow and \rightarrow keys. Confirm the new setting by pressing **ENTER**.

Activate the modified setting for the system by pressing the **Apply** key. The system will restart using the new settings.

4.3.15 Restart

The restart function can be used to restart the Safedock system.



Press **Accept** to confirm the restart operation, press **CANCEL** or **Back** to resume normal operation.

4.4

4.4.1

OPERATOR PANEL SETUP AND TEST FUNCTIONS MENU

The Operator Panel includes a setup and test functions menu for adjusting settings in the Operator Panel.

The menu is accessed as the unit or system is powered on by simultaneously pressing and holding the Operator Panel **Cancel** button until the menu appears.

 The Operator Panel is restarted in the unit as follows: (a) Open the Operator Panel front panel. (b) Remove the J1 connector. (c) Press and hold the CANCEL button. (d) Insert the J1 connector. Alternatively, the Safedock system including Operator Panel can be powered off/on using the main switch in the display unit. This would require two people, one to turn off/on the display unit and one to press and hold the Operator Panel unit. 	FIGURE 4.21 – OP J1 CONNECTOR
(e) Release the CANCEL button when the firmware version and the two soft key menus appear.	Version <number> Setup Test func FIGURE 4.22 – OP SETUP/TEST FUNCTIONS</number>
Operator Panel Contrast Intensity Adjust	tment
 (a) Restart the Operator Panel to access the setup and test functions menu. (b) Release the CANCEL button when the firmware version and two soft key menus appear. (c) Press Setup func key. 	Version <number> Setup Test func FIGURE 4.23 – OP SETUP/TEST FUNCTIONS</number>
(d) Press the LCD contr key.	LCD Com1 Com2 Key Defit Contr Addr Addr form Defit FIGURE 4.24 – OP LCD CONTRAST
 (e) Adjust the contrast using the + or - buttons (upper right). (f) Press CANCEL button (twice) to exit. 	ELCLIPE 4.25 OD LOD CONTRACT SETTING
 (g) Press YES key to save changes. (h) Press ENTER button to exit the setting menu and return to normal operation. 	FIGURE 4.25 - OP LOD CONTRAST SETTING

5. TROUBLESHOOTING

All Safedock systems complete a factory acceptance test (FAT) before shipping; however some error messages may appear during configuration and commissioning due to unforeseen reasons.

If a malfunction occurs within a Safedock system, error numbers appear on the Pilot Display and their equivalent error messages appear on the Operator Panel display. Some error messages may appear in abbreviated form on the Pilot Display, depending on the Safedock type and/or size of Pilot Display installed at the stand. Faults can be diagnosed and rectified from error messages.

5.1 FAULT EVALUATION

It is important to evaluate an error in a logical order, for example:

- 1. **An airport operations event** see Chapter 3 OPERATION or Chapter 4 MAINTENANCE.
- 2. **Routine maintenance** see Planned or Corrective Maintenance sections in this Chapter.
- 3. **Cabling fault** see Chapter 2 INSTALLATION or Chapter 5 DRAWINGS.
- 4. **A configuration problem** see Chapter 2 INSTALLATION.
- 5. **Component fault** see Errors and Warnings and Replacement sections in this Chapter.
- 6. **Support** see Support information in this Chapter.

Note: Some error messages appear for 10 seconds and then disappear from the display. The operator may then attempt a new or continue a docking procedure. The error is saved in the event log.

5.2 ERRORS AND WARNINGS PD – OP messages, symptom Possible cause Action to rectify ERROR - Failed to load aircraft data Aircraft data missing in Add the aircraft to the The requested aircraft data could not be loaded. configuration or configuration or adjust unknown configuration the configuration of the id sent from superior superior system. system. ERROR - Centerline data Corrupted centreline Contact Safegate Failed to load centerline data defined. Support. **ERROR – Centerline points** Define centreline Failed to load centreline points. No centreline points defined. points. ERROR - Ground data Perform a system The system has not The calibration does not contain a valid ground been calibrated. data profile. calibration. **ERROR - System integrity** One or more parts the system configuration Configuration not Complete the and/or hardware is inoperable. Refer to log files complete. configurationfor details. Temperature out of Make sure the system allowed range. has adequate/functioning cooling/heating. **ERROR - Apron scan data** Apron scan data is invalid. Configuration not Complete the complete. configuration.

PD – OP messages, symptom	Possible cause	Action to rectify
ERROR - Clip too short		
The clip distance is set to a distance that is shorter than the current stop position plus ID-fail limit.	Badly configured system.	Correct the configuration.
ERROR - Prepare timeout		
Stand equipment interlock signalling not functioning.	Internal error	Contact Safegate Support.
STOP / ID / FAIL – ID FAIL		
The docking has been halted due to aircraft identification failure. The operator panel may show one of the following additional reasons for the error:	Incorrect aircraft type selected on the docking system.	Press 'OFF' to abort the docking and select the correct aircraft type to initiate a new docking procedure.
 Geometry failed: The approaching aircraft does not the expected geometry. Nose height failed: Measured nose height outside allowed limits. 	The laser scanning unit field of view is impaired.	Clean the mirrors and windows of the scanning unit.
 Engine verification: Verification of engine position failed. Profile failed: Horizontal/vertical profile matching failed. Lost Track: Lost aircraft inside ID-fail distance, but outside two meters from the stop position. 	The laser scanning unit field of view is blocked by an object.	Move the object out of view (the docking area at the stand).

PD – OP messages, symptom	Possible cause	Action to rectify
STOP / SBU – SBU STOP		
 Safety Backup behaviour. Common error message for issues that may require human intervention or restarted docking procedure after visual inspection of the stand area. The operator panel may show one of the following additional reasons for the error: No scan request: Scanner subsystem has not received a scan order within the required timeframe. Scan failed: The scanner subsystem was unable to perform a scan. Scan too slow: The scanner subsystem did not deliver a scan within the required timeframe. Positioning error: The scanner subsystem did not deliver a scan within the required timeframe. Scanner not ready: The scanner subsystem could not bring the mirrors to their respective home position. Scanner not ready: The scanner subsystem could not active the LRF inside the required timeframe. Lost Track: Lost aircraft within two meters from the stop position. Too far from CI: The aircraft is more than 5dm offset from the centreline at a distance of 2m from stop position. 		
STOP - AUTOCAL FAILED		
Auto calibration failed.	No auto calibration configured	Configure auto calibration.
	Object obstructing the view to the calibration plate.	Remove the object.
ERROR - EM-STOP CIRCUIT		
The emergency stop circuit test has failed when starting a docking procedure. The system prevents a docking procedure from starting	The emergency stop circuit is shorted to ground.	Check the emergency stop circuit.
starting.	The Control Unit is malfunctioning.	Replace the Control Unit.

PD – OP messages, symptom	Possible cause	Action to rectify		
WAIT – Stand equipment interlock	-			
The bridge or other stand equipment is not in a safe position and may obstruct the aircraft approach.	Incorrect Passenger Boarding Bridge position for aircraft type. PBB is not fully retracted. Pits are open.	Correct the passenger boarding bridge position. Close pits.		
WAIT > GATE > BLOCK – GATE BLOCKED				
The normal view of the Laser Scanning Unit is impaired by an obstruction in the aircraft docking area. The docking procedure re-commences automatically as soon as the obstruction is cleared from the docking area. Note: The Pilot Display cycles the messages WAIT , GATE and BLOCK until the docking area is cleared or the docking is aborted.	The docking area is obstructed.	Clear the docking area.		
WAIT > VIEW > BLOCK – VIEW BLOCKED				
The system is unable to see through the forward window. The docking procedure will abort. Note : The Pilot Display cycles the messages WAIT , VIEW , BLOCK .	Dirty window/mirrors.	Clean the window/mirrors.		
	obstructed by a reflecting or low- visibility object.	obstruction. For more information, see Chapter 4A Stand Configuration Utility.		
	The Laser Range Finder is malfunctioning.	Replace the Laser Range Finder.		
WAIT > APRON > BLOCK – APRON BLOCKED				
An enhanced view of the Laser Scanning Unit is impaired by an obstruction in the docking (apron scan) area. The docking procedure re-commences automatically as soon as the obstruction is cleared from the docking area. Note : The Pilot Display cycles the messages WAIT , APRON and BLOCK until the apron area is cleared or the docking is aborted.	Note: This error is only possible, if the optional function APRON SCAN is installed. The docking (apron area) is obstructed.	Clear the docking (apron) area.		

PD – OP messages, symptom	Possible cause	Action to rectify		
ERROR - WALKTEST REQUIRED				
A walk-test is required by the system.	The configuration for the stand has been modified since the last walk-test procedure was performed.	Perform a walk-test procedure to verify the current configuration at the stand.		
FAIL- Pri Surge FAIL				
The build in monitoring function over the surge arrestors on the primary side is indicating a fail. Note : This FAIL does not impede the operational capacity of the VDGS, it simply makes the operator aware of the status and that it is highly recommended to take a look into the arrestors by the maintenance team.	The arrestor is consumed due to a voltage peak from the source of incoming power.	Check on the arrestors and change the plug in module when consumed		
FAIL- Sec Surge FAIL				
The build in monitoring function over the surge arrestors on the secondary side is indicating a fail. Note : This FAIL does not impede the operational capacity of the VDGS, it simply makes the operator aware of the status and that it is highly recommended to take a look into the arrestors by the maintenance team.	The arrestor is consumed due to a voltage peak.	Check on the arrestors and change the plug in module when consumed		
FAIL- Display Vent FAIL (T1 only)	-	_		
The build in monitoring function over the display ventilation fan(s) is indicating a fail. Note : This FAIL does not impede the operational capacity of the VDGS, it simply makes the operator aware of the status and that it is highly recommended to take a look into the display fan assembly by the maintenance team.	The fan(s) does not operate when it it is supposed to.	Check the functionality of the fan in relation to the temperature. Note: The switching point of an active fan is default set to 40 degrees but subject to individual adjustments.		



6.

REPLACEMENT OF MALFUNCTIONING UNITS

This chapter describes the disassembly, inspection and the assembly of Safedock units. The following figures show the different types of Safedock units.

WARNING: TO PREVENT ELECTRIC SHOCK, ISOLATE THE POWER SUPPLY PRIOR TO UNDERTAKING ANY MAINTENANCE WORK WITHIN THE UNIT. IF A BATTERY BACKUP IS INSTALLED, ALSO THE 24-VOLT DC CURRENT TO THE ELECTRONICS HAS TO BE SWITCHED OFF!



FIGURE 4.28 - OVERVIEW SAFEDOCK UNIT TYPE 1 OPEN









FIGURE 4.30 - OVERVIEW SAFEDOCK UNIT TYPE 3

SAFEDOCK® Manual Chapter: 4 MAINTENANCE

6.1 RENEWAL OF STEPPER MOTOR

6.1.1 Motor Disassembly

The figure below illustrates the positions of the two stepper motors of the Laser Scanning Unit.



FIGURE 4.31 – SAFEDOCK T1 STEPPER MOTORS OF LASER SCANNING UNIT



FIGURE 4.32 – SAFEDOCK T 2/3 STEPPER MOTORS OF LASER SCANNING UNIT



Page 25 of 52

- (a) Switch OFF the main power switch.
- (b) To gain entry to the Laser Scanning Unit, undo the cabinet lock and open the hinged door.
- (c) Turn off the power in the system
- (d) Loosen the two 3-mm socket head screws, on the axle adapter, which secures the scanning mirror (smaller) to the motor drive shaft (stem).
- (e) Carefully withdraw the scanning mirror, complete with axle adapter, from the motor drive shaft. Place the scanning mirror in a suitable place to avoid damage.
- (f) Loose the four 4-mm socket head screws, which secure the stepper motor to the motor bracket.
- (g) Carefully remove the stepper motor from the bracket.
- (h) Disconnect the stepper motor electrical leads (13 cables) at the terminal block (strip) situated in the laser unit cabinet. Disconnect the cable connector to the motor position sensor located on the back of the stepper motor.

6.1.2 Inspection

- (a) Inspect the scanning mirror assembly for signs of damage. Renew if required.
- (b) Inspect the Laser Range Finder lenses for cleanliness. Clean as required.
- (c) Inspect the two scanning mirrors, and the calibration mirror, for cleanliness. Clean as required.
- (d) Inspect the Laser Scanning Unit cabinet, front and side windows for cleanliness. Clean as required.
- (e) Ensure the Laser Scanning Unit cabinet is free of all extraneous material.

Note: The items covered in step b to d inclusive must be free of grease, dirt and moisture. Only anti-static cleaning materials should be used.

The cables from the stepper motor are colour coded for connection. The checklist in the table below can be used as a guideline:

Stepper motor wiring, numbering and colour codes						
Cable No.	Terminal No. Strip 1	on connector: Strip 2	Cable colour codes	Check ✓ for correct connection		
Cables from the Stepper Motor						
1	59	72	BROWN			
2	60	73	BROWN/WHITE			
3	61	74	RED			
4	62	75	RED/WHITE			
5	63	76	ORANGE			
6	64	77	ORANGE/WHITE			
7	65	78	YELLOW			
8	66	79	YELLOW/WHITE			
Cables f	rom the Black	Box behind the	Stepper Motor			
9	67	80	BROWN			
10	68	81	YELLOW			
11	69	82	GREEN			
12	70	83	GREY			
13	71	84	WHITE			

6.1.3 Assembly

- (a) Connect the stepper motor electrical connections to the terminal block (make sure to follow the colour codes).
- (b) Connect the connector to the motor position sensor.
- (c) Fit the new stepper motor to the bracket and secure in position with the four socket head screws.
- (d) Switch on mains/system power, observe the stem on the stepper motor. It rotates for a few seconds and stop. Once the stem stops rotating, turn mains/system power off again.
- (e) Install the mirror on the stem of the motor, such that the clear side of the mirror faces the laser unit. The mirror shall be installed at an angle of 45 degrees not necessarily aligning the mounting screws with the bevel on the stem.
- (f) Secure the axle adapter to the motor drive shaft, by tightening the two socket head cap screws.
- (g) Close the cabinet door and secure using the lock.
- (h) Switch ON the mains/system power.

The system must be set up again: defining and verifying the centrelines, setting calibration check points and making a new backup of the Stand configuration file. Please refer to Chapter 4A Stand Configuration Utility.

6.1.4 Testing

- (a) Verify the centreline definition according to Chapter 4A Stand Configuration Utility.
- (b) If the centreline definition points are not correct, the system must be set up again. This means: defining and verifying the centrelines, setting calibration check points and making a new backup of the Stand configuration file. Please refer to Chapter 4A Stand Configuration Utility.
- (c) Perform a Walk Test procedure.



6.2 RENEWAL OF CALIBRATION MIRROR

6.2.1 Mirror Disassembly

The calibration mirror is mounted on a bracket, situated above the laser range finding unit, see the figure below.



FIGURE 4.33 – SAFEDOCK T1 CALIBRATION MIRROR



FIGURE 4.34 – SAFEDOCK T2/3 CALIBRATION MIRROR

- (a) Switch power OFF and isolate the power supply unit.
- (b) To gain entry to the Laser Scanning Unit, undo the cabinet lock, and open the hinged door.
- (c) Loosen the four 5-mm socket head screws, which secure the calibration mirror bracket.
- (d) Remove the bracket from the Laser Scanning Unit.
- (e) Carefully remove the calibration mirror from the bracket using a sharp knife or chisel. If needed, heat the backside to dissolve the tape on the back of the mirror.
- (f) Remove the remaining tape from the bracket.

Note: If the calibration mirror is being renewed because it has been broken, ensure no mirror fragments are left in the cabinet. Any mirror fragments left in the cabinet could affect the operation of the Laser Scanning Unit.

6.2.2 Inspection

Carry out an internal inspection of the Laser Scanning Unit assembly as detailed in § 6.1.2 Inspection, item (b) to (e).

6.2.3 Assembly

CAUTION: EACH MIRROR ASSEMBLY IS MADE OF FRAGILE MATERIAL. USE EXTREME CARE WHEN LOCATING THE MIRROR ASSEMBLY TO AVOID DAMAGE OR BREAKAGE!

- (a) Carefully position the calibration mirror on its mounting and secure in position using the 3M mounting tape.
- (b) Ensure the mirror is free of fingerprints, grease, dust and moisture.
- (c) Close the cabinet door and secure using the lock.

6.2.4 Testing

- (a) Switch power ON.
- (b) Verify the centreline definition according to Chapter 4A Stand Configuration Utility.
- (c) If the centreline definition points are not correct, the system must be set up again. This means: defining and verifying the centrelines, setting calibration check points and making a new backup of the Stand configuration file. Please refer to Chapter 4A Stand Configuration Utility.
- (d) Perform a walk-test procedure.



6.3 RENEWAL OF SCANNING MIRROR

6.3.1 Mirror Disassembly

The figure below illustrates the assembly of the two mirrors for horizontal and vertical scanning direction.

The small mirror is used for the horizontal scan on T2/T3, vertical scan for T1. The large mirror is used for the vertical scan on T2/T3, horizontal scan for T1.



FIGURE 4.35 – SAFEDOCK T1 SCANNING MIRRORS



FIGURE 4.36 – SAFEDOCK T 2/3 SCANNING MIRRORS

- (a) Switch power OFF and isolate the power supply unit.
- (b) To gain entry to the Laser Scanning Unit, undo the cabinet lock, and open the hinged door.
- (c) Loosen the two 3-mm socket head screws on the axle adapter, which secure the scanning mirror to the motor drive shaft.
- (d) Carefully withdraw the scanning mirror, complete with axle adapter, from the motor drive shaft.

Note: If the scanning mirror is being renewed because it has broken, ensure no mirror fragments are left in the cabinet. Any mirror fragments left in the cabinet could affect the operation of the laser scanning system.

6.3.2 Inspection

Carry out an internal inspection of the Laser Scanning Unit assembly as detailed in § 6.1.2 Inspection, items (b) to (e).

6.3.3 Assembly

CAUTION: EACH MIRROR ASSEMBLY IS MADE OF FRAGILE MATERIAL. USE EXTREME CARE WHEN LOCATING THE MIRROR ASSEMBLY TO AVOID DAMAGE OR BREAKAGE.

- (a) Carefully locate the new scanning mirror, complete with axle adapter, on the motor drive shaft.
- (b) Secure the axle adapter to the motor drive shaft, by tightening the two socket head cap screws.

6.3.4 Testing

- (a) Reconnect the power supply to the Laser Scanning Unit and switch ON.
- (b) Verify the centreline definition according to Chapter 4A Stand Configuration Utility.
- (c) If the centreline definition points are not correct, the system must be set up again. This means: defining and verifying the centrelines, setting calibration check points and making a new backup of the Stand configuration file. Please refer to Chapter 4A Stand Configuration Utility.
- (d) Perform a walk-test procedure.



6.4 RENEWAL OF LASER RANGE FINDER

6.4.1 Range Finder Disassembly

The figure below illustrates the position of the Laser Range Finder.



FIGURE 4.37 – SAFEDOCK T1 LASER RANGE FINDER



FIGURE 4.38 – SAFEDOCK T2/3 LASER RANGE FINDER

- (a) Switch OFF and isolate the power supply.
- (b) To gain entry to the Laser Scanning Unit, undo the cabinet lock and open the hinged door.
- (c) Disconnect the Laser Range Finder electrically by pulling out the green connector from the terminal block.
- (d) Remove the two socket head cap screws, which secure the Laser Range Finder to the bracket.
- (e) Lift the Laser Range Finder clear of the bracket.

6.4.2 Inspection

Carry out an internal inspection of the Laser Scanning Unit assembly as detailed in § 6.1.2 Inspection, items (b) to (e).

6.4.3 Assembly

- (a) Locate the new Laser Range Finder and secure to the bracket with the two socket head cap screws.
- (b) Connect the Laser Range Finder's electrical leads to the terminal block.
- (c) Close the cabinet door and secure using the locks.

6.4.4 Testing

- (a) Reconnect the power supply to the Laser Scanning Unit and switch ON.
- (e) Verify the centreline definition according to Chapter 4A Stand Configuration Utility.
- (f) If the centreline definition points are not correct, the system must be set up again. This means: defining and verifying the centrelines, setting calibration check points and making a new backup of the Stand configuration file. Please refer to Chapter 4A Stand Configuration Utility.
- (b) Perform a walk-test procedure.

6.4.5 Reset Laser Statistics

Note: This operation is to be performed whenever a laser unit is replaced.

(a) From the Operator Panel, select Test.



(b) From the **Test** menu, press the right arrow for the next page and select **Statistics**.

-										
Walk	View	OP	Light	Temp		Set				Re-
Test	Log	Test	Sens	Sens		IP			I	start
Program version			Progra	m versio	n					
SOS 1.0.0			SOS 1.	.0.0						
Mirr	Mirr	Laser	Scan	Disp		Com	Stati	Cal	1	ı
Pos	Test	Test	Test	Test		info	stics	Test		IJ

FIGURE 4.40 – OP STATS

(c) From the **Statistics** menu, select **Reset laser** and then **Confirm** to reset the laser time.



Page 33 of 52

6.4.6 Scan Test

A LASER SCAN ERROR may be caused by one of the following components: stepper motor, stepper motor card, laser or CU card. The following steps may help to diagnose which of the components is at fault:

- (a) Move one of the mirrors gently by hand. When moving it the LED named LASER SAFE should light up as an indication of that the stepper motor sensor is detecting a movement. There should be some resistance when moving the mirror by hand. If not, the Stepper Motor Driver is possibly broken. Swap the 2 Stepper Motor Drivers to check if the problem moves to the other stepper motor.
- (b) If the LED does not light up, then there is a problem with the cable between the stepper motor and the CU board, or the stepper motor itself.

6.5 RENEWAL OF CONTROL UNIT

6.5.1 Preparations before Maintenance

Note: Stand set-up parameters, such as configuration data, calibration values and aircraft data, are stored in a non-volatile memory of the control unit.

A DISK COPY OF THE STAND SET-UP PARAMETERS SHALL PREVIOUSLY HAVE BEEN MADE AT THE SAFEDOCK INSTALLATION/SET-UP PHASE AT EACH STAND.

THIS PROCEDURE HAS BEEN DONE FOR FACILITATING THE EXCHANGE OF THE CONTROL UNIT IN CASE OF AN ERROR, AND FOR MAKING RESTORATION OF SOFTWARE AND SET-UP PARAMETERS EASIER AFTER THE EXCHANGE OF HARDWARE.

THE APPLICABLE STAND SET-UP FILE SHALL BE LOADED INTO THE MAINTENANCE PC ACCORDING TO INSTRUCTIONS IN CHAPTER 4A STAND CONFIGURATION UTILITY.

6.5.2 Dumping Stand Set-Up Parameters from the Control Unit

If the stand parameter back-up file is not available, the procedure described in Chapter 4A Stand Configuration Utility can be carried out to secure the Stand set-up parameters, if possible.

- (a) Connect the Maintenance PC, loaded with the Safedock Maintenance software, called SMT.EXE, to the connector at the right side of the Operator Panel.
- (b) Dumping the CU memory contents to the PC will be done automatically, as soon communication between the CU and the PC is established. To make a disk copy, use the function "SAVE" in the Safedock Stand Configuration Dialogue Box. The current configuration will be saved onto disk in the maintenance PC.

If a faulty Control Unit does not allow you to dump its memory contents, the set-up and calibration procedure has to be done manually again as described in the Chapter 4A Stand Configuration Utility.

6.5.3 Control Unit Disassembly

The figure below illustrates the position of the Safedock Control Unit/CU.



FIGURE 4.42 - SAFEDOCK T1, T2 AND T3 CONTROL UNIT



Renewal of Control Unit/Carrier Board

This information is a basic step-by-step guide for authorized personnel to replace a Control Unit (CU) Carrier Board.

Safedock T1/2/3 (system design from Spring 2008) - CU circuit includes a docking board (connections) and a carrier board (CPU).

Before you start

(a) If possible, use the Safedock Maintenance program (SMT) to save the configuration file. *Note:* For more information, see the Chapter 4A Stand Configuration Utility.

WARNING: DANGER OF ELECTRIC SHOCK!

- (b) ISOLATE THE POWER SUPPLY PRIOR TO UNDERTAKING ANY MAINTENANCE!
- (c) IF A BATTERY BACKUP IS INSTALLED, THE DC CURRENT TO ELECTRONICS MUST ALSO BE SWTICHED OFF.

Note: Standard tools are required such as screwdrivers and Allen keys.

Image examples Removal Carrier board (SG590524-000) (a) Open the Safedock Pilot Display cabinet and set the Clamp for Stepper Motor Driver Cards Safedock power switch to OFF. L Stepper Motor Driver Cards (b) Locate the protective cover for the CU-circuit board assembly and remove it. CU-Circuit Board (c) Remove the carrier board. (d) Return the (old) CU-circuit boards to Safegate. Renewal (a) Position the Carrier Board-CPU assembly over the mating contacts and stand offs on the docking board and press until contacts are seated and locking tabs on the stand-offs click into place. Protective Cover (b) Re-install the protective cover. (c) Power up the system and install and configure the Part Identification for Disassembly software for the Safedock system, if required. FIGURE 4.43 - CU PARTS Note: The new CU-circuit board requires version 8 or higher to run properly. Testing (a) Verify the system starts up correctly: Operator Panel contact is re-established and the emergency stop function is operational. (b) If it was possible to save the configuration file using the Safedock Maintenance program (SMT) then the configuration can be loaded to the system once again. If not, a new configuration is required according to the manual.

(c) Perform a walk-test procedure.

Renewal of Control Unit/Docking Board

This information is a basic step by step guide for authorized personnel to replace a Control Unit (CU) Docking Board.

Safedock T1/2/3 (system design from Spring 2008) - CU circuit includes a docking board (connections) and a carrier board (CPU).

Before you start

(a) If possible, use the Safedock Maintenance program (SMT) to the configuration file. *Note:* For more information, see the Chapter 4A Stand Configuration Utility.

WARNING: DANGER OF ELECTRIC SHOCK!

- (b) ISOLATE THE POWER SUPPLY PRIOR TO UNDERTAKING ANY MAINTENANCE!
- (c) IF A BATTERY BACKUP IS INSTALLED, THE DC CURRENT TO ELECTRONICS MUST ALSO BE SWTICHED OFF.

Note: Standard tools are required such as screwdrivers and Allen keys.

Removal	Image examples
Docking board (SG590562-000)	
(a) Open the Safedock Pilot Display cabinet and set the Safedock power switch to OFF.	-Clamp for Stepper Motor Driver Cards
(b) Locate the protective cover for the CU-circuit board assembly and remove it.	Stepper Motor Driver Cards
(c) Disconnect all wiring from the docking board.	
 (d) Undo the clamp fasteners holding the stepper motor driver cards in place. Remove the stepper motor driver cards by pulling them away from the CU-circuit board. 	
(e) Remove the carrier board.	
 (f) Remove the docking board by removing the six fasteners holding it in place on the stand-offs. Note: Be careful not to loosen the stand-offs, as it can be difficult to re-tighten them without loosening 	Protective Cover
the mounting plate.	Part Identification for Disassembly
(g) Return the (old) board to Safegate.	,
	FIGURE 4.44 – CU PARTS



Renewal	Image examples
 (a) Fasten the new docking board in place on the standoffs. (b) Position the Carrier Board-CPU assembly over the mating contacts and stand offs on the docking board and press until contacts are seated and locking tabs on the stand-offs click into place. (c) Re-install the stepper motor driver cards. (d) Position the extension assembly on the edge of the mounting plate so it is centred to the stepper motor driver cards, and then tighten the set screws on the extension plate. (e) If the stepper motor driver cards are mounted horizontally, use the clamp and screw supplied with the spare part to fasten the clamp. 	Image: Constraint of New Parts, Systems with Horizontally Mounted Stepper Motor Driver Cards
 If the stepper motor driver cards are mounted vertically, attach and fasten the original clamp. <i>Note:</i> If an extension assembly exists in the system, it must be re-used with the clamp. (f) Re-connect all wiring. (g) Re-install the protective cover. (h) Set the Safedock power switch set to ON (i) Power up the system and install and configure the software for the Safedock system, if required. <i>Note:</i> The new CU-circuit board requires version 8 or higher to run properly. 	FIGURE 4.45 – CU PLACEMENT HORIZONTAL
Testing	
(a) Verify the system starts up correctly: Operator Panel co stop function is operational.(b) If it was possible to save the file using the Safedock Ma configuration can be loaded to the system once again.	intact is re-established and the emergency

- If not, a new configuration is required according to the manual.
- (c) Perform a walk-test procedure.

Renewal of Control Unit with a CU Board Upgrade Kit

This information is a basic step by step guide for authorized personnel to replace a Control Unit (CU) circuit board.

Safedock T1/2/3 (system design from Spring 2008) - CU circuit includes a docking board (connections) and a carrier board (CPU).

Safedock T2/3 (SG590125-000/older system design to Spring 2008) - CU-circuit single board (connection and CPU). *Note: This design is now obsolete.*

- CU Board Upgrade Kit (SG590399-001-01) includes:
 - A docking board and a carrier board.
 - Extension plate, clamp and screw for some systems, if required.

Note: The CU Board Upgrade Kit requires software version 8.0 or higher.

Before you start

(a) If possible, use the Safedock Maintenance program (SMT) to save the configuration file. *Note:* For more information, see the Chapter 4A Stand Configuration Utility.

WARNING: DANGER OF ELECTRIC SHOCK!

- (b) ISOLATE THE POWER SUPPLY PRIOR TO UNDERTAKING ANY MAINTENANCE!
- (c) IF A BATTERY BACKUP IS INSTALLED, THE DC CURRENT TO ELECTRONICS MUST ALSO BE SWTICHED OFF.

Note: Standard tools are required such as screwdrivers and Allen keys.

Removal

CU-circuit board (SG590125-000)

- (a) Open the Safedock Pilot Display cabinet and set the Safedock power switch to **OFF**.
- (b) Locate the protective cover for the CU-circuit board assembly and remove it.
- (c) Disconnect all wiring from the CU-circuit board.
- (d) Undo the clamp fasteners holding the stepper motor driver cards in place.
 Note: If a welded stud is used as the clamp fastener,
- carefully twist the stud to break it off.(e) Remove the stepper motor driver cards by pulling
- them upwards from the CU-circuit board.
- (f) Remove the CU-circuit board by removing the six fasteners holding it in place on the stand-offs.
 Note: Be careful not to loosen the stand-offs, as it can be difficult to re-tighten them without loosening the mounting plate.
- (g) Return the (old) board to Safegate.



Image examples

Renewal	Image examples
 (a) Fasten the new docking board in place on the standoffs. (b) Position the Carrier Board-CPU assembly over the mating contacts and stand offs on the docking board and press until contacts are seated and locking tabs on the stand-offs click into place. (c) Re-install the stepper motor driver cards. (d) Position the extension assembly on the edge of the mounting plate so it is centred to the stepper motor driver cards, and then tighten the set screws on the extension plate. (e) If the stepper motor driver cards are mounted horizontally, use the clamp and screw supplied with the spare part to fasten the clamp. 	Image: Constraint of New Parts, Systems with Horizontally Mounted Stepper Motor Driver Cards
 If the stepper motor driver cards are mounted vertically, attach and fasten the original clamp. Note: If an extension assembly exists in the system, it must be re-used with the clamp. (f) Re-connect all wiring. (g) Re-install the protective cover. (h) Set the Safedock power switch set to ON (i) Power up the system and install and configure the software for the Safedock system, if required. Note: The new CU-circuit board requires version 8 or higher to run properly. 	FIGURE 4.48 – CU PLACEMENT HORIZONTAL
Testing	
 (a) Verify the system starts up correctly: Operator Panel constop function is operational. (b) If it was possible to save the configuration file using the then the configuration can be loaded to the system once of the the configuration is required according to the matching of the term. 	ntact is re-established and the emergency Safedock Maintenance program (SMT) e again.

(c) Perform a walk-test procedure.

6.6 RENEWAL OF POWER SUPPLY

6.6.1 Power Supply Disassembly

The figure below illustrates the position of the Safedock power supply.

WARNING: DANGER OF ELECTRIC SHOCK! ISOLATE THE POWER SUPPLY PRIOR TO UNDERTAKING ANY MAINTENANCE!

IF A BATTERY BACKUP IS INSTALLED, ALSO THE 24 VOLT DC CURRENT TO THE ELECTRONICS HAS TO BE SWITCHED OFF!



FIGURE 4.50 - SAFEDOCK T1, T2 AND T3 POWER SUPPLY



Renewal of Power Supply Unit

This information is a basic step by step guide for authorised personnel to replace a power supply unit. *Note:* For more information, see Chapter 4A Stand Configuration Utility.

Before you start

WARNING: DANGER OF ELECTRIC SHOCK!

- (a) ISOLATE THE POWER SUPPLY PRIOR TO UNDERTAKING ANY MAINTENANCE!
- (b) IF A BATTERY BACKUP IS INSTALLED, THE 24 VOLT DC CURRENT TO ELECTRONICS MUST ALSO BE SWTICHED OFF.

Note: Tools required are a standard flat blade screwdriver and an electrical flat blade screwdriver.

Removal

- (a) Open the Safedock Pilot Display cabinet and locate the lower DIN rail.
- (b) Locate the Safedock power switch and set to OFF.
- (c) Locate the power supply unit.
- (d) Disconnect primary and secondary cables from the unit.
- (e) Use a standard flat blade screwdriver to release the spring latch under the unit.





FIGURE 4.51 – POWER SUPPLY RELEASE REMOVAL

Renewal

- (a) Locate the upper DIN rail in the Safedock Pilot Display cabinet.
- (b) Carefully place the new power supply unit into position.
- (c) Apply gradual pressure until the spring latch catches on the DIN rail.
- (d) Connect primary cables to the power unit.
- (e) Set the Safedock power switch set to **ON**.
- (f) Adjust the secondary voltage with a small screwdriver for 24VDC
- (g) Connect secondary cables to the power unit.

FIGURE 4.52 – POWER SUPPLY ADJUST

Testing

- (a) With the power supply ON, measure 115/230VAC (primary side) and 24 VDC ±1 (secondary side).
- (b) Verify the system starts up correctly: Operator Panel contact is re-established and the emergency stop function is operational. *Note:* For more information, see Chapter 3 OPERATION.

SAFEDOCK® Manual Chapter: 4 MAINTENANCE

6.7 RENEWAL OF STEPPER MOTOR DRIVERS

6.7.1 Stepper Motor Driver Disassembly The figure below illustrates the position of the two motor control boards, connected directly to the Control Unit.



FIGURE 4.53 – T1 STEPPER MOTOR DRIVERS



FIGURE 4.54 – T2/3 STEPPER MOTOR DRIVERS



WARNING! DANGER OF ELECTRIC SHOCK. THE ELECTRICAL CONNECTIONS MAY BE LIVE. DO NOT PLACE ANY TOOL INSIDE THE CONTROL RACK.

- (a) Switch power OFF and isolate the power supply unit.
- (b) To gain access to the motor control boards, loosen the four self-retaining screws, on top of the cover plate, which secures the protective cover plate.
- (c) Withdraw the motor control board. The two motor boards are equivalent.

6.7.2 Assembly

- (a) Ensure the DIP switch positions, located on the control boards, and are set correctly. The switch settings have to correspond with the setting of the removed control board.
- (b) Carefully insert and locate the motor control board. Tighten the screw.
- (c) Fit and secure the protective cover plate, using the four self-retaining screws.

6.7.3 Testing

- (a) Switch **ON** power to the system.
- (b) Start a docking procedure. The system will perform a calibration control and a self-test.
- (c) If the system fails during the calibration control test, undertake a new calibration procedure, according to Chapter 4A Stand Configuration Utility.

6.8 RENEWAL OF LED MODULE

6.8.1 LED Module Disassembly

The figure below illustrates the LED matrix boards' connection to the mounting plate.



FIGURE 4.55 – SAFEDOCK T1 LED MODULE

Note: The front glass is hinged at the top of the display unit.

- (a) To gain access to the inside of the display unit, undo and lift the front glass of the cabinet.
- (b) Switch **OFF** and isolate the power supply.
- (c) Undo the two lock devices on the outer end of the front glass and let down the plate with the LED modules on.
- (d) Carefully remove the defective LED module.

6.8.2 Inspection

- (a) Inspect the front glass for cleanliness. Clean as required.
- (b) Inspect the cabinet for extraneous material. Clean as required.

6.8.3 Assembly

- (a) Insert the new LED module.
- (b) Carefully close the front glass and secure.

6.8.4 Testing

- (a) Switch power **ON**.
- (b) Run the display test from the Operator Panel to verify the function of the new board as follows. Push the **Test** key and select **Display Test** and activate **Address test**. The display shows now the alphabet with one letter on each module. Check if the right letter is displayed on the modules.

Page 45 of 52

Renewal of Operator Panel Film (Softkey) This information is a basic step by step guide for authorized personnel to replace an old type, a damaged or worn film on the front cover, with a new one. Before you start WARNING: DANGER OF ELECTRIC SHOCK! (a) ISOLATE THE POWER SUPPLY PRIOR TO UNDERTAKING ANY MAINTENANCE! (b) IF A BATTERY BACKUP IS INSTALLED, THE 24 VOLT DC CURRENT TO ELECTRONICS MUST ALSO BE SWTICHED OFF. Note: Tools required are No. 1, 2 Phillips and flat blade screwdrivers, a knife, white spirits and a cleaning cloth. Removal (b) (b) (a) Pilot Display: Locate the power switch on the lower DIN rail and set to OFF. (b) Operator Panel: Loosen the screws of the cover and open it. (b) (b) FIGURE 4.56 - OP FILM Disconnect the film cable and maintenance cable (c) (c) connectors from the circuit board inside the Operator Panel. (d) Disconnect the Emergency-Stop button and cabling from the inside of the cover as follows: Loosen the terminal screw. Release the terminal clamp. Pull the Emergency-Stop button away from the cover. Note: Keep the Emergency-Stop button and terminal screw in a safe place until the film is replaced. (d) FIGURE 4.57 - OP FILM CONNECTION
(e) On the Operator Panel front, lift up a corner of the film using a knife. (f) Carefully start to cut at the film (bottom layer) adhesive and simultaneously detach the film. Note: The film is layered, be careful not to split the layers when cutting/detaching it. When approximately half of the film is released from the surface, it may be possible to detach the rest of the film, without cutting. (g) During removal of the film, pull the film cable out through the upper hole in the cover. Clean the exposed front cover metal surface thoroughly with white spirits on a cleaning cloth until all remaining adhesive is removed. FIGURE 4.58 - OP FILM REMOVAL Renewal (a) Remove all protective coverings from the new film to expose the adhesive surface. (b) Carefully feed the film cable through the exposed upper hole in the front cover. (c) Carefully place the upper area of the film according to the contours for the film on the cover surface. (d) Slowly even out from the top of the film downwards, making sure no air bubbles exist. Continue until the entire film is in place at the bottom. (e) Wipe over the film surface with a dry clean cloth. Note: If the new film does not have a pre-cut Emergency-Stop button hole, locate the approximate centre of the hole by pressing on the film, or use the old film as a template to find it. Make neat incisions (horizontal, vertical and diagonal) with a knife from the centre of the hole to the contour FIGURE 4.59 - OP FILM RENEWED to create sections to cut away. Carefully cut away the sections to expose the hole. (f) Place the Emergency-Stop button in position. (g) Whilst holding the Emergency-Stop button in position, open the front cover and clamp the Emergency-Stop button terminal in the place on the inside. Fasten the terminal with the screw. (h) Connect the film and Maintenance connectors to the circuit board on the inside of the cover. (i) Close the cover and secure the screws. (j) **Pilot Display**: Locate the lower DIN rail and set the power switch set to ON. Testing (a) Verify the system starts up correctly: Operator Panel contact is re-established and the Emergency-Stop button function is operational.

Note: For more information, see Chapter 3 OPERATION.



6.10 RENEWAL OF SURGE ARRESTORS

Ш

Coordon

Renewal of surge arrestor (primary or secondary side)

This information is a basic step by step guide for authorized personnel to replace an old type, a damaged or worn film on the front cover, with a new one.

Before you start

WARNING: DANGER OF ELECTRIC SHOCK!

- (a) ISOLATE THE POWER SUPPLY PRIOR TO UNDERTAKING ANY MAINTENANCE!
- (b) IF A BATTERY BACKUP IS INSTALLED, THE 24 VOLT DC CURRENT TO ELECTRONICS MUST ALSO BE SWTICHED OFF.

Note: No tools required

Removal

TCIII044I	Drimony
 (a) Pilot Display: Open the display door and locate the arrestors subject to exchange, primary or secondary (b) Unplug the corresponding module failing from the socket, by pulling it towards you, (c) Insert a new spare module (d) Re-energise the system. 	Primary side
Testing	
(a) Verify the FAIL message to disappear when starting a d	locking procedure.

6.11 RENEWAL OF DISPLAY FAN AND/OR FILTER (T1 ONLY)

Renewal of display Fan/Filter

This information is a basic step by step guide for authorized personnel to replace display fan or filter.

Before you start

WARNING: DANGER OF ELECTRIC SHOCK!

(a) ISOLATE THE POWER SUPPLY PRIOR TO UNDERTAKING ANY MAINTENANCE!

(b) IF A BATTERY BACKUP IS INSTALLED, THE 24 VOLT DC CURRENT TO ELECTRONICS MUST ALSO BE SWTICHED OFF.

Note: Tools required: alen key, srcrewdriver

Removal

- (a) **Pilot Display:** Open the display door and locate the fan assembly including filters (air outlet) and/or the filter assembly (air inlet) subject to the renewal
- (b) Use the alen key to unscrew the mounting plate for the assembly
- (c) In case of filter exchange, open the now exposed filter cassette and remove the old filter and replace with a new
- (d) In case of fan exchange, disconnect the cabling to the fan and use the screwdriver to dismount the fan. Re install a new fan and re-connect the cabling, re-insert the mounting plate and tighten the alen screws.

Fan/filter assembly. Air outlet.



Filter assembly. Air intlet.



Testing in case of fan exchange

(a) Verify the Fan operation in relation to the temperature and the disappearance of FAIL message in operator panel.
 Note: The switching point of an active fan is default set to 40 degrees but subject to individual

Note: The switching point of an active fan is default set to 40 degrees but subject to individual adjustments.

7. SUPPORT

Our experienced engineers are available for support and service at all times, 24 hour/7 days a week. They are part of a dynamic organization making sure the entire Safegate Group is committed to minimal disturbance for airport operations.

Safegate Support

Safegate knows that our equipment is used in one of the busiest industries in the world, where downtime costs money and creates delays for airlines and their passengers. As one of the world's leading suppliers of airport systems, Safegate is committed to ensuring that our customers are able to get the most out of your equipment, regardless of the location or the time of day. For this reason, Safegate has established the Safegate Support service.

Safegate Support is a unique service provided by Safegate to our customers, free of charge during the warranty period or as a service contract. Any time of day, any day of the year, a Safegate engineer is on standby to answer questions and assist with any problems that may arise. Qualified technical assistance is just a phone call or an email away,

24-7 worldwide.

Support@safegate.com

🖀 +46 40 699 1740



7.1 SAFEGATE WEBSITE

The Safegate Website, <u>www.safegate.com</u>, offers information regarding our airport solutions, products, company, news, links, downloads, references, contacts and more. *Note:* There is also a *Client/Partner login* area for the latest information and updates, if available.

7.2 RE-CYCLING

7.2.1 Local Authority Re-cycling

The disposal of Safegate products is to be made at an applicable collection point for the recycling of electrical and electronic equipment. The correct disposal of equipment prevents any potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. The recycling of materials helps to conserve natural resources. For more detailed information about recycling of products, contact your local authority city office.

7.2.2 Safegate Re-cycling

Safegate is fully committed to environmentally-conscious manufacturing with strict monitoring of our own processes as well as supplier components and sub-contractor operations. Safegate offers a re-cycling program for our products to all customers worldwide, whether or not the products were sold within the EU.

Safegate products and/or specific electrical and electronic component parts which are fully removed/separated from any customer equipment and returned will be accepted for our recycling program.

All items returned must be clearly labelled as follows:

- For ROHS/WEEE Re-cycling
- Sender contact information (Name, Business Address, Phone number).
- Main Unit Serial Number.

Safegate will continue to monitor and update according for any future requirements for EU directives as and when EU member states implement new regulations and or amendments. It is our aim to maintain our compliance plan and assist our customers. *Note:* For more information, see <u>www.safegate.com</u>, or contact Safegate Support via email at <u>support @safegate.com</u> or phone +46 40 699 1740.

7.2.3 Packaging

All packaging shipped with products should be properly marked for recycling per GB 18455-2001 Packaging recycling Mark. Responsible and sustainable recovery of packaging products is therefore of paramount importance, and with the right actions, it contributes to a sustainable environment based on a best effort basis.

All packaging and boxes are to be re-cycled according to local authority regulations.

- Cardboard Used cardboard packaging is to be flattened for delivery to a local authority re-cycling site and onward delivery to, for example, a paper mill for recycling/reuse as a new product.
- Plywood box Used plywood boxes are to be flattened for delivery to a local authority re-cycling site and onward delivery to, for example, a materials recovery facility (MRF) where the box is to be grinded down, while the steel is separated from the Plywood, using an electromagnet. The steel is then sent to a steel mill where it is melted down and reused as a new product. Plywood spillage is burned in a controlled environment, for example a combined heat power plant where the extracted energy is reused in the municipality's energy system with high efficiency, such as in the electricity network.

Note: If plywood is burned in an uncontrolled environment, the amount of CO2 released is the same as the amount of CO2 from the atmosphere through photosynthesis. Wood is a source of bio-energy, in contrast to fossil fuel, and does not contribute to global warming. The concentration of the restricted substances in the waste gas from Plywood is also below the limit.

Nefab Packaging Sweden AB has an Environmenta/Management System certified according to ISO 14001. For more information see <u>www.nefab.com</u>.



SAFEDOCK® Manual Chapter: 4 MAINTENANCE

7.3

SPARE PARTS

For a complete and updated list of spare parts for Safedock system, please see <u>www.safegate.com</u> or contact Safegate for assistance with ordering spare parts.

CHAPTER 4 MAINTENANCE - APPENDIX A STAND CONFIGURATION UTILITY (SAFEDOCK MAINTENANCE TOOL) CONTENTS

Section	Description Pa	ge No.
1.	SCOPE	3
2.	LICENSE INSTALLATION AND SELECTION	3
3.	SOFTWARE OVERVIEW	4
4.	SOFTWARE DESCRIPTION	5
4.1	CONNECTION	5
4.1.1	Creating a New Configuration/ Opening an Existing Configuration	on5
4.2	SYSTEM CONFIGURATION	6
4.2.1	System Information	6
4.2.2	Gate Sign	7
4.2.3	Operational Settings	7
4.2.4	Interlock	8
4.2.5	Docking Confirmation	8
4.2.6	Display Type	8
4.2.7	Display Variants	8
4.2.8	Scanner Type	8
4.2.9	Apron Scan	8
4.2.10	Modbus Interface	8
4.2.11	LDM Type (Laser Distance Meter)	9
4.2.12	Communication	9
4.2.13	Password Method	9
4.2.14	Enable Operator Panel Buttons	9
4.2.15	Log Settings	9
4.2.16	Docking Procedure	10
4.3	SUPPORT FUNCTIONS	11
4.3.1	Updating support functions	11
4.4	SYSTEM CALIBRATION	11
4.4.1	Preferred Calibration Procedure	11
4.4.2	Alternate Calibration Procedure	12
4.4.3	Feature Buttons	13
4.5	AUTO CALIBRATION	13
4.6	CENTRELINE	14
4.7	APRON SCAN	16
4.8	AIRCRAFT	17
4.8.4	Changing multiple settings on multiple aircrafts	18
4.8.1	Aircraft Settings	18
4.8.2	Creating a Stop Position on a Centreline	19
4.8.3	Adding an Aircraft to a Stop Position	19
4.8.4	Modifying Content in Aircraft Menu	19

SAFEDOCK® Manual Chapter: 4A Stand Configuration Utility

4.8.5	Customizing the Operator Panel Layout	20
4.8.6	Creating Generic Aircrafts	21
4.8.7	Legacy A/C-id (GOS)	22
4.9	ISSUES	23
4.10	CONFIGURATION APPLIED	24
4.11	GET LOGS	24
4.12	UPDATING THE SYSTEM	25
5.	IMPORTING CONFIGURATIONS	26
5.1.1	Importing Aircraft Mix, Features and Rules	26
5.1.2	Importing Legacy Configuration	26

1. SCOPE

This is a presentation of the Safedock Maintenance Tool (SMT) describing the procedures of how to configure and calibrate a Safedock system.

2. LICENSE INSTALLATION AND SELECTION

To start, the application requires at least one license file to be present in the license folder. If more than one license file is present, the application will present a list of available licenses and let the user choose one to use until next restart. If only a single license is present it will be used without questions to the user.

All license files are branded with the name of the airport they belong to and also information about inherence to a specific terminal etc. This information is displayed in the title bar of the application.

★ Select license	×
No license found	
Cancel	Ok 📘

FIGURE 4A.1 – LICENSE SCREEN

If no license is found, the license folder can be accessed via the button in the lower right corner of the dialog. Simply copy the license file you have obtained into the license folder and restart SMT.

Use the File > Open data directory menu to access the license folder when a single license is installed and the license dialog isn't displayed during application start.



3. SOFTWARE OVERVIEW

On the left side each task that needs to be performed is represented by a red, yellow or green marker, where the colours have the following meanings:

- Green OK
- Red Incomplete
- Yellow Intermediate (configuration may need to be applied to system before continuing)

🛧 Safed	lock Maintenance To	ol Site: 'Example Airport' Variant: 'Example License'	- 0 ×
File Se	ettings Safedock	About	
× °	Connection +		
× s	System Configuration		
× s	System Calibration		
	Auto Calibration		
8	Centerline	SAFEDOCK MAINTENANCE TOOL	
	Aircraft	10	
	ssues	- Contraction of the second se	
	Configuration Applied		
G	Set logs		
		Program version: 1.2.1.0	
		Aircraft data: 1777/2013-08-16 14:38:31	
Status: Di	lisconnected		TX:ORX:O

FIGURE 4A.2 – SMT START SCREEN

The tasks needed may vary based on the configuration. The details for each task presented here may not always correspond to what you see on your screen. The license you are using may also affect the layout of the application. When clicking on each task a view with corresponding settings will appear. It is recommended to perform the tasks top to bottom.

4. SOFTWARE DESCRIPTION

CONNECTION

4.1

SMT can connect using either a serial line or a network connection. To connect, click the right-arrow to open the connection settings, select/enter information as required and press the "Connect" button. Network adresses can be entered either as DNS-names (if such are available) or IP-numbers (only IPv4 is supported).

Safedock Maintenance Too	ol Site: 'Example Airport' '	Variant: 'Example License'	
Connection	Network 🔻		
System Configuration	• Connect		
System Calibration			
Auto Calibration	<u>n</u>		
Centerline		* SAFEDOCK MAINTENANCE TOOL	
Aircraft.		10	
Issues			
Configuration Applied			
Get logs			
		Program version: 1.2.1.0	
		Aircraft data: 1//// 2013-08-10 14:38:31	
Status: Disconnected		Î.	TX:ORX:

FIGURE 4A.3 - CONNECTION FEATURE

4.1.1 Creating a New Configuration/ Opening an Existing Configuration

To create or open a configuration, use one of the following ways

- Connect to a Safedock system to download a configuration.
- Open an existing configuration using the "File / Load" menu.
- Create a new configuration using the "File / New" menu. Using this option you will also need to select the template to use for schematics in the new configuration.

You need to have a configuration open to access most parts of the application. Some parts will be disabled when not connected to a Safedock system.

When connecting to a system without an existing configuration, a dialog will appear that prompts for a selection of one of the possible actions.





Page 5 of 26

4.2

SYSTEM CONFIGURATION

SMT comes with a series of features that can be adjusted to your needs. The availability of these features depends on both the version of the Safedock system and also the license in use.

You must apply the configuration to the system after changing the type of scanner being used, otherwise the system calibration will be invalid; this is indicated by the yellow icon on the left side.

Safedock Maintenance	Tool Site: 'Safegate' Variant: 'Example	e' Stand: 'Luo'
File Safedock About		
Connection	Configuration Support Function	s
192.168.1.11	System Information	Stand name Luo
System	Gate Sign	
Configuration	Operational Settings	Serial number -
System	Interlock	Program version SOS 1.5.8
Calibration	Docking Confirmation	SoShallyarrian SHELL 1.1 PTT524
Auto Calibration	Display type	System version Shell 1.1-KTT554
	Scanner type	
Centerline	LDM Type	
	Apron Scan	
Aircraft	Password method	
Decement	Enable operator panel buttons	
	Communication	
Issues	Docking procedure	
Configuration Applied		
Get logs		
Serial number		
Status: Connected		TX:●RX:●

FIGURE 4A.5 - SMT – SYSTEM CONFIGURATION

Some settings may display a confirmation dialog asking you to accept changing the setting. This is done to prevent accidental activation/deactivation of a feature that may have a negative impact on other features in the system.

4.2.1 System Information

- Stand name: This setting specifies the name of the stand, and will be reported to the Superior System.
- Program version: Shows the version of the software that wrote the currently used configuration template, whether loaded from disk or directly from a system.

4.2.2 Gate Sign

Different type of gate related information can be enabled on the Pilot Display:

- Allow off: If checked, the display can be blanked. This is also the default mode for the Pilot Display.
- Allow sign: If checked, the texts entered in parameters Line 1 & Line 2 can be shown on the first and second line of the display (if available).
- Allow time: If checked, the display can show the Current Time.
- Allow alternating time/gate sign: The display can show alternating Current Time/Stand ID and Stand No.
- Large font (if supported by display): The display will show double-sized text instead of two texts on two lines.

4.2.3 Operational Settings

- Use Prepared: The default scheduling procedure is changed to an alternative, site specific procedure. The message appears when the scheduled flight information is made available for the Safedock system. The system is then awaiting activation of the docking procedure. The only operation available to the local operator at this time is to abort the prepared flight. The activation command must come from the Superior System.
- Use pushback tracking: The system tracks the aircraft during pushback and reports the distance to the superior system. Requires activation either from the operator panel, superior system or via input signalling.
- Do park-off checks also when pushback tracking is used: Normally when pushback operations are used, the park-off scans are not required. However, depending on the operational procedures it may be desired to use them. Use this option to alternate between the modes.
- Send approach track data: Depending on the level of integration with other systems, it may be desired by the superior system to receive positional information of an approaching aircraft.
- Report nose wheel position instead of nose position: Selecting this option results in the nose wheel position being sent instead of the nose position during approach and pushback.
- Max Open Gate Duration: The maximum time the system remains in the open state before going back to ready state.
- 'Start docking' as start menu: If checked, the start docking menu will be displayed when the system is idle instead of the normal root menu.
- Revert to ready and clear RIDS if communication to superior system is lost: Depending on the requirements, it may be desired to prevent out-dated data from being used by an operator when the communication to the superior system is lost. If this option is selected, the system will revert from the states Scheduled and Prepared to the Ready state and clear any RIDS texts one minute after loss of communication is discovered. This option is only applicable if SAM is the superior system.
- Blocking amplitude: The amplitude value to use for filtering of echoes within the view blocked limit.

Unexpected **VIEW BLOCK** messages can be caused by internal reflections within the enclosure. A calibration picture facing the area where the aircraft type is expected to appear should be taken to identify the echoes and a right click on the echo seen as a yellow mark will give the amplitude. The value that should be inserted is the echo amplitude + 5. Maximum value that can be used is 60.

• Use UPS: This option should be set if the system is equipped with internal Uninterruptible Power Supply unit.

4.2.4 Interlock

- Use Superior System Interlock: This activates a blocking scheme, whereby two
 adjacent Safedock systems will lock each other out, allowing only one of the
 systems to be active at a time, or allow for operational use up to a pre-defined
 size of aircraft depending on the aircraft parked at adjacent stand. This feature is
 normally used only where two centrelines are located too close to each other to
 allow them both to be used at the same time. Requires appropriate configuration
 of the superior system.
- Request Interlock Timeout: The maximum time to wait for an answer from the Superior system when requesting permission to start a docking. If the specified time is exceeded, the operator will be presented with an option to manually confirm or to abort the docking.

4.2.5 Docking Confirmation

- Use Docking Confirmation via Superior System: When a docking is started, a confirmation request is sent to the superior system. If the requested aircraft matches what the superior system has in its flight schedule, the docking is started, otherwise the operator is presented with a menu where (s)he can select either the aircraft type previously selected or the one provided by the superior system.
- Request Docking Timeout: The maximum time to wait for an answer from the Superior System when requesting permission to start a docking. If the specified time is exceeded, the operator will be presented with an option to manually confirm select the aircraft or to abort the docking.
- Flight Information System: The label that should be used for the FIS system on the Operator Panel when presenting the options to the operator.

4.2.6 Display Type

• Display type: Different types of Pilot Display can be specified (if the license permits). Select the one matching the actual hardware in the system.

4.2.7 Display Variants

- Use digital countdown: If checked, the system will display a digital countdown of the distance to go on the Pilot Display. The distances specify during which ranges the different steps are used for digital countdown.
- Use countdown in feet: If selected, digital countdown will be displayed using feet instead of meters.

4.2.8 Scanner Type

Currently, only one scanner type is available:

• LRFScanner: This is the scanner that uses stepper motors and a Laser Range Finder.

4.2.9 Apron Scan

- Perform apron scan: If checked, the system will perform a scan of the area in front of the system (as defined in the apron scan configuration), notifying the operator or the Superior System if any blocking object is found.
- Detection height: The minimum height of objects to be detected. Lowering this value increases the time it takes to scan the defined area.
- Ground margin: The height relative to the ground that the system will ignore items below, used to compensate for irregularities in the apron.
- 4.2.10 Modbus Interface

Safedock can communicate with up to four external equipment devices, such as a PBB, using Modbus/TCPIP.

- Channel 1-4: If checked, Safedock will act as a TCP/IP client and Modbus master, connecting to the Modbus server specified by the parameter *IP Address* on port *Port number* with a poll update frequency as specified by the *Poll time* parameter.
- Please note that additional configuration is required to enable the functionality; please contact Safegate Support for further information.
- 4.2.11 LDM Type (Laser Distance Meter)
 - LD3 LDM: Should be checked if a digital LDM is mounted.
 - LD90 LDM: Should be checked if an analogue LDM is mounted.

Note: The LMD type of must be correctly set for system proper operation.

- 4.2.12 Communication
 - SAM (SafeControl Apron Management) Communication Channel 1 & 2:
 - SAM Communication Mode: Specifies if SOS shall work as server or client.
 - SAM server IP (Client mode only): Specifies the IP address of the SAM server. Has no effect if mode is Server.
 - Port number: Specifies the port number to connect to (as client) or listen on (as server).
 - Legacy GOS ID: Identifier for the system when connected to a GOS system. Must be unique among all systems connected to the same GOS.
 - Legacy GOS communication mode: Specifies the communication mode for the connection to the GOS server. If the standard serial line converter is used, i.e. a "Tibbo" (connected to connector J11), the setting 'Serial' shall be used.

4.2.13 Password Method

- No password: No password protection for operator and/or maintenance operations is used.
- Pincode: A four-digit password for operator and/or maintenance operations is required.

4.2.14 Enable Operator Panel Buttons

- Open gate: Enables a local operator to acknowledge that the Stand area is empty and ready to accept an aircraft. This command can be used to accept a scheduled docking, initiated by the Superior System, or to set the stand status to 'Free Open', allowing remote start of a docking procedure.
- Chocks on: Enables a local operator to send a message to the pilot that the ground personnel has put the chocks on the wheels and the docking procedure is completed. This option must not be enabled at the same time as "Chocks on/off".
- Chocks on/off: Same as "Chock on", but also allows the operator to signal Chocks off. This option must not be enabled at the same time as "Chocks on".
- ID-override: Enables a local operator to override an ID-Fail condition.
- Legacy GOS comm info: Specifies whether the button for opening menu page with information about GOS communications activity should be enabled on the operator panel.
- Superior comm info: Specifies whether the button for opening menu page with information about Superior communications activity should be enabled on the operator panel.

4.2.15 Log Settings

 Maximum total log size: Specifies the maximum amount of megabyte the docking logs may occupy before the system starts to delete the oldest files to allow new logs to be saved.

Page 9 of 26

4.2.16 Docking Procedure

- Use rolling arrows in downgrade: If checked, the system will allow the rolling arrows to be displayed even in downgrade mode; by default the system is preventing this type of signal in downgrade mode.
- Use engine verification: If checked, the system will perform engine verification on the approaching aircraft, unless specifically disabled for a particular aircraft.
- Standstill time: The time (in seconds) that the aircraft must be at a standstill before the docking is considered complete.
- Ok message time: The time (in seconds) that the **OK** message will be displayed.
- Too far message time: The time (in seconds) that the **TOO FAR** message will be displayed.
- Stop short detection distance: Maximum distance from the stop-position at which the system may consider the docking completed if the aircraft is at a standstill. Must be > 0 to enable the function.
- Stop short detection time: The time (in seconds) that the aircraft must be at a standstill before the docking is considered finished if the aircraft stops before the stop-position. Must be > 0 to enable the function. Stop short message time: The time (in seconds) that the **STOP SHORT** message will be displayed.
- ID-Fail message time: The time (in seconds) that the **ID FAIL** message will be displayed. During this time, it is possible to restart the docking without engine identification check, using the "ID-override" button.

4.3 SUPPORT FUNCTIONS

This view enables adding, removing and importing support functions into the configuration. The left side lists those that are in use and the right side those that are unused and that can be entirely removed from the configuration. By clicking on the buttons with the arrows, they can be moved between the two lists.

When a function is removed, new ones may appear since the last function that used them was just removed.

Safedock Maintenance To	ol Site: 'Safegate' Variant: 'Example' Stand: 'Luo'	
File Safedock About		
Connection	Configuration Support Functions Functions in use Unused functions	
System Configuration	BridgeText >>> ChockOn >>>	*
System Calibration	DockingInProgress >>> StandardBridgeIn >>>	
Auto Calibration	SurgeArrestor >>> SystemStatus >>>	
Centerline	UPS >>>	
Aircraft		
Password		
Issues		
Configuration Applied		
Get logs		
Serial number	· ·	
Status: Connected		TX:●RX:●

4.3.1 Updating support functions

A support function may be updated by first moving it to the list of unused functions, the deleting all functions in that list until there are none left. Then, using the Importbutton, import the function and move it to the list of used functions.

4.4 SYSTEM CALIBRATION

This step prepares the configuration of the system regarding the stand area in front of the Safedock unit. It is important to be thorough while calibrating the system because everything relies on the calibration being correct. All values in this view are relative to the position of the laser, meaning that if the system is mounted with a laser height of 5m; the ground will thus be at -5m relative to the laser.

4.4.1 Preferred Calibration Procedure

- Enter the horizontal height and the vertical width, in degrees, for the area to scan. A value of ten is a good starting point. Note that the area you define here is what you will have available during centreline definition later in the setup procedure. Make sure that you cover enough of the area; otherwise you will have to redo this step. Likewise, if you will be using the "Apron Scan" feature, the entire area to be scanned must be seen in the final image.
- 2. Enter the horizontal and vertical centre, in degrees, of the area to scan. These are normally close to zero, but will differ from system to system depending on

how the mirrors are mounted on the axis of the mirror motor. Negative values are to the left/up, positive to the right/down, from the system point of view.

- 3. Press the "Start Scan" button and wait for the application to build an image of the defined area. While the image is being built, a counter will indicate how many scans there are left until completion.
- You can choose to show the scanned image in a multi-colour scale (when "Distance" is selected) and the in a blue-white gradient scale (when "Amplitude" is selected), see figures below.



FIGURE 4A.6 - SYSTEM CALIBRATION FEATURE - COLOUR SCREEN

- 5. Next, use the paint tool ("Paint" button) to mask/hide those areas in the image that should not be considered as the ground. Use left-click to mask and right-click to erase the mask.
- 6. When all non-ground areas have been masked, press the button "Use Calibration". A dialog will be displayed, asking for confirmation.
- 7. Verify that the point-graph (with a white background) in the lower part of the window accurately represents the silhouette of the area in the middle of the newly masked image. In most cases, the points should form a straight line.

2 Alternate Calibration Procedure

If conditions are such that they prevent the system from obtaining a good image of the apron, an alternate method for calibration can be used. The procedure is as follows:

- 1. Check the "Reduced mode" checkbox on the right side (this disables the Paint-option).
- 2. Press and hold **Ctrl** and left-click along the centreline (use reflexes while scanning the image if it is not visible). For each click, a new marker will be placed. Two markers are sufficient in most cases but if there are slopes or rises in the apron you should place one marker on each top/bottom.
 - a. When the first marker is placed, a second marker in a different colour is placed to the right. This marker shall be moved to the side as far away as possible from the centre of the image, while still being placed on an area where there is ground and within the inner and outermost marker. Again, use reflexes if needed.

4.4.2

- 3. Press the "Save Calibration" button.
- 4. Verify that the silhouette of the apron corresponds to the imaginary line between the placed markers. Only a single point will be displayed for each marker.

Note: This method cannot be used if Apron Scan is activated.

4.4.3 Feature Buttons

Apart from the button "Start Scan" and "Use Calibration" there are several buttons for this feature that can be used:

- Home can be used to send the mirrors to their home position. Used when adjusting the mirrors on their axis.
- Distance to home used to measure the distance from the mirrors current position to their home position.
- Set centre point click this, then click in the image to acquire a new image centred on the clicked point.

4.5 AUTO CALIBRATION

Auto calibration or "automatic calibration check" is a safety measure used to make sure that the hardware is OK or that the system has not been moved out of its original position since being commissioned.



FIGURE 4A.7 - SMT – AUTO CALIBRATION FEATURE

The procedure to setup the auto calibration is following:

- 1. Enter fitting values for the *Hor*, *Ver*, *Size Hor* and *Size Ver* settings so that the system looks in the desired direction.
- 2. Acquire a new image by using "Start Scan".

- 3. Find a suitable object to use as a reference for calibration. It should be a flat surface located at least 3m from the system and preferably with its edges within the view.
- 4. Press and hold **Ctrl** and left-click near the edge of the object to set the first reference point. Now press and hold **Ctrl** and right-click at another point near (but not on) the edge of the object to set the second reference point.

When the system verifies the calibration, it looks at these two reference points and compares the stored distances to the acquired ones, and if they differ more than 2dm, the system will report an error. Since it is the distance that is compared, it is important to set the reference points at different sides of the object, and even better at opposite corners if possible. If there are no edges available, the points should at least be set at different distances if possible.

You can test the calibration points using the test function on the Operator Panel once the configuration has been applied.

4.6 CENTRELINE

Here you can define the layout of each centreline by placing markers along the centreline in an image.

On the left side of this feature's window you can see the calibration image where you define your centreline area. On the right side you can see a top view of the calibration image (to the left) where any object with a height of >0.5m is displayed in red.



FIGURE 4A.8 - CENTRELINE FEATURE - DISTANCE

To define a centreline, follow the steps below:

- 1. Click on the appropriate centreline button on the right side, then press the "Edit" button.
- 2. Press and hold **Ctrl** and left-click along the centreline to place the centreline markers. If the apron is flat and the centreline is straight, two markers should be sufficient. If the centreline is curved or if the apron has slopes, place additional markers on the top/bottoms along the centreline. The closest marker should be placed at or very near the inner most stop-position and the outer most marker should be placed near the clip distance. To remove a marker, right-click on the marker and choose "Remove marker".



FIGURE 4A.9 - CENTRELINE FEATURE - AMPLITUDE

- 3. Set an appropriate "Far Clip" using the box on the right side.
- 4. Use the same approach as when placing the centreline markers as when you set the left and right clip using the top view. Clicking in the left third of the top view adds a marker to the left side clip and clicking in the right third of the top view adds a marker to the right clip. The clip markers can be moved into the middle third after they are added to either the right or the left clip. Keep in mind where the engines of the aircrafts on the current centreline will be so that you do not set the clip too tight, causing the engines to be clipped which may prevent dockings from completing.
- 5. When done, click the "Overview" button and repeat the above steps for any additional centrelines.
- 6. Use the buttons to add/remove centrelines. Up to a total of three can be configured.



4.7

APRON SCAN

Apron Scan configuration is done once for each centerline. The goal is to tell the system which area should be scanned and which should not. Please note that a proper apron scan setup can only be achieved using a high quality image (taken during the system calibration) of the area in front of the system. Images with lots of drop-outs or objects that are not normally present during docking should not be used. The procedure is as follows:

- 1. Click the button that corresponds to the centerline for which to configure apron scan.
- 2. Click the "Edit" button
- 3. Ctrl-click on the ground to the left of the image center to add the first marker.
- 4. Add a second marker to the left of the image center.
- 5. Adjust the markers so that the areas which should not be scanned are grayed out. Please take the perspective into consideration when placing the makers. You may add more markers as needed, for example to work around a stationary object, but keep in mind that the system cannot see through these objects.
- 6. Repeat step 3 for the right side of the centerline. There must be at least one marker on each side of the image center; otherwise the application will mark the apron scan setup as invalid.
- 7. Enter a far clip, i.e. the maximum distance to which the apron scan will perform the scan.



FIGURE 4A.10 - APRON SCAN FEATURE

4.8

AIRCRAFT

Here you can configure the centrelines, stop-positions and Operation Panel menu layout.

🛧 Sa	fedock Maintenance To	ol - current.scfg Site: 'Safegate' Variant: 'Example' Stand: '57'	Name and Address of Case of Street or other	-		X
File	Safedock About					
	Connection	Aircraft Mix OP Menu Create Generics Legacy A/C-id (GOS)				
	, ,	Centerlines	Aircrafts			
	Sustam		Name	Configuration	ID Legacy G	os ID 🔺
	Configuration	5/ 5/A	Airbus A300-600	A300/6	71	
	- Curtury	Stop Positions	Airbus A300-B2	A300/B2	76	
	Calibration	1 29.8 (m) 🔿 💰 🗡 💟	Airbus A300-B4	A300/B4	77	
		A330/3	Airbus A310-200	A310/2	78	
	Auto Calibration	A340/3	Airbus A310-300	A310/3	79	
	Castalia	B747/4 B777/2	Airbus A318	A318	158	
	Centerline	B777/3	Airbus A319	A319	38	
	Aircraft	B787/9	Airbus A320-100	A320/1	172	
	Alleran	3 35.3 (m) 🔊 🚄 🧪 😮	Airbus A320-200	A320/2	173	
	Rule editor		Airbus A321-100	A321/1	374	
		A330/2 B787/8	Airbus A321-200	A321/2	376	
	Password		Airbus A330-200	A330/2	116	*
	·		Generics			
	Issues		Configuration ID Legacy	Gos ID		
	Configuration					
	Applied					
	File Handler					
\bigcirc	Get logs	Add Stop Position				
	Serial number	Name				
		Distance 0				
		Delta Move / Change all				
Status	s: Disconnected					TX:ORX:O

FIGURE 4A.11 – AIRCRAFT FEATURE

On the left is where the centrelines and stop-positions are shown. The middle part displays the properties for the currently selected aircraft. On the right, the list of available aircrafts and generic aircrafts is displayed.

- Centrelines: The system supports up to three centrelines, depending on the used license.
 - Stop Positions: A visual representation of the different configured stoppositions on the currently selected centreline. The icon represents the selected stop-position reference.
 - Add Stop Position: Enter a name and a distance for a new stop-position, then press one of the three stop reference-buttons to add the new stop-position.
 - Delta Move: Opens a dialog window where you enter a distance to which all stop-positions will be adjusted by. Negative values will decrease the distance to stop-position and positive values will increase it.
- Aircraft Menu: The aircraft selection menu, as it will appear on the Operator Panel (within the unit's capabilities).
- Aircrafts: The list of available aircraft profiles.
- Generics: The list of generic aircraft profiles created by a user.

4.8.4

Changing multiple settings on multiple aircrafts

Below the centreline/stop positions, there is a button labelled "Change all...". Pressing this button brings up the dialog to change one or many settings on one or many aircrafts at the same time.

On the left the available settings are shown, on the right the available aircrafts sorted by centreline & stop position. Clicking the checkbox on the same lines as the stop position name will (de)select all aircrafts on that position.

🛧 Cha	nge Settings For Multiple Aircrat	fts						
Apply			Apply To	*				
	Too far distance 1	m (0.5-2.0)	A / A A300-600					
	Max speed 2	m/s (0.5-3.0)	A300-B2					
	Skip engine verification		A310-200					
Skip engine verification in downgrade condition								
Prefer engine-ID on bridge side								
	Use nose height clip for Capt	ture	A321-100					
	Extend ID-fail lim 0	m (0-10.0)	A321-200					
	- Stand Equipment Interlack		B747-400					
	SEO signal 1		✓ A / B					
	SEQ signal 2		A320-200					
	SEQ signal 3		B767-400					
	SEQ signal 4		☑ 8767-SP					
	Category		B 777-200					
			B777-200LR					
			B 777-300					
			B 777-300ER					
			📝 B787-3					
			📝 Dash 8 Q100					
			A/C					
			A318	•				
		Ok	Cancel					

FIGURE 4A.12 - SMT START SCREEN

To change a setting, first check the corresponding "Apply" checkbox, then set the desired value for that setting. Once all settings are as desired, select the aircrafts to which these settings should be applied. Press the Ok-button to apply, or Cancel to cancel any edits.

Settings that do not have the "Apply"-checkbox checked, are left untouched on the selected aircrafts.

4.8.1 **Aircraft Settings**

- Configuration id: The ID used to identify this specific aircraft configuration. This ID, together with the Tag (see below), makes up the unique identification value used to specify one among many instances of the same aircraft type.
- **Display Texts**
 - Operator text: The text referring to the aircraft's identity that is displayed in the Operator Panel.
 - Operator key: The text that is displayed on the Operator Panel soft key (when choosing between different aircrafts in the menu). Use the character ^ to specify a line break. Maximum ten characters (excluding a single ^).
 - Pilot display: The text that is shown on the Pilot Display when the docking is initiated and the system is waiting for an aircraft.

- Docking procedure:
 - Too far distance: The maximum distance the aircraft may have travelled past the stop-position before the system will signal a **TOO FAR** condition.
 - Max speed: The maximum speed the aircraft may approach the system with before the system signals a **SLOW** sign.
 - Skip engine verification: If checked, the engine verification is not performed for this aircraft instance.
 - Skip engine verification in downgrade condition: If checked, the engine verification is not performed for this aircraft instance during downgrade conditions.
 - Prefer engine-ID on bridge side: By default engine-ID performs the check on the side away from the bridge. Activating this option makes the system to prefer the bridge-side engine instead. This can be used if the approach is such that this option makes it easier for the system to perform the check.
 - Extend ID-fail limit: Can be used to extend with up to 10m the minimum distance to the stop-position for the activation of the **ID-FAIL** message.
- Aircraft configuration:
 - Category: Used for, among other things, Bridgeln logic. Enter one or more "categories" (separated by a comma) where the particular aircraft should be included in. These categories are then available for use in the schematics.
 - Tag: Used to make aircraft instances unique by entering one or more tags. These are used to find a specific aircraft configuration instance when dockings are started from SafeControl – Apron Management system. For example, to specify an aircraft configuration instance with winglets, "WL" (without quotes) is entered.

4.8.2 Creating a Stop Position on a Centreline

At the bottom left there are fields and buttons used to create a new stop-position on the currently selected centreline. First, enter a distance in meters, and then give it a name. Press then the stop reference button (nose, nose wheel or door) that matches your needs to create a new stop-position with the newly entered values. Following aspects are to be considered:

- Each stop position must be uniquely named, per centreline.
- There can be only one stop-position with a specific distance and reference.
- The shortest distance that is accepted is 4.0m.
- A stop-position can be adjusted individually using the "pen" button and deleted using the red "X" button. Stop reference cannot be changed.
- All stop-positions can be moved by a certain distance using the button "Delta Move". Enter a positive or a negative value to move the positions away from or closer to the system.

4.8.3 Adding an Aircraft to a Stop Position

An aircraft can be added to a stop-position by using drag-and-drop from the list of available aircrafts and generic aircrafts on the right side.

4.8.4 Modifying Content in Aircraft Menu In addition to the standard operator panel, the system also supports a 54-key extension panel. The image below shows the editor for both panels; the left side is the standard panel with the extension panel to the right. Both editors use drag-and-drop operations to place an aircrafts on the appropriate place.

Page 19 of 26

Safedock Maintenance Tool Site: 'Safegate' Variant: 'Example' Stand: 'Per'																	
File Safedock About																	
Connection + 192.168.2.60	Aircraft Mix OP Menu Create Generics Aircraft Menu	54 key la	/out					Wardenad									
System Configuration	Air^bus Air^bus Air^bus	A300-B2 A300/B2	A300-B4 A300/B4	A300-600 A300/6				A340-200(A340/2) B737-400(B737/4)									
System Calibration	□ A330-200F(A330/2F) □ A310-200(A310/2) □ A300-B4(A300/B4)	A310-200 A310/2	A330-200F A330/2F														
Auto Calibration	A300-B2(A300/B2) A300-600(A300/6)																
Centerline	▲ Boe^ing B737-200(B737/2)																
Aircraft	ft	B737-200 B737/2	8737-300 8737/3														
Rule editor																	
Issues				\square	\square	\square	\square										
Configuration Applied	ion																
File Handler																	
Get logs																	
Serial number				\square	\square												
Status: Connected		-						TX:®RX:●									

FIGURE 4A.13 – EDITOR FOR OPERATOR AND EXTENSION PANELS

4.8.4.1

4.8.5

- Customizing the menu layout on the standard panel
 - To add a folder, right-click in the Aircraft Menu window (do not mark any of the existing folders) and choose "Add folder".
 - To add an aircraft to an existing folder, drag and drop the aircraft onto the folder. If a folder is not empty, you can directly drag the item you want to move onto another item within the target folder.
 - To delete or rename an item in the list, right-click and choose "Remove" or "Rename".
 - Items in the menu can be sorted using drag-and-drop.
 - To move an item above a folder, press and hold the Shift-key first.

Customizing the Operator Panel Layout

The Aircraft Menu shows the aircraft types that will be available for direct selection from the Operator Panel. The correspondence between the two is shown in the figure below:



FIGURE 4A.14 - THE CORRESPONDENCE BETWEEN THE AIRCRAFT MENU AND OERATOR PANEL

On the Operator Panel display you can see ten items (folders/aircrafts) at a time. The first position (for the first item and the 11th item) will appear in the left lower corner and the last position (for the 10th item and 20th item) will appear in the right upper corner. There can be up to 10 pages with 10 items on each page.

4.8.6 Creating Generic Aircrafts

A generic aircraft is an aircraft that has been created from multiple aircraft types. These generics are used to group similar aircrafts into a single type. The main usage for a generic is to reduce the number of choices available for the operator when starting a docking. However, this leads to a reduced accuracy in aircraft identification.

A Safedoc	k Maintenance Too	ol Site: 'Safegate' Variant: '	Example' Stand: "						×	
File Safe	dock About									
Con	nnection	Aircraft Mix OP Menu Create Generics Legacy A/C-id (GOS)								
<u> </u>		Configuration ID	A300			 Aircrafts 				
Sys	item	ž				Name	Configuration	ID Legacy Gos	ID Â	
Cor	nfiguration	Generic legacy GOS ID	1			Airbus A300-600	A300/6 A300/82	71		
Sys	stem	Operator text	A300			Airbus A300-B2	A300/B2	77		
	Ibration				_	Airbus A310-200	A310/2	78		
Aut Aut	to Calibration	Operator key	A300			Airbus A310-300	A310/3	79		
	oterline	Pilot display	A300			Airbus A318	A318	158		
N Ca	ntenine	r liot display				Airbus A319	A319	38		
Airo	craft	Pilot display 2				Airbus A320-100	A320/1	172		
]		Use door 2 as door re	ference		Airbus A320-200	A320/2	173		
Rule	le editor				^ A	Airbus A321-100	A321/1 A321/2	3/4		
		Generic distance into	Min. door to engine	9.93 (m)	/@_ /\$ }	Airbus A321-200	A321/2 A330/2	116		
V Issu	ues		Door to engine diff.	0 (m)	- 1 ile 1	Ganica Association	A550/2		Ψ	
	ofiguration		Nose to Wheel Distance	6.67 (m)		Configuration ID Legacy	Gos ID			
App App	plied		Nose to Door Distance	5.85 (m)		A300 1				
File	Handler					A300-D2 118				
<u> </u>		Aircrafts to combine	Name	Configuration ID						
Get Cet	t logs		Airbus A300-600	A300/6						
Ser	rial number		Airbus A300-B2	A300/B2						
			Airbus A300-B4	A300/B4						
			New							
				Delete						
			con	Delete						
			Save	Cancel						
						тА	dd Legacy Generics			
Status: Disc	connected							T	X:ORX:O	

FIGURE 4A.15 - AIRCRAFT FEATURE - GENERICS

To create a generic aircraft follow the steps below:

- 1. Click on the tab "Generics" (to the right of "Aircraft") on the top left of the window.
- 2. Press "New", a dialog pops up asking for a unique configuration id.
- 3. Enter the new configuration id and click Ok. Note: this cannot be changed at a later time.
- 4. Enter the Generic Legacy GOS ID, if available for this type.
- 5. Enter operator text, key and pilot display texts.
- 6. Drag and drop the aircrafts to be included in the generic type from the list with available aircrafts to the "Aircrafts to combine" box.
- 7. If the selected aircrafts have different nose-to-nose wheel or nose-to-door distances, sliders will be shown helping to adjust these values for this generic type. To make the user aware of the fact that the difference between the door and an engine varies between the selected aircrafts, the application will mark the distance in yellow if the difference is >3m or in orange if the difference is >5m.

Note: only aircrafts with the same nose height and nose geometry can be use used. When "Use door 2 as door reference" is checked, the door-to-door-2 distance of all aircrafts must be within +/-2 dm.

8. Press the "Save" button.

You can now use the generic as any other aircraft in the "Aircraft" tab.

Page 21 of 26

4.8.6.1 Legacy Generics

In older versions of Safedock, there were several generic aircraft types that are not included in today's normal set of aircrafts. However, it may still be desirable to use those aircrafts. Therefore, they are provided via the "Add Legacy Generics" button.

Pressing this button will switch the view of the generics to a list of available generics that can be imported into the current configuration. Check those you want to import and press the "Add Selected" button. Pressing "Cancel" will bring you back to the original view without adding any generics.

Note that the list of available generics is filtered so that it only shows aircrafts which Legacy GOS Id is not already present in the configuration.

4.8.7 Legacy A/C-id (GOS)

This tab shows a list of all aircrafts (column 1) and their GOS-ids (column2) available in the old version of Safedock together with the name (column 3) of the profile in the current configuration that matches (through GOS id) and the configuration id (column 4) that goes with it.

Password

The Safedock system can be equipped to use password protection for operator and/or maintenance (remote) operations.

More specific, the system would require a four-digit password at the following commands:

- (a) Local Start of Docking (by assigning an aircraft type)
- (b) Local Park ON or Park OFF (creating Blocks On and Blocks Off transactions)
- (c) Confirmation of a Scheduled Flight Start-of-docking Command from Superior System
- (d) Aircraft Loading Bridge Lock Override (if installed)
- (e) Diagnostic Test Procedure (requires a maintenance operator password)



FIGURE 4A.16 - PASSWORD FEATURE

4.9

ISSUES

The application looks for certain conditions, such as missing and out-dated profiles, in the configuration. If any of the conditions are met, this view will present the user with an item for each detected issue.

🛧 Saf	edock Maintenance To	ol Site: 'Safegate' Variant: 'Example' Stand: '22'
File	Settings Safedock	About
	Connection	Aircraft geometry version mismatch: A318
	192.168.2.60	Aircraft geometry version mismatch: A340/3
	System	Aircraft profile version mismatch: AN225 Update
	Configuration	Aircraft profile version mismatch: BAE Update
	System	Profile missing in template data: ATR72
	Calibration	Profile missing both in template and on system: ATR72
	Auto Calibration	
	Centerline	
	Aircraft	
	Issues	
	Configuration Applied	
\bigcirc	Get logs	
Status:	Connected	TX:@RX:@

FIGURE 4A.17 - ISSUES FEATURE

There are two was to handle an issue:

- 1. By using the "Update" button. Pressing this button will update the used profile and/or aircraft data to the most recent version available.
- 2. Adjusting the configuration so that the issue conditions no longer are met, i.e. removing an aircraft.
- 3. Leave as-is, i.e. opting not to update. This does not work for issues marked with a red symbol as they must be resolved before applying a configuration.

Some issues have a disabled "Update button", meaning that the data used by the system is more recent than that available in the template data – an item can never be made to use an older version of the data.

Issues marked with a green symbol are auto-resolved by the application when the configuration is applied.

Hint: Try right-clicking on a button for an issue; some issue types may be accepted in bulk using the menu that is shown when right-clicking.

4.10 CONFIGURATION APPLIED

Here you can see the configuration history of the system, send a new configuration to the system and also set the time of the system.

To apply a new configuration, enter a comment in the upper box and press the "Apply" button. The application will then upload the configuration to the system and update its history file with the entered comment and current computer & user name.

To set the time, simply click the "Set time" button.

The system automatically saves the last five applied configurations. These can be retrieved by selecting an earlier configuration in the history and pressing the "Get previous configuration" button.

Safedock Maintenance To	ool - current.scfg Site: 'Example Airport' Variant: 'Example License' Stand: '10'
File Settings Safedock	About
Connection 192.168.2.60	Apply configuration
System Configuration	Saved as STH-PMG-W7\pm
System Calibration	A descriptive comment
Auto Calibration	Apply
Centerline	Time
Apron scan	Set time
Aircraft	Configuration Status
Password	System configuration
Issues	Date Comment Configuration baseline
Configuration Applied	Previous configurations
Get logs	Date Comment Configuration baseline
Status: Connected	

FIGURE 4A.18 - CONFIGURATION APPLIED FEATURE

4.11 GET LOGS

This view is used to select docking- and short-logs for retrieval to the local computer. You can either use standard **Ctrl** and **Shift** selection or use the quick-selection buttons to select the desired log files. Once selected press the button "Get selected files" to start the retrieval process. The logs are saved in the folder <installation dir>\Logs\<stand name>. This folder can easily be opened by pressing the button labelled "Open log directory".

The button "Create support archive" retrieves the selected logs (always at least the last two days) and also additional files. Additionally, the entire configuration is archived together with the downloaded files in a single file named <date> <time><stand name>.sarc in the same directory as the log files.

🚯 Safedock Maintenance Tool - current.scfg Site: 'Example Airport' Variant: 'Example License' Stand: '10'							
File Settings Safedock	About						
Connection	Docking lo	gs	Shor	rt logs			
192.168.2.60	20131023-134925-Pushback_CRJ	-700.pdock	2013-10-24.pbrief				
System Configuration	20131023-134747-Faiten_closh 20131023-134657-CRJ-700.pdock 20131023-134548-CRJ-700.pdock	ς ς	2013-10-23.pbner				
System Calibration	20131023-133324-Kalle.pdock 20131023-124713-CRJ-700.pdock	¢					
Auto Calibration	20131023-124219-CKJ-700.pdock 20131023-123438-CRJ-700.pdock 20131023-123301-CRJ-700.pdock	с с с					
Centerline	20131023-123157-CRJ-700.pdock 20131023-114041-A319.pdock	c					
Apron scan	20131023-112856-Kalle.pdock 20131023-112854-ParkOff_A319.	pdock					
Aircraft]						
Password]						
Issues]						
Configuration Applied]						
Get logs	Select all Selec	t none	Select all Select none				
	Last 30 days	Last 7 days	Last 2 days	Today			
	Get selected files 🕂 Create support archive Open log directory						
Status: Connected				TX:ORX:O			

FIGURE 4A.19 - GET LOGS FEATURE

4.12 UPDATING THE SYSTEM

Occasionally you may want to update the software/data files in the system. This is done through the menu option **Safedock** -> **Apply update**. When clicked, you are asked to select an update (.spkg) package provided by Safegate. Once selected, press the Open button and a message will show you the purpose of the update package and also ask for permission to continue.



FIGURE 4A.20 – VERSION UPDATE SCREEN

Press "Yes" to continue with the update and no to cancel. If you continue, the application will upload and apply the update. Please note that the system will be restarted at the end of the update, resulting in a lost connection message

Page 25 of 26

5. IMPORTING CONFIGURATIONS

5.1.1 Importing Aircraft Mix, Features and Rules

Using the menu File > Import... parts of an existing SOS configuration can be imported into the current configuration (imported items will replace existing items). This is useful when a configuration has been prepared beforehand.

When used, a dialog box is presented, asking for the source configuration. When selected, more options appear.

Select those items that are to be replaced in the current configuration.



FIGURE 4A.21 – IMPORT CONFIGURATION

When importing the aircraft mix, you have to select which centerline the source items are to be put on. When there are more centerlines in the source than the current configuration, an option "*new*" gets available in the drop down box. This allows you to add new centrelines but the total number cannot exceed three.

5.1.2 Importing Legacy Configuration

Using the menu File > Import Legacy Configuration, a configuration from an older Safedock can be imported. The items that are imported are aircrafts, stop positions and operator menu (menu-based version only).

The behaviour for creations of new centerlines are the same as when importing a modern configuration.

Import Legacy Configuration					
Gate Configuration:	D:\Temp\243L.GTE				
Menu File:	D:\Temp\243L.cfg				
Source centerline T A	arget centerline T	Cancel	Ok		

FIGURE 4A.22 – IMPORT LEGACY CONFIGURATION

When the configuration has been selected, the application will search for a matching menu file and if found, ask if it shall be used as a source for the import. If no match is found, you can select one manually.

Upon completion, a message informing of the result is displayed.

CHAPTER 4 MAINTENANCE - APPENDIX B SAFEDOCK LOG VIEWER CONTENTS

Section	Description	Page No.
1.	INTRODUCTION	3
2.	OVERVIEW	3
3.	DOCKING VIEW	4
3.1	DOCKING VIEW	4
3.2	EVENT INDICATOR	5
3.3	MIMIC PANEL	5
4.	SHORT LOG VIEW	6



Note: This page is blank for convenient double-sided printing.

1. INTRODUCTION

The Safedock Log Viewer (SLV) is a tool that can be used to explore the content of log files from the Safedock system.

SLV can be used to view both Safedock docking logs from individual docking operations and event logs from the system.

2. OVERVIEW

The SLV tool consists of 3 views: two at the upper side and one at the bottom side. The upper side includes:

- Docking view a graphical representation of a docking procedure, with important events highlighted.
- Short log view a text representation of events from a docking operation or from the system, depending of what type of file is currently active.

The bottom side includes a mimic of the Pilot Display and a set of buttons that can be used to navigate through events in the docking view.

💫 Safedock L	og Viewer	 	 -		X
File About	_				
Docking view	Short log view				
				First	Levet
			Offset: 0	FIFSt	Last
			Dist: 0	Previous	Next



3. DOCKING VIEW

The docking view is a graphical representation of the docking procedure.

3.1 DOCKING VIEW

In the docking view, each capture and tracking activity is represented in a range bar with events. Each range bar starts with a time field where the upper time indication shows when capture was achieved, and the lower time indication shows when the tracking was ended.

Between the time markers there is a track selection button. If there are multiple tracks, this button can be used to position the mimic panel to the beginning of the desired track.

Each range bar has a distance scale that indicates the distance from the Safedock to the tracked object. The distances are indicated in meters.



The range bar includes a tracking indicator. This is a multi-colored bar that represents the position of a tracked object. The color indicates the state of the tracking procedure for that distance. The color indications are:

- Orange Acquisition phase. Tracking but no guidance given.
- Yellow Early Guidance phase. Tracking and giving active guidance. Object not verified.
- Green Late Guidance phase. Tracking and giving active guidance. The object has been verified as a good match for the selected aircraft type.
- Red Stop indication given to pilot.

Together with the tracking indicator one can also see a position track, which is a line that indicates the tracked objects sideways position relative to the configured centreline. The edge of the tracking indicator represents an offset of 0.5m from the centreline.
3.2 EVENT INDICATOR

Special events that occur during the tracking will be marked with 'balloons' surrounding the track. Specific information about the event can be seen as a 'tooltip' by placing the mouse cursor over the balloon.



3.3 MIMIC PANEL

The mimic panel is located below the docking track view, and can be used to step through the track data to examine individual steps of the docking procedure. It consists of a view of the Pilot Display and a set of buttons to step through the track data.

The tracks in the docking view will show a cursor formed by two opposing vertical arrows connected by a line. This cursor indicates the tracker position that is presented in the mimic panel.

The mimic panel will indicate what information was presented to the pilot at each given instance of the docking procedure. This includes: information messages, offset from the centreline and distance to go to the configured stop position.

4. SHORT LOG VIEW

The short log view is a textual representation of all the major events that occur in a docking operation.

Each line in the shortlog represents a specific event, with timestamp.

A Safedock Log Viewer	
File About	
Docking view Short log view	
=== 20130924-071015-A380-800.pdock === 07:10:15 [Docking] Dock A380-800 07:12:00 [Docking] Lead-in @90m 07:12:02 [Docking] Identified @87m 07:12:08 [Docking] Steed 4.0m/s 48m to go 07:12:39 [Docking] Stop @20m 07:12:45 [Docking] Stop @20m 07:12:50 [Docking] System idle	
	First Last
Offse Dist	t: 0 Previous Next
20130924-071015-A380-800.pdock	

SAFEDOCK DRAWINGS LIST

Drawing Title	Drawing Number
590131 - Stepper Motor Card	*SG590131-001-01_RVB
590137 - Temperature Card, COMPONENT AND PARTS LIST	SG590137-000_RVB
590222 - Cable Entry Cover Plate (3 hole) ASSEMBLY	SG590222-001-01
590222 - Cable Entry Cover Plate	SG590222-201-01
590222 - Cable Entry Cover Plate (3 hole with gasket)	SG590222-202-01
590253 – Safedock T1 Cabinet	SG590253-002-01_RVB
590253 – Safedock T1S Cabinet	SG590253-219-01_RVB
590255 - HEATER	SG590255-106-01_RVA
590255 - LIGHT SENSOR ASSEMBLY	SG590255-108-01_RVB
590255 – COMMUNICATION CABLE	SG590255-109-01_RVB
590255 – SCANNING MOTOR	SG590255-111-01
590255 – OPTICAL ENCODER CABLE	*SG590255-112-01_RVC
590255 – LASER RANGE FINDER ASSEMBLY	SG590255-113-01_RVE
590255 – Adapter Scanning Motor	SG590255-116-01_RVA
590255 – Standard Cooling Assembly for T1/T1S	SG590255-200-01_RVA
590256 - T1 Display 42 CARD	SG590256-001-01_RVA
590258 – PATCH CABLE	*SG590258-101-01_RVC
590259 - T1 Supercooler	SG590259-001-01_RVC
590261 - T1 Installation Hardware	SG590261-001-01
590263 – X3 Terminal Block	SG590263-001-01_RVE
590264 - T1 Ventilation Assm	SG590264-100-01_RVC
590264 – T1 Ventilation Filter Assm	SG590264-101-01_RVA
590264 – Filter Adapter Plate	SG590264-200-01_RVA
590266 - Utility Outlet	*SG590266-001-01_RVA
590268 – CONTROL CABLE	SG590268-101-01
590268 – CONTROL CABLE	SG590268-102-01
590268 – CONTROL CABLE	SG590268-103-01
590268 – POWER CABLE	SG590268-111-01
590281 - Cabinet, T2	SG590281-001-01
590360 - Cabinet, T3	SG590360-001-01
590399 - CU Replacement Kit	SG590399-001-01
590405 - Laser Cooling Fan COMPONENT PART LIST	SG590405-000-01_RVD
590405 - Laser Cooling Fan	SG590405-001-01_RVC
590405 - BRACKET	SG590405-200-01
590479 - Ventilation Fan, T2 & T3 COMPONENT PART LIST	*SG590479-001-01_RVE
590486 - Defroster Assembly, T2-T3 COMPONENT PART LIST	SG590486-000-01_RVA
590486 - Defroster Assembly, T2-T3	SG590486-001-01



Page 1 of 1

Drawing Title	Drawing Number
590487 - Calibration Mirror	SG590487-001-01_RVA
590495 - Soft Key Operator Panel COMPONENT PART LIST	SG590495-010-01_RVG
590495 - Soft Key Operator Panel ASSEMBLY CONNECTION	SG590495-011-01_RVD
590495 - Soft Key Operator Panel INSTALLATION	SG590495-015-01_RVE
590512 - Scanner Heating Element	SG590512-001-01_RVA
590525 - Softkey OP-Panel with Deadman COMPONENT PART	SG590525-000-01_RVB
590525 - Softkey OP-Panel with Deadman ASSEMBLY	SG590525-001-01_RVB
590525 - Softkey OP-Panel with Deadman INSTALLATION	SG590525-005-01_RVB
590543 - Supercooler, T2	*SG590543-001-01_RVD
590543 – COOLING UNIT	SG590543-100-01_RVC
590543 – COOLING UNIT COMPONENT PART LIST	SG590543-100-02_RVB
590543 - Supercooler, COVER	SG590543-200-01_RVB
590543 - Supercooler, GASKET	SG590543-201-01_RVA
590543 - Supercooler, FILTER	SG590543-202-01
590553 - Supercooler, T3	*SG590553-001-01_RVC
590553 - COOLING UNIT	SG590553-100-01
590553 - COOLING UNIT COMPONENT PART LIST	SG590553-100-02
590553 - Supercooler, COVER	SG590553-200-01_RVA
590553 - Supercooler, GASKET	SG590553-201-01
590553 - Supercooler, FILTER	SG590553-202-01
590559 - Scanning Assembly, T2-T3 Heated COMPONENT PART	*SG590559-000-01_RVB
590559 - Scanning Assembly, T2-T3 CONNECTION	*SG590559-001-01_RVA
590559 - Scanning Assembly, T2-T3	*SG590559-004-01_RVA
590559 - Scanning MOTOR	*SG590559-101-01_RVA
590559 – OPTICAL ENCODER CABLE	*SG590559-201-01.RVA
590560 - Scanning Assembly, T2-T3 Non-heated COMPONENT	*SG590560-000-01_RVB
590560 - Scanning Assembly	*SG590560-001-01_RVA
590606 - Gate Sign, T1	SG590606-001-01
590606 - Gate Sign, T1 CONNECTION	SG590606-004-01
590606 - Gate Sign, T1 REFLECTOR MOUNTING PLATE	SG590606-200-01_RVA
590606 - Gate Sign, T1 LAMP HOLDER BRACKET	SG590606-201-01
590606 - Gate Sign, T1 CABINET	SG590606-202-01
590606 - Gate Sign, T1 REFLECTOR LAMP ASSEMBLY	SG590606-203-01
590606 - Gate Sign, T1 REFLECTOR LAMP ASSY CONNECTION	SG590606-203-02
590611 - Network Switch, 4x RJ45 & 1x ST	*SG590611-001-01_RVE
590616 - Heater LED Display	*SG590616-001-01_RVD
590619 - T2 Display gen.2	*SG590619-001-01_PC
590619 - T2 Display gen.2 LIGHT SENSOR ASSEMBLY	*SG590619-101-01
590619 - T2 Display gen.2 MOUNTING PLATE	*SG590619-200-01_PA
590620 - T3 Display gen.2	*SG590620-001-01_PE
590620 - T3 Display gen.2 MOUNTING PLATE	*SG590620-200-01_PA

Drawing Title	Drawing Number
590621 - Control & Power Assembly	*SG590621-001-01_RVU
590621 – DGS Connection Diagram	SG590621-004-01_RVO
590621 – DGS Connection Diagram (Options)	SG590621-004-02_RVO
590621 – CONTROL CABLE VERTICAL SCANNING MOTOR	*SG590621-101-01
590621 – CONTROL CABLE HORIZONTAL SCANNING MOTOR	*SG590621-102-01
590621 – CONTROL CABLE LASER RF - TEMP SENSOR	*SG590621-103-01
590621 – POWER CABLE DEFROSTER/HEATER/LASER COOL	*SG590621-104-01
590621 – POWER CABLE WIRING ASSEMBLY	*SG590621-105-01
590621 – POWER CABLE WIRING ASSEMBLY	*SG590621-106-01
590621 – POWER CABLE WIRING ASSEMBLY	*SG590621-107-01
590621 – POWER CABLE WIRING ASSEMBLY	*SG590621-108-01_RVC
590621 – POWER CABLE WIRING ASSEMBLY	*SG590621-110-01
590621 – WIRING ASSEMBLY DISPLAY POWER	*SG590621-112-01
590621 – WIRING ASSEMBLY DISPLAY POWER T1/T2	*SG590621-113-01
590621 – COMMUNICATION CABLE LED DISPLAY	*SG590621-114-01
590621 – WIRING ASSEMBLY	*SG590621-115-01
590621 – CONTROL CABLE	*SG590621-116-01
590621 – CONTROL CABLE HORIZONTAL SCANNING MOTOR T1	*SG590621-117-01
590621 – CONTROL CABLE LASER T1	*SG590621-118-01_RVC
590621 – COMMUNICATION CABLE LED DISPLAY T2/T3	*SG590621-119-01
590621 – WIRING ASSEMBLY	*SG590621-120-01
590621 – Control Cable C1, T1	SG590621-125-01_RVA
590621 – Control Cable C2, T1	SG590621-126-01_RVA
590621 – Multi Cable C21, T1	SG590621-127-01_RVA
590621 – Multi Cable C23, T1S	SG590621-128-01_RVA
590621 – Multi Cable C24, T1S	SG590621-129-01_RVA
590621 – Control Cable C25, T1S	SG590621-130-01_RVA
590621 – Control Cable C26, T1S	SG590621-131-01_RVA
590621 – Power Cable, T1/T1S	SG590621-132-01_RVA
590621 – MOUNTING PLATE	*SG590621-203-01_PA
590621 – LABEL CU BOARD LED	*SG590621-205-01
590623 – COMMUNICATION ASSEMBLY I/O MODULE	SG590623-001-01_RVC
590626 – X9 Terminal Block	SG590626-001-01_RVA
590980 - T1 Assembly	*SG590980-001-01_RVE
590981 – T1S Assembly	SG590981-001-01_RVD

Drawing Title	Drawing Number
590982 - T2 Assembly	*SG590982-001-01_RVE
590984 - T3 Assembly	*SG590984-001-01_RVE

Drawing Title Drawing Nur						
ACCESSORIES						
590221 - U-CLAMP AND FASTENERS FOR Ø139.7 MM POLE	SG590221-001-01					
590353 - SDK3 INSTALLATION HARDWARE FOR Ø143 MM POLE	SG590353-001-01					
590353 - CLAMP FOR Ø143 MM POLE	SG590353-201-01					
590354 - SDK3 INSTALLATION HARDWARE T3 FOR Ø275 MM POLE - SUN SHADE PANELS	SG590354-001-01					
590354 - CLAMP FOR Ø275 MM POLE	SG590354-201-01					
590354 - UPPER TILT BRACKET FOR Ø275 MM POLE	SG590354-202-01					
590354 - PROFILE	SG590354-203-01					
590354 - BRACE	SG590354-204-01					
590354 - LOWER TILT BRACKET FOR Ø275 MM POLE	SG590354-205-01					
590355 - SUPPORT FIXTURE ASSEMBLY	SG590355-001-01					
590355 - SUPPORT FIXTURE	SG590355-201-01					
590355 – CROSS MEMBER	SG590355-202-01					
590355 - U-CLAMP	SG590355-203-01					
590356 - SDK3 INSTALLATION HARDWARE FOR Ø139.7 MM - SUN SHADE PANELS	SG590356-001-01					
590483 - INSTALLATION HARDWARE, T2-T3 ON Ø140 MM POLE	SG590483-001-01					
590496 - CALIBRATION TARGET	SG590496-001-01					
590507 - USB MAINTENANCE INTERFACE	SG590507-001-01					
590507 - MAINTENANCE INTERFACE CABLE	SG590507-100-01_RVA					
590515 – LOWER TILT BRACKET	SG590515-204-01					
590515 – UPPER TILT BRACKET	SG590515-211-01					
590515 – PROFILE	SG590515-212-01					
590515 – BRACE	SG590515-213-01					
590533 - CENTERLINE TARGET	SG590533-001-01_RVA					
590533 - TARGET ANGLE	SG590533-200-01					
590547 - CAMERA MOUNTING ASSEMBLY	SG590547-001-01					
590547 - CAMERA MOUNTING BRACKET	SG590547-200-01					
590547 - RAIL	SG590547-201-01					
590547 - PLATE	SG590547-202-01					
590547 – EXTERNAL CAMERA INSTALLATION	SG590547-203-01					
590556 - SDK SUPPORT FOR WIBE MAST	SG590556-001-01					
590556 - CROSS MEMBER	SG590556-201-01					
590556 - CLAMP PLATE	SG590556-202-01					



Drawing Title	Drawing Number
590557 - U-CLAMP FOR Ø100 MM PIPE	SG590557-001-01
590561 - U-CLAMP FOR Ø214 MM PIPE	SG590561-001-01
590595 - U-CLAMP – FOR Ø6 IN PIPE	SG590595-001-01

toring	stitu Dae enistina (D-sinae	Description No.	Cofeeste Dreduct No	Manufactured's Dart No	Manufashuna	Cunneliante Charle Number	Cumpline	
	STEPPER MOTOR DRIVE CIRCUIT, EDM-453			EDM-452-00	PORTESCAP, SWITZERLAND	EDM-452-00	API PORTESCAP SCANDINAVIA	AB, SWEDEN
						NOTE: SWITCHES I & S I = 9 S = E		
					CAECATE /	Unless otherwise indit tolerances are accord	cated, all ding to	Sharp Edges
					SAFEGALE	Surface Coating		Weight
					Safegate International AB MALMÖ, SWEDEN	STEPPER M FOR SCANNING M	OTOR DRIVER CIRCUIT 10TORS	
	B DIP-switch settings shown graphically	20	<u> </u>		Drawn by: Date drawn: Checked by:	<u>+</u>		
	A Parts List updated	20	02.05.08 G.O.		App. by: Date approved: Project No:	Drawing No.	Rev. Sheet	Scale
	Revision Description	Date	Drawn by:	Checked by: Approved	· · · · · · · · · · · · · · · · · · ·	<u>SG590131-</u>	-001-01 B 1 of 1	1:-

SG5	901	37-000					DE	EROSTER ASSEMBLY
							REVISIONS B. File format changed from the change of the ch	om dwg to xls: R1 alternative resistor added :-26
ASSMBLY LE	VEL DOCL	UMENT LIST						
SG590137-000.xls GERBER_SG5901: PCB_SG590137-10 SCH_SG590137-10 SG590137-100_R1. SG590137-100_R1.	37-100-R1.zip 0-REV1.pdf 0-REV1.pdf pcb sch	PARTS LIST GERBER FILE PCB FILE SCHEMATIC FILE						
COMPONENT	AND PAR	TS LIST						
POSITION	QUANTIT	TY DESCRIPTION/RATINGS	DRAWING NO.	SAFEGATE PROD. NO	D. MANU. PART NO.	MANUFACTURER	SUPPLIER'S. PART NO.	
	~	PRINTED CIRCUIT BOARD	SG590137-100					
B1	.	JUMPER						
B2	-	JUMPER						
C1	-	CAPACITOR, POLYESTER, 0.1 µF, 63 V					511012	BEJOKEN
C2	-	CAPACITOR, TANTAL, 47 µF, 10 V					67-762-15	ELFA
11	-	CONNECTOR			MSTB2,5/4-5,08	PHOENIX CONTACT		
R1	-	RESISTOR, 1.2 kOhm, ±1 %, alt. 1.21 kOhm						
R2-R4	ю	RESISTOR, 5,1 kOhm, ±1 %						
R5	-	RESISTOR, 3.3 kOhm, ±1 %						
R6	-	RESISTOR, 2.2 kOhm ±1 %						
U1	-	DIGITAL THERMOMETER AND THERMOSTAT						
							_	



LY COVER PLATE	AND, RUTAB EMC PERFECT RUTAB EMC, M20 AND, RUTAB EMC EEX II TAB FMC M12	
Description/Ratings CABLE ENTR	CABLE GLA JAM NUT, F CABLE GLA	
Quantity 1	1 2 2	
tem -	۲ م	







-GASKET, FERMAPOR K31. Height=4mm, Width=8mm.



						Sheet	1(1)
					3 holes)	Size	A2
	A H14	Info			Cover Plate (;	Scale	1,000
Surface treatment RAL 9005	Basic material EN AW 1050	€ [Description		Cable Entry (Rev.	
		G R O U P	Date drawn:	2013-12-19	Date approved:	Drawing No.	SG590222-202-01
	THORN	Airheid Lighting	Drawn by:	K JOHANSSON	Approved by:	Project No.	
							Issue text
							Issue checked by
							Issue by
	-						Issue date

sue No.

Gen.



								Sheet	1(1)
								Size	A1
Surface treatment	Basic material	Info)]	Description	CAEEDOCK T1			Rev. Scale	В
		G R O U P		Date drawn:	2008-05-27	Date approved:		Drawing No.	SG590253-002-01
		Arried Lighting		Drawn by:	<u> </u>	Approved hv.		Project No.	
							Drawing updated with new T1 Cabinet and additional dimensions.	Dimensions for the slots on the back of the cabinet added.	Issue text
									Issue checked by
							V.N.	K.J.	Issue by
							2014-10-01	2013-06-26	Issue date
							В	A	ssue No.











							Sheet	1(1
					ABINET		Size	A1
		Info			CK T S C	, - - -	Scale	
Surface treatment	Basic material	Ę)	Description	SAFFDC) 	Rev.	В
		G R O U P		Date drawn:	2013-10-23	Date approved:	Drawing No.	SG590253-219-01
		Airlinka Lighting	ARRANGE I	Drawn by:	A.O.	Approved by:	Project No.	
							Drawing updated with new T1S Cabinet and additional dimensions.	checked by Issue text
							N	sue by Issue
							_	ls













er Sundjør	0EM ELECTRONICS		ELFA	ELFA	ELFA	WEIDMÜLLER			ise indicated, all $SO-2768-C$ Sharp Edges e according to $SO-2768-C$ $R = 0.5$ ing			255-106-01 Rev. Sheet Scale
unnlier's Stock Numb			522909	522925	+822909	902606000			Unless otherv tolerances ar Surface Coat	HEATER		Drawing No. SG590,
Manufacturer	DBK	PHOENIX CONTACT	ALPHA WIRE 5	ALPHA WIRE 5	7	6	PARTEX		SAFEGATE	G R O U P Safegate International AB MALMÖ, SWEDEN	awn by: Date drawn: Checked by:	pp. by: Date approved: Project No.:
or's Part No		19	BLACK	RED							20	by: Approved
No Manufactur		17570	3053 E	3053 F			PA02					.O. swn by: Checked t
the Description/Batime Safenate Product N	HEATER, CIRRUS C40/1-60W-24V-DC-24V-0-0-1-0	CONNECTOR, MSTB 2,5/2-ST-5,08	ELECTRICAL WIRE, UL1007/1569, BLACK, AWG 20	ELECTRICAL WIRE, UL1007/1569, RED, AWG 20	BUTT SPLICE, SK1525	BOOTLACE FERRUL, H 0.5/14	WIRE MARKERS, NUMBERING ACCORDING TO ILLUSTRATION	100 100 100 100 100 100 100 100				A WIRE NUMBER 85-21 CHANGED TO 85 2008-05-23 G.(Revision Description Date Date Drave
ltem Dilar		2 1		4	5 2	6 2	L					



POS	QTY DESCRIPTION	STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
-	1 CABLE, LIVY, 3x0.34 mm ² , L=800 mm	Standard	T1/T1S				7852030	NOVUM
2	1 CONTACT	Standard	T1/T1S		0-925366-3	AMP, USA		
3	1 LIGHT SENSOR	Standard	T1/T1S		TSL235R	TAOS, USA		
4	3 CRIMP TERMINALS	Standard	T1/T1S		1-141708-1	AMP, USA		
5	3 CRIMP TERMINALS, H 0.34/12	Standard	T1/T1S		9025790000	WEIDMÜLLER		
9	2 SHRINK WRAP, L=20 mm	Standard	T1/T1S				55-070-25	ELFA
7	WIRE MARKERS, NUMBERING AS SHOWN ON ILLUSTRATION	Standard	T1/T1S		PA02	PARTEX		



							Sheet	1(1)
				SSEMBLY			Size	A3
	Info			ENSOR A		[1S	Scale	1,500
Basic material	¢	€]	Description	LIGHT S))	K16, T1/	Rev.	В
	SAFEGATE		Date drawn:	ZUU8-U3-13	Date approved:		Drawing No.	SG590255-108-01
	THORN Airfield Ugining		Drawn by:	G.U.	Approved by:		Project No.	
						Cable updated to fit new T1 Cabinet.	Item 1 changed, valid for both T1 and T1 Split.	lssue text
								Issue checked by
						V.N.	A.S.	Issue by
						2014-09-30	2012-04-03	Issue date
			1	í I	- 1			1

	В	A	ev.
			Re

POS QTY	DESCRIPTION	STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
-	CABLE, LIVY, 4x0.34 mm ² , L=800 mm	Standard	T1/T1S					
2 2	SHRINK WRAP, L=20 mm	Standard	T1/T1S				55-070-25	ELFA
3 8	BOOTLACE FERRULE, H0.34/12	Standard	T1/T1S				9025790000	WEIDMÜLLER
4	WIRE MARKERS, NUMBERING AS SHOWN ON ILLUSTRATION	Standard	T1/T1S		PA02	PARTEX		



									[1/T1S	Sheet	1(1)
							MBI Y		SENSOR, 1	Size	A3
				Info			R ASSF		RATURE S	Scale	1,000
Gen. tolerance	Surface treatment	Basic material		¢	€]	Description	C20 CAF		TEMPER	Rev.	В
						Date drawn:	2008-03-15	Date approved:		Drawing No.	SG590255-109-01
			THORN	Airfield Ughting		Drawn by:	G.O.	Approved by:		Project No.	
									Cable updated to fit new T1 Cabinet.	Item 1 changed, now valid for both T1 and T1 Split.	Issue text
											Issue checked by
									V.N.	A.S.	Issue by
									2014-09-30	2012-04-03	Issue date
									В	A	Rev.

							Sharp Edges	Weight	_	Choot Cont	ev. sneer scale
ack Number Sumplier			45 ELFA	33 ELFA	22 ELFA		otherwise indicated, all ces are according to	e Coating	NNING MOTOR		90255-111-01 Ke
Sumplier's St			44500	44504	7/0644		Unless toleran	GATE Surface	ational AB SCA	hecked by:	roject No.: Urawin SG5
Manufarturer			AMP	AMP	AMP			SAFE	G R O Safegate Intern MALMÖ, SW	Drawn by: Date drawn: C G.O. 2008.09.30	App. by: Uate approved: P
sfenate Product No Manufactureer's Part No	014800002 ESCAP		182642-1	182655-1	1-000501	MOTOR					Drawn by: Checked by: Approv
Draving No.	2	SG590255-112-01				IRES					Date
	T0R, P850	ODER CABLE	CKET CONTACTS	> WITH STRAIN RELIEF	PLA I EU	PIN NUMBER ASSIGNMENT FOR W BROWN (PIN 1) BROWN (PIN 1) RED (PIN 3) RED/WHITE (PIN 4) ORANGE (PIN 5) ORANGE (PIN 5) YELLOW (PIN 7) YELLOW (PIN 9)	YELLOW (PIN 10) GREEN (PIN 11) GDAY (DIN 12)	WHITE (PIN 13)			Description
Quantity Description/Pations	1 STEPPER MOT	1 OPTICAL ENCC	1 PLUG FOR SOU	1 CABLE CLAMP	13 SULKEI, IIN F	PLUG FOR SOCKET CONTACTS					Revision
met		2		1	_ _						

Supplier's Stock Number Supplier			Unless otherwise indicated, all toless otherwise indicated, all SU-2768-C Sharp Edge tolerances are according to Solution Surface Coating Weight OPTICAL ENCODER CABLE T1 Meight			Drawing No. Rev. Sheet Scale
e Product No. Manufacturer's Part No. Manufacturer 0–925366–5 AMP 1 11.1708 1 AMD	1-141/08-1 AMP	52 The second s	SAFEGATE G R O U P Safegate International AB	23 A.S MALMÖ, SWEDEN	20 A.S T G.O. DY: Uate drawn: LINECKED DY: C H	25 A.S App. by: Date approved: Project No.
Urawing No.		BROV BROV		2012.01.2	2012.01.20	2010.05.2
	E			or cable updated	d drawing changed	ble length added drawing number added



ltem	Quantity	Description/Ratings
ļ	l	LASER RANGE FINDER
2	Ļ	PLUG FOR SOCKET CONTACTS
3	l	CABLE CLAMP WITH STRAIN RELIEF
4	9	SOCKET, TIN PLATED
2	l	CABLE LENGTH 300mm
9	ļ	GROUND CABLE

		50					
TECHNOTRADE	21302G			T1/T1S		LABEL, YELLOW, Text: H, 15x8	12 1
TECHNOTRADE	21302G			T1/T1S		LABEL, YELLOW, Text: V, 15x8	11 1
		PARTEX	PA02	T1/T1S		WIRE MARKERS, NUMBERING AS SHOWN ON ILLUSTRATION	10
WEIDMULLER	9026090000			T1/T1S		BOOTLACE FERRULE, h1.5/14	9 2
WEIDMULLER	9025780000			T1/T1S		BOOTLACE FERRULE, h0.12/12	8 26
		PHOENIX CONTACT	1786336	T1/T1S		CONNECTOR, IC2.5/18-ST-5.08	7 1
		PHOENIX CONTACT	1786255	T1/T1S		CONNECTOR, IC2.5/10-ST-5.08	6 1
ELFA, SWEDEN	55-062-09	ALPHA WIRE	FIT-300-3/4	T1/T1S		HEAT SHRINKABLE TUBING, Ø9.5, BLACK	5 2
		TE CONNECTIVITY	182655-1	T1/T1S		CABLE CLAMP WITH STRAIN RELIEF	4
		TE CONNECTIVITY	163086-1	T1/T1S		PIN CONTACT	3 26
		TE CONNECTIVITY	183077-1	T1/T1S		RECEPTICLE FOR PIN CONTACTS	2 2
				T1/T1S		CABLE, LIYCY, 13x0.25, L=200 (It is ok to use a standard cable with more wires)	7
SUPPLIER	SUPPLIER'S STOCK NUMBER	MANUFACTURER	MANUFACTURER'S PART NO.	SAFEGATE PRODUCT NO.	DRAWING NO.	DESCRIPTION/RATINGS	ітем ату



NNING MOTOR	WIRE NUMBER	59	60	61	62	63	64	65	66	67	68	69	20	71
VERTICAL SCA	PIN NUMBER	1	2	3	4	5	6	7	8	6	10	11	12	13

ANNING MOTOR	WIRE NUMBER	72	73	74	75	76	77	78	79	80	81	82	83	
HORIZONTAL SC	PIN NUMBER	-	2	с	4	5	9	7	8	6	10	11	12	

			201	Issue date
			А	Rev.

	STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
	Standard	T1/T1S		CTA305-0005-02	MARLOW INDUSTRIES INC		
	Standard	T1/T1S		9019120000	WEIDMÜLLER		
22	Standard	T1/T1S					
	Standard	T1/T1S					
	Standard	T1/T1S					



COMPONENT PLACEMENT IN DOCKING GUIDANCE UNIT PARTIAL FRON VIEW, DOOR REMOVED

USE CABLE TIES TO SECURE THE CABLES INSIDE SCANNER COMPARTMENT. PLACE COMPONENT IDENTIFIER LABEL ON THE BACK OF THE WALL, ABOVE COMPONENT. NOTE:

Gen. tole

naterial	∏ ⊕ Info		ANDARD COOLING ASSEMBLY	R T1/T1S	Scale Size Sheet	A 0,500 A1 1(1)
Basic	COATE A		2	<u>O</u> L	Rev.	5-200-01
	SAFE 6 2	Date drawn:	ZU 14-U3-1	Date approved	Drawing No.	SG59025
FOCUL		Drawn by:		Approved by:	Project No.	
						Issue text
						Issue checked by
						Issue by
						ssue date













141 142

ssue No.







Dra	wing No. Safegate Product No.	Manufacturer's Part No.	Manufacturer	Supplier's Stock Number	Supplier	
= 800		AA-100-24-23-00-10	LAIRU IELHNULUGIES, SWEDEN	55-609-25	ELFA AB, SWEDEN	
= 1420				55-609-25 1757019	ELFA AB, SWEDEN PHOENIX CONTACT, SW	/EDEN
		PA02	PARTEX, SWEDEN	9026070000	WEIDMÜLLER, SWEDEN	
JW, 15×8mm, TEXT: K73				55-028-10, SEE NOTE 2 21302G	ELFA, SWEDEN TECHNOTRADE SCANDINAN	/IA AB, SWEDEN
NOTE 2: STOCK REFERS TO A P 1000 PIECES.	NUMBER ACKAGE OF			DZACIZ	IELTINUIKADE SLANDINAN	VIA AD, SWEDEN
	WHEN THE CC THEIR TERMIN (K73) 7 CABLES SHOL	IOLING UNITS ARE INS IAL BLOCKS FOR THE JLD LOCATED TOWAR JET	STALLED, POWER RD THE BACK (K74, 8)			
•		•				
	COMPONE DOCKING PARTIAL DOOF	F PLACEMENT IN GUIDANCE UNIT FRONT VIEW, REMOVED				
DOCKING GUIE	ANCE UNIT 91(BROWN) 92 (BLUE) 93 (BROWN) 93 (BROWN) 94 (BLUE)	(BROWN) (BROWN	91 92 1 1 1 1 1 1 1 1 1 1 1 1 1			
	CONNEC	TION DIAGRAM				
			SAFEGATE	Unless otherwise indicat tolerances are according Surface Coating	ed, all to EMBLY	Sharp Edges Weight
inection diagram changed, note for cooling u	nit installation added 2008.07.02 G.O. Date Drawn by:	Draw G.O. Checked by: Approved	Safegate International AB MALMÖ, SWEDEN vn by: Date drawn: by: Date approved: Project No.:	FOR T1 Drawing No. SG590259-(01-01 Rev. Sheel	t Scale of 1 1:2



NOTE 1: PLACE IDENTIFIER LABELS ON BACK WALL OF CABINET UNDER RESPECTIVE UNIT.



A Wire numbering changed for K74; con Revision Description

	STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
	Standard	T1/T1S		CTA305-0004-02	MARLOW INDUSTRIES INC.		
	Standard	T1/T1S		CTA305-0004-02	MARLOW INDUSTRIES INC.		
	Standard	T1/T1S		9019120000	WEIDMÜLLER		
8	Standard	T1/T1S					
6	Standard	T1/T1S					
	Standard	T1/T1S					
	Standard	T1/T1S					



COMPONENT PLACEMENT IN DOCKING GUIDANCE UNIT PARTIAL FRONT VIEW, DOOR REMOVED

NOTE:

USE CABLE TIES TO SECURE THE CABLES INSIDE SCANNER COMPARTMENT PLACE COMPONENT IDENTIFIER LABELS ON THE BACK OF THE WALL, ABOVE COMPONENTS.

Gen. tol

								Sheet	1(1)
								Size	A1
		Info			ED COOI		L1S	Scale	0,500
Surface treatment	Basic material		9	Description			FOR T1/	Rev.	C
		SAFEGATE		Date drawn:	NZ-CU-80UZ	Date approved:		Drawing No.	SG590259-001-01
		Airfield Lighting	Monor	Drawn by:	e.C.	Approved by:		Project No.	
							Drawing updated with new TECs - K78, K79	Wire numbering changed for K73 and K74.	Issue text
									Issue checked by
							V.N.	A.S.	Issue by
							2014-09-16	2012-10-05	ssue date









Wire no's 144 144

143 143 RED K79 (FAN +) RED K78 (FAN +)

145 146 141 142 BLUE K79 (TEC -) WHITE K78 (TEC +) BLUE K78 (TEC -)

B B Ssue No.



ltem	Quantity	Description/Ratings	Drawing No.	Safegate Product No.	Manufacturer's Part No.	Manufacturer	Supplier's Stock Number	Supplier
<u></u>	<u> </u>	COVER PLATE (DELIVERED AS PART OF CABINET ASSEMBLY)	NPP 913798					
2	2	CLAMP	AT 605283					
<u>~</u>	4	T-BOLT AND NUT, HS 50/30 - fv - M12 x 40			12-1769	HALFAN, GERMANY		SIFVERT SKRUV, SWEDEN
4	4	NUT, ISO 4032, M12, GALVANIZED						
5	4	WASHER, DIN 125 13x24x2.5, GALVANIZED						
9	2	CABLE GLAND, RUTAB EMC PERFECT			50.620M/EMV	RUTAB, SWEDEN	1476023	AHL SELL, SWEDEN
L	2	JAM NUT, RUTAB EMC, M20			50.220MP0T	RUTAB, SWEDEN	14 76513	AHLSELL, SWEDEN
8	<u> </u>	CABLE GLAND, RUTAB EMC EEX II			221284	RUTAB, SWEDEN	1476041	AHLSELL, SWEDEN
6	<u> </u>	JAM NUT, RUTAB EMC, M12			50.212MP0T	RUTAB, SWEDEN	14 76511	AHLSELL, SWEDEN
							_	











Date Drawn by: Checked by: Approved



Revision Description

tem Quantity Descriptions	Drawing No.	Safegate Product No.	fanufacturer's Part No.	Manufacturer	Supplier's Stock Number	Supplier	
1 2 END BRACKET, CLIPFIX 35–5	, ,	,			3022276	PHOENIX CONTACT, SWEDEN	
2 1 COMPONET IDENTIFIER LABEL, YELLOW, 15x8mm, TEXT: K10	10				21302G	TECHNOTRADE SCANDINAVIA AB, SWED	DEN
C6 1 PATCH CABLE	SG590258-101-01						
K10 1 CAT 6 TRANSIENT FILTER, D-LAN-CAT.6+					2881007	PHOENIX CONTACT, SWEDEN	
					Unless otherwise indicat tolerances are according	ed, all Sharp Edi to	dges
				SAFEGATE	Surface Coating	Weight	
				Safegate International AB MALMÖ, SWEDEN	CAT6 FILTER		
		-		Drawn by: Date drawn: Checked by: Checked by:	•	-	
A Drawing Changed Revision Description	20 Date	11.11.04 A.S. Drawn by:	Checked by: Approved	App. by: Date approved: Project No.:	Drawing No. SG590262-(01-01 Rev. Sheet Scale $01-01$ A $1 of 1$	
-	-	-	-	-			

POS QTY	DESCRIPTION	STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
1	DIN RAIL, 350 mm	Standard	T1/T1S	SG590621-211-01		PHOENIX CONTACT		
2 2	END BRACKET, CLIPFIX 35-5	Standard	T1/T1S		3022276	PHOENIX CONTACT		
3 10	TERMINAL CONTACT, UK 3-MSTB-5,08	Standard	T1/T1S		3002034	PHOENIX CONTACT		
4	COVER, 2.5 mm	Standard	T1/T1S		3002047	PHOENIX CONTACT		
5 2	SCREW, ISO7045, M5x12, ZINC PLATED	Standard	T1/T1S					
6 2	WASHER, ISO7089, 5.3x15x1, ZINC PLATED	Standard	T1/T1S					
7 1	RELAY MODULE, PLC-RSC-24UC/21	Standard	T1/T1S		2966184	PHOENIX CONTACT		
8a 2	RELAY SOCKET, RIF-4-BPT/3X21	Standard	T1/T1S		2900961	PHOENIX CONTACT		
8b 4	RELAY SOCKET, RIF-4-BPT/3X21	SC	T1/T1S		2900961	PHOENIX CONTACT		
9a 2	RELAY, REL-PR2-24DC/2X21	Standard	T1/T1S		2903698	PHOENIX CONTACT		
9b 4	RELAY, REL-PR2-24DC/2X21	SC	T1/T1S		2903698	PHOENIX CONTACT		
10a 4	TERMINAL CONTACT, UT 4-TWIN	Standard	T1/T1S		3044364	PHOENIX CONTACT		
10b 6	TERMINAL CONTACT, UT 4-TWIN	SC	T1/T1S		3044364	PHOENIX CONTACT		
11 1	END COVER, D-UT 2,5/4-TWIN	Standard	T1/T1S		3047141	PHOENIX CONTACT		
12	TERMINAL MARKERS, NUMBERING AS SHOWN ON ILLUSTRATION	Standard	T1/T1S					



					:MBLY		Sheet	1(1)
		Info			11NAL BLOCK ASSE	Γ1S	Scale Size	NO SCALE A3
Surface treatment	Basic material	¢	€ }	Description	X3 LERN	FOR T1/7	Rev.	Ш
		SAFEGATE		Date drawn:	2000-001	Late approved:	Drawing No.	SG590263-001-01
	NACHE	Airled Ugfting		Drawn by:	G.U.	Approved by:	Project No.	
			Components added, changed to fit new release of T1.	Items 8 and 9 added.	Item 7 renumbered.	Quantity for item 3 changed, items 9&10 renumbered to 6&7	Quantity for item 3 changed.	issue text
								Issue checked by
			N	КJ	AS	GO	GO	Issue by
			2014-10-10	2014-01-08	2012-08-30	2008-02-03	2008-09-21	Issue date
			ш	٥	U	В	A	kev.

Gen. tolerance

STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
Standard	T1/T1S		4414F/2L	EBM-PAPST		
Standard	T1/T1S	SG590264-200-01				
Standard	T1/T1S		PFA20000	PFANNENBERG		
Standard	T1/T1S					
Standard	T1/T1S					
Standard	T1/T1S		9025780000	WEIDMÜLLER		
Standard	T1/T1S		9026090000	WEIDMÜLLER		
Standard	T1/T1S				735-991	FARNELL
Standard	T1/T1S					
Ctord and						



SUPPLIER			
SUPPLIER'S STOCK NO.			
MANUFACTURER		PFANNENBERG	
MANUFACTURER'S PART NO.		PFA20000	
DRW. NO.	SG590264-200-01		
T1/T1S/T2/T3	T1/T1S	T1/T1S	T1/T1S
STD/OPT	Standard	Standard	Standard





				EMBLY			Sheet	1(1)
				TER ASS			Size	A2
		Info				JISPLAY	Scale	0,666
surrace treatment	Basic material	<i>€</i>	Description	VENTILA		T1/T1S, [Rev.	A
		C R O U F	Date drawn:	2014-03-23	Date approved:	:	Drawing No.	SG590264-101-01
	NACHT	Airfield Lighting	Drawn by:	V. NURELL	Approved by:		Project No.	
								Issue text
								Issue checked by
								Issue by
								Issue date

No

DESCRIPTION	FILTER ADAPTER PLATE	FILTER ASSEMBLY	M5x12, DIN912/ISO4762, A2
QTY	٢	2	9
POS	1	2	3





ltem	Quantity	Description/Ratings	Drawing No.	Safegate Product No.	Manufacturer's Part No.	Manufacturer	Supplier's Stock Number	Supplier	
_	~	MAINS WIRE, UL 1015, BROWN, AWG 16					5526017	ELFA AB, SWEDEN	
5	-	NEUTRAL WIRE, UL 1015, BLUE, AWG 16					5526066	ELFA AB, SWEDEN	
 	-	GND WIRE, UL 1015, YELLOW/GREEN, AWG 16					5526082	ELFA AB, SWEDEN	
4	m	CRIMP LUG, H2.5/14					9026100000	WEIDMÜLLER, SWEDEN	
_ د	~	WARNING LABEL, SHOCK HAZARD					PLD-56	PANDUIT NORDIC, SWEDE	Z
9	~	COMPONET IDENTIFIER LABEL, YELLOW, 15×8mm, TEXT: K11					21302G	TECHNOTRADE SCANDINAVIA	AB, SWEDEN
K11	-	POWER OUTLET FUSE, SD 035, DIN STYLE			03500.0-00	STEGO ELEKTRONIK, GERMANY	03500.0-00	STEGO NORDEN, SWEDEN	
K11	-	POWER OUTLET FUSE, SD 035, French Model			03501.0-00	STEGO ELEKTRONIK, GERMANY	03501.0-00	STEGO NORDEN, SWEDEN	
¥1	_	POWER OUTLET FUSE, SD 035, Brittish Style			03503.0-00	STEGO ELEKTRONIK, GERMANY	03503.0-00	STEGO NORDEN, SWEDEN	
K11	—	POWER OUTLET FUSE, SD 035, US Style			03504.0-00	STEGO ELEKTRONIK, GERMANY	03504.0-00	STEGO NORDEN, SWEDEN	
						Ced below K11			
	$\overline{\Box}$) 					Unless otherwise indition	cated, all tinn to	Sharp Edges
						SAFEGATE	Surface Coating	2	Weight
						G R O U P , Safegate International AB MALMÖ, SWEDEN	UTILITY OU	TLET	_



<u>...</u>

1 of 1

Rev. Sheet A 1 of

Drawing No. SG590266-001-01

Checked by:

Project No.:

Drawn by: Date drawn: G.O. 2009.03.10 App. by: Date approved:

Approved

Checked by:

2011.11.04 A.S. Date Drawn by: C

BOM changed

Scale



Description/Ratings	CABLE, CYLIYCY, 8 x 2 x 0.25	CONNECTOR, MC1.5/10-ST-3.81	CONNECTOR, MC1.5/6-ST-3.81	HEAT SHRINKABLE TUBING, Ø9.5,	CRIMP LUG, H 0.25/12	CRIMP LUG, H 1.5/14	WIRE MARKERS, PARTEX PA02	LABEL, SK 3,81/2,8: S0, TEXT: J2	LABEL, SK 3,81/2,8: S0, TEXT: J13	CONNECTOR, MSTB 2,5/13-ST-5,0		Revision Description
Quantity		~	~	2	26	<u>~</u>		-	L	-	BROWN (59) WHITE (60) RED (61) BLACK (66) BLACK (66) GRATY (63) GRATY (68) GRAY (69) GRAY (69) FINK (70) E/GREEN (71)	
ltem	—	2	m	4	5	9	L	8	6	10	KHI G. B.	



Description/Ratings	CABLE, CYLIYCY, 8 x 2 x 0.25	CONNECTOR, MC1.5/10-ST-3.81	CONNECTOR, MC1.5/6-ST-3.81	HEAT SHRINKABLE TUBING, Ø9.5, BI	BOOTLACE FERRULE, H 0.25/12	BOOTLACE FERRULE, H 1.5/14	WIRE MARKERS, PARTEX PA02	LABEL, SK 3,81/2,8: S0, TEXT: J15	LABEL, SK 3,81/2,8: S0, TEXT: J20	CONNECTOR, MSTB 2,5/13-ST-5,08	100												
Desc	CP	2	2	H	BC	BC	MI	ΓÞ	ΓÞ	0	V	•											
Quantity	—	—	—	2	26	~		<u> </u>	—	-			BROWN (72) WHITE (73) RED (74) BLUE (75) YELLOW (76) BLUET (78) BLUET (78) BLUET (78) GRAY (81) GRAY (82) GRAY (83) TE/GREEN (84)										
ltem		2	m	4	G	6	L	8	6	10													
																	- L	Sharp Edges	Weight	-			eet Scale 1 NN SCALE
---	---	-----------------------------	-------------------------------------	--	-----------------------------------	------	-----	----------	--	---	-------------	---	---	--------------	---------------------------	-----------	---------------------	--	-----------------	----------------	---	--	-------------------------------------
Supplier			ELFA, SWEDEN	WEIUMULLEK WFIDMÜLLFR					RED [52] BLUE [51] COAVIER				8					licated, all ding to		ABLE			
Supplier's Stock Number			5507108	902/20000 SFF NDTF			170											Unless otherwise inc tolerances are accor	Surface Coating	CONTROL C		⊕ ∏7	Drawing No.
Manutacturer	PHOENIX CONTACT	PHOENIX CONTACT	ALPHA WIRE		PHOENIX CONTACT													C A E C A T E	JAFEUALE		Safegate intel'national Ad MALMÖ, SWEDEN	awn by: Date drawn: Checked by: E .0.	pp. by: Date approved: Project No.:
Salegare Producti No. Manuracturer Sinari No.	1757077	1803659	FIT-221-3/8		0805056	5000					(~								•				AF Arboroved Action Approved
DI AWING NO.														WIRE MARKERS	21 ND. QTY. 21044101 2	1044102 2	1044104 2	1044105 16	71044106 Z	01044107 2	1		Dat
Description/Katings	CABLE, LIYCY, 4 x 2 x 0.25 CONNECTOR, MSTB 2,5/8-ST-5,08	CONNECTOR, MC1.5/10-ST-3.81	HEAT SHRINKABLE TUBING, Ø9.5, BLACK	BUUILALE FEKKULE, H U.25/ 12 WIRF MARKFRS PARTFY PAN?	LABEL, SK 3,81/2,8: SO, TEXT: J28		100	-	BLUE (51) BLUE (52) BLUE (PINK (54) 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	VELLOW (57)	(9	NOTE FOR	NO. PAR 1 11-01	2 11-0	4 11–0 ⁻	5 11-0	0-11 9	7 11=0 11=0	,		Revision Inscription
n uuaniiy		-	2																				



Description/Ratings	HEAT SHRINKABLE TUBING, 09.5, BI BOOTLACE FERRULE, H 0.75/14	01 01 01 01 01 01 01 01 01 01 01 01 01 0	(19) (13) (13) (13) (13) (13) (13) (13) (13
Quantity 1	12		
ltem 4			









ma ti		Quantity	Description/Ratinus
-			CARRIER BOARD AND CPU ASSEMBLY
2		-	DOCKING BOARD
m		_	EXTENSION ASSEMBLY
4			SCREW, LKCS, M4×12, ZINC PLATED
Ъ		-	HOLD DOWN BRACKET
	40	ctions for	controlocity hourd SCE0013E AAA
	1111 1111	1012 1012 101	ו בהופרווות בט-בוו נטון מטפו ט, אטאט ובא-טטט, אוו
יו –		possible.	download and save the existing configuration
	S	ystem usir	ig the SD-Config tool. This will make configura
	Ĕ	ew board 6	asier
2	≥ ĭ 	ith power	off, remove the protective cover for the CU-
~		uaru asser isronnert	muty. all wiring from the Cll-circlif board
t 1	Ē	emove the	clamp that holds the stepper motor driver ca
	Ъ	ace by un	doing the fastener that holds it in place.
ഹ	Ř	emove the	stepper motor driver cards by pulling them u
		om the LL	i-circuit board.
۵	52	n model wi aiat far th	here there is a weided stud that is used as th a shrea rowing motor motor drived and a
	ίΞ	reak the s	tud off. This is best done by using a twisting .
	<u>ک</u>	tud.	
L	<u>م</u>	emove the	CU-circuit board by removing the six fastener
	÷	in place o	n the stand-offs. Note: Be care not to loosen
	S	tand-offs	as it can be difficult to re-tighten them withc
	0	osening tl	ne mounting plate.
œ	نٽ حت	asten the	new docking board in place on the stand-offs.
6	<u>م</u> .	osition the	: Carrier Board-CPU assembly over the mating
	le)-pustand-(offs on the docking board and press until the
	le	re seated	and the locking tabs on the stand-offs make
	ν ν	ound. · · · · ·	-
	5, 2,	e-Install f	he stepper motor driver cards.
_	<u> </u>	0SITION TN(extension assempty on the top edge of the matter driver.
	₹ ‡	are surrive	at is territer and a more the stepper more in the set of the set o
-	2. F(or svstem:	s where the stepper motor driver cards are m
	V	ertically, a	ittach the original clamp to the extension ass
	10	ther syste	ms, use the clamp that supplied with the kit. I
	S	crew that	is supplied with the replacement kit to do this
<u> </u>	м. 1	e-connect	all wiring.
<u> </u>	4. . R	e-install t	he protective cover.
,	ب ح	ower up tt 	ie system and install and configure the softw
	ð	ocking sys	tem. Note: The new CU-circuit board requires :

version 8 or higher to run properly.

COOLING FAN FOR RIEGL LASER RANGE FINDER

REVISIONS B. ITEM 8 ADDED. BY: G.O. DATE: 2003-03-20 C. ITEM 8 CHANGED. ITEM 9 ADDED BY: G.O. DATE: 2004.03.08 D. ITEMS 2 & 3 CHANGED, ITEM 10 ADDED. BY: G.O., DATE: 2006.09

PRODUCT CONFIGURATION FILE PRODUCT ASSEMBLY AND COMPONENT PLACEMENT

COMPONENT	AND PAR	TS LIST							
POSITION	QUANTITY	Y DESCRIPTION/RATINGS	AWING NO. SI	AFEGATE PROD. NO.	MANU. PART NO.	MANUFACTURER	SUPPLIER'S. PART NO.	SUPPLIER	
.		BRACKET	590405-200-01						
2		FAN, 92x92, 24 VDC			3414NGH	PAPST GERMANY	9600450	FARNELL SWEDEN	
e	~	FINGER GUARD, LZ23K					1171817	FARNELL SWEDEN	
4	~	ALLEN HEAD SCREW, ISO 4762, M5 x 20 ZINK PLATED					MC6S M5 x 20 8.8 fzb	BIX SWEDEN	
ß	5	SCREW, ISO-7045, M4x12, ZINK PLATED					MRX-Z 4x12 4.8 fzb	BIX SWEDEN	
9	7	LOCKNUT, ISO 7040, M4, ZINK PLATED					DIN 985 M4 fzb	BIX SWEDEN	
7	7	CRIMP LUG, H0.25/12			9025780000	WEIDMÜLLER, GERMANY	9025780000	WEIDMÜLLER, SWEDEN	
ω		WIRE MARKERS							
	~	PARTEX PA02, TEXT: 3			11-01044103	WEIDMÜLLER, GERMANY	11-01044103	WEIDMÜLLER, SWEDEN	
	.	PARTEX PA02, TEXT: 4			11-01044104	WEIDMÜLLER, GERMANY	11-01044104	WEIDMÜLLER, SWEDEN	
	7	PARTEX PA02, TEXT: 9			11-01044109	WEIDMÜLLER, GERMANY	11-01044109	WEIDMÜLLER, SWEDEN	
o	-	COMPONET IDENTIFIER LABEL, YELLOW, 15x8mm, TEXT: K56					21302G	TECHNOTRADE SCANDINAVIA AB SWEDEN	
10	4	RIVIT, PLASTIC			094 0330 699 01	SKIFFY THE NETHERLANDS		BUFAB-BIX SWEDEN	

PRODUCT CONFIGURATION FILE, PRODUCT 590405 SG590405-000-01

ASSMBLY LEVEL DOCUMENT LIST

SG590405-000-01 SG590405-001-01





ltem	Quantity	Description/Ratings	Drawing No.	Safegate Product No.	Manufacturer's Part No.	Manufacturer	Supplier's Stock	t Number Supplier		
_	-	FAN, 119×119, 24 V DC			4314U	EBM-PAPST, GERMANY	<u>337-3317</u> 9600175	RS COMPONEN	NTS, SWEDEN EDEN	
2	, -	ELECTRICAL CABLE, LIYY, 2x0.34, L = 1900mm					7852020	AB NOVUN	M, SWEDEN	
 	<u> </u>	FINGER GUARD, METAL					735-991	FARNELL,	SWEDEN	
4	4	MOUNTING CLIP			LZ212	PAPST, GERMANY	311-1623	FARNELL,	SWEDEN	
2	4	SCREW, ISO 7049, ST3.5x9.5, STAINLESS STEEL						FARNELL,	SWEDEN	
9	2	HEAT SHRINKABLE TUBING, Ø6.4, BLACK			FIT-221-1/4	ALPHA WIRE	5507009	ELFA, SW	EDEN	
	2	CRIMP SPLICE, TINNED COPPER, PVC, GREEN					48-212-	45 ELFA, SW	EDEN	
8	2	CRIMP LUG, H 0.34/12			9025790000	WEIDMÜLLER, GERMANY	9025790	000 WEIDMÜLL	-ER, SWEDEN	
6	-	LABEL, YELLOW, 15×8, TEXT: K17					21302G	TECHNOTE	RADE, SWEDEN	
10		WIRE MARKERS, PARTEX PA02			SEE NOTE	WEIDMÜLLER, GERMANY	SEE NOT	E WEIDMÜLL	-ER, SWEDEN	
		NOTF	FOR WIRF MARK	FRS					Ĺ	
		NO.	PART NO.	<u>ат</u> Ү.			+	+		
			11-01044101	~				X		
		4	11-01044104							
									$\overline{)}$	
)—								
		BROWN (114)					•	(
					-		$\left<\right>$	-		
								(
					-		BLUE WIRE	5		
)))		
			 					(
		CONTROL AND POWER ASSEMBLY								
						_				
			_			-				
]	L		-)		-
						C A E E C A T	Unless of tolerance	herwise indicated, all s are according to		Sharp Edges
		VENTILATION FAN, K17				JALECAL	Surface	Coating		Weight
							VENT	ILATION FAN		
						sareyare ini ernarionar Ab MALMÖ, SWEDEN				
		E Cable length changed, drawing now valid for	T2 and T3	2011.10.18 A.S.		rawn by: Date drawn: Checked b) .0. 2003.03.07	⊕ ↓ ∵			
		D FAN MODEL, ITEM 1 AND AIR FLOW DIRECTION	CHANGED	2007.10.18 G.O.	4	pp. by: Date approved: Project No	Drawing	No.	Rev. Sheet	Scale
		Revision Description		Date Drawn by:	Checked by: Approved			10-10-14	E 1 of	1 NO SCALE



DEFROSTER ASSEMBLY

REVISIONS

A. Items 4 thru 7 changed. By: G.O. Date: 2004.09.21

POSITION		I S LIS I / DESCRIPTION/RATINGS	DRAWING NO.	SAFEGATE PROD. NO.	MANU. PART NO.	MANUFACTURER	SUPPLIER'S. PART NO.	. SUPPLIER
RS1-RS3	ო	POWER RESISTOR, 6.5 Ohm, 25 W			HS25 6R8 J	ARCOL, ENGLAND		
RS4-RS5	5	POWER RESISTOR, 10 Ohm, 25 W			HS25 10R J	ARCOL, ENGLAND		
7	-	DEFROSTER PLATE	AT 606373					
2	-	DEFROSTER PLATE	AT 606103					
3	-	SPIRAL WIRE GUARD, DIA. 10 mm					E 29 933 10	AHLSELL, SWEDEN
4	-	WIRE, UL1007/1569, AWG 20, BLACK, L = 820 mm			3053 BLACK	ALPHA WIRE, USA	5522909	BEJOKEN, SWEDEN
ى	~	WIRE, UL1007/1569, AWG 20, BLACK,L = 1000 mm			3053 BLACK	ALPHA WIRE, USA	5522909	BEJOKEN, SWEDEN
9	~	WIRE, UL1007/1569, AWG 20, BLACK,L = 350 mm			3053 BLACK	ALPHA WIRE, USA	5522909	BEJOKEN, SWEDEN
7	-	WIRE, UL1007/1569, AWG 20, BLACK,L = 350 mm			3053 BLACK	ALPHA WIRE, USA	5522909	BEJOKEN, SWEDEN
ω	5	CRIMP LUG, H 0,5/14			9026060000	WEIDMÜLLER, GERMANY	9026060000	WEIDMÜLLER, SWEDEN
თ	14	POP RIVIT, AL/AC, BLACK, 3,2 X 8						
10	4	SHRINK WRAP, L = 15					55-070-25	ELFA, SWEDEN
11		WIRE MARKERS						
	~	PARTEX PA02, TEXT: 5			11-01044105	WEIDMÜLLER, GERMANY	11-01044105	WEIDMÜLLER, SWEDEN
	-	PARTEX PA02, TEXT: 6			11-01044106	WEIDMÜLLER, GERMANY	11-01044106	WEIDMÜLLER, SWEDEN
	7	PARTEX PA02, TEXT: 8			11-01044108	WEIDMÜLLER, GERMANY	11-01044108	WEIDMÜLLER, SWEDEN
12	-	CABLE TIE MOUNT, BLACK					55-140-96	TECHNOTRADE SWEDEN
13	-	CABLE TIE, 71x1.8, NATURAL			PLT.6SM-C0	PANDUIT, USA	5502828	ELFA, SWEDEN
14	-	LABEL, YELLOW, 15x8, TEXT: R1-R3					21302G	TECHNOTRADE SWEDEN
15	-	LABEL, YELLOW, 15x8, TEXT: R4-R5					21302G	TECHNOTRADE SWEDEN

Ō
\leq
0
0
\mathbf{O}
ų
4
Ò
07
D
U
Ň
VJ

 ASSMBLY LEVEL DOCUMENT LIST

 SG590486-000-01
 PRODUCT CONFIGURATION FILE

 SG590486-001-01
 COMPONENT PLACEMENT AND CONNECTION DIAGRAM





SOFT KEY OPERATOR PANEL

REVISIONS

CONFIGURATION FILE / AND CONNECTION DIAGRAM FION DIAGRAM OARD OARD OARD OR, EITHER OF FOLLOWING ONNECTOR, CA3GD, 4 POLE ONNECTOR, C16-1 TYPE, 4 POLE ONNECTOR, C16-1 TYPE, 4 POLE						
IOWRATINGS OARD TOUCH PAD OR, EITHER OF FOLLOWING ONNECTOR, CA3GD, 4 POLE ONNECTOR, C16-1 TYPE, 4 POLE ONNECTOR, C16-1 TYPE, 4 POLE						
IONRATINGS OARD TOUCH PAD OR, EITHER OF FOLLOWING ONNECTOR, CA3GD, 4 POLE ONNECTOR, C16-1 TYPE, 4 POLE ONNECTOR, C16-1 TYPE, 4 POLE						
OARD TOUCH PAD OR, EITHER OF FOLLOWING ONNECTOR, CA3GD, 4 POLE ONNECTOR, C16-1 TYPE, 4 POLE ON CAP, EITHER OF FOLLOW	DRAWING NO.	SAFEGATE PROD. NO. MANU.	PART NO. M.	ANUFACTURER	SUPPLIER'S. PART VO.	SUPPLIER
TOUCH PAD OR, EITHER OF FOLLOWING ONNECTOR, CA3GD, 4 POLE ONNECTOR, C16-1 TYPE, 4 POLE ON CAP, EITHER OF FOLLOW	SG590495-000-01					
OR, EITHER OF FOLLOWING ONNECTOR, CA3GD, 4 POLE ONNECTOR, C16-1 TYPE, 4 POLE ON CAP, EITHER OF FOLLOW		18071,	Rev. A1 S1	TEEL GRAPH, SWEDEN		
ONNECTOR, CA3GD, 4 POLE ONNECTOR, C16-1 TYPE, 4 POLE ON CAP, EITHER OF FOLLOW						
ONNECTOR, C16-1 TYPE, 4 POLE ON CAP, EITHER OF FOLLOW		932321	-100 HI	IRSCHMANN Electronics GmbH & Co. KG	362279	BEJOKEN AB SWEDEN
ON CAP, EITHER OF FOLLOW		T3111-(000 AN	MPHENOL	1456158	ELFA SWEDEN
		831531	-100 HI GI	IRSCHMANN Electronics GmbH & Co. KG I	362285	BEJOKEN AB SWEDEN
Ш		T6483-(000 AN	MPHENOL FRMANY	1456455	ELFA SWEDEN
CY STOP SWITCH ASSEMBLY		XB4BS	542 S(CHNEIDER ELECTRIC, SWEDEN	XB4BS542	SCHNEIDER ELECTRIC, FRANCE
Y OPEN CONTACT		ZBE-10	1 S(CHNEIDER ELECTRIC, SWEDEN	ZBE-101	SCHNEIDER ELECTRIC, FRANCE
CONTACT		140101	6 1	HOENIX CONTACT, SWEDEN	1401019	PHOENIX CONTACT, SWEDEN
• E/MBK		140163	7 PI	HOENIX CONTACT, SWEDEN	1401637	PHOENIX CONTACT, SWEDEN
. MARKER, TML (EX5)R, 1-16		550373.	2 PI	HOENIX CONTACT, SWEDEN	5503732	PHOENIX CONTACT, SWEDEN
G	SG590495-301-01					
C8	SG590495-302-01					
C10	SG590495-303-01					
CS1	SG590495-304-01					
CP1	SG590495-305-01					
M ENCLOSURE	SG590495-200-01					
AND POLYAMID M20, CABLE DIAMETER 8-13mm.		AHLSE			14 761 13	AHLSELL, SWEDEN
POLYAMID M20		AHLSE	L		14 765 33	AHLSELL, SWEDEN
F, M3 X 20					DSS M3050X20	BIX, SWEDEN
5O 2009, M3 X 6, ZINC PLATED						
(032, M3						
DIN 125, 3.2 X 6 X 0.5						
SO 1207, M3 X 10, STAINLESS STEEL						
αΥ, POLYETHYLEN, M20					1470181	AHLSELL, SWEDEN
IN 7985, M6 X12, ZINC PLATED						
. BLOCK MOUNTING RAIL	SG590495-300-01					
ROSS RECESSED PAN, STEEL, M5X12, DIN 7500						
;, 71X1,8, BLACK	SG590495-400-01					
	BLOCK MOUNTING RAIL 80SS RECESSED PAN, STEEL, M5X12, DIN 7500 , 71X1,8, BLACK	BLOCK MOUNTING RAIL SOSS RECESSED PAN, STEEL, M5X12, DIN 7500 , 71X1,8, BLACK SG590495-400-01	BLOCK MOUNTING RAIL SOSS RECESSED PAN, STEEL, M5X12, DIN 7500 , 71X1,8, BLACK SG590495-400-01	BLOCK MOUNTING RAIL SOSS RECESSED PAN, STEEL, M5X12, DIN 7500 , 71X1,8, BLACK SG590495-400-01	BLOCK MOUNTING RAIL SOSS RECESSED PAN, STEEL, M5X12, DIN 7500 71X1,8, BLACK 2055 RECESSED PAN, STEEL, M5X12, DIN 7500 SG590495-400-01 SG590495-400-01	BLOCK MOUNTING RAIL SOSS RECESSED PAN, STEEL, M5X12, DIN 7500 71X1,8, BLACK . 71X1,8, BLACK

SG590495-010-01 PRODUCT CONFIGURATION FILE,





ltem	Quantity	Description/Ratings	Drawing No.	Safegate Product No.	Manufacturer's Part No.	Manufacturer	Supplier's Stock Number	Subolier	
K70		POWER RESISTOR, 10 Ohm, 100 W		<u>`</u>			60-681-26	ELFA, SWEDEN	
	<u> </u>	WIRE, UL 1007/A569, AWG 20, L = 270 mm, BLACK			3053 BLACK	ALPHA WIRE, USA	55-229-09	ELFA, SWEDEN	
2	<u> </u>	WIRE, UL 1007/A569, AWG 20, L = 120 mm, BLACK			3053 BLACK	ALPHA WIRE, USA	55-229-09	ELFA, SWEDEN	
<u> </u>	2	Shrink Wrap, L = 15					55-070-25	ELFA, SWEDEN	
4	2	CRIMP LUG, H 0,5/14			9026060000	WEIDMÜLLER, GERMANY	9026060000	WEIDMÜLLER, SWEDEN	
5		WIRE MARKERS							
	<u> </u>	PARTEX PA02, TEXT: 1					11-01044101	WEIDMÜLLER, SWEDEN	
	<u> </u>	PARTEX PA02, TEXT:2					11-01044102	WEIDMÜLLER, SWEDEN	
	2	PARTEX PA02, TEXT: 9					11-01044109	WEIDMÜLLER, SWEDEN	



					SAFE G R	GATE 0 U P	¢	Unless otherwise indicated, all tolerances are according to Surface Coating		Sharp Edges Weight
					Safegate Inte MALMÖ, S	rnational AB sWEDEN		HEATINU ELEMENT For scanning assembly		
-		-	-	Drawn by: G.O.	Date drawn: 2004-01-19	Checked by:				
2004-09-2	0.0.			App. by:	Date approved:	Project No.:		Drawing No.	Rev. Sheet	Scale
Date	Drawn by:	Checked by:	Approved					SG590512-001-01	A 1 of 1	NO SCALE

changed	
\sim	
1 and	
ltems .	Description
A	Revision

01

SOFT KEY OPERATOR PANEL

С S	590	525-000-01					SOFT KEY (DPERATOR PANEL
PRODU	CT CONFI	GURATION FILE,				REVISIONS A. Item K2 Changed. Terminal contact (OPX1) B. OP X1 position changed, cables added. By:	+ + cables added. By K.J. Date K.J. Date 2014-02-24	• 2013-12-03
ASSMBL	Y LEVEL D(DCUMENT LIST						
SG590525-(SG590525-(SG590525-(000-01 001-01 005-01	PRODUCT CONFIGURATION FILE ASSEMBLY AND CONNECTION DIAGRAM INSTALLATION DIAGRAM						
COMPON	IENT AND P	ARTS LIST						
POSITION	QUANTITY	DESCRIPTION/RATINGS	DRAWING NO.	SAFEGATE PROD. NO.	MANU. PART NO.	MANUFACTURER	SUPPLIER'S. PART NO.	SUPPLIER
ž		CIRCUIT BOARD	SG590495-000-01					
K2	.	SOFT KEY TOUCH PAD			18071, Rev. A1	STEELGRAPH, SWEDEN		
P1	-	CONNECTOR, EITHER OF FOLLOWING						
		FEMALE CONNECTOR, CA3GD, 4 POLE			932321-100	HIRSCHMANN Electronics GmbH & Co. KG	662279	BEJOKEN AB SWEDEN
		FEMALE CONNECTOR, C16-1 TYPE, 4 POLE			T3111-000	AMPHENOL GERMANY	4456158	ELFA SWEDEN
	~	PROTECTION CAP, EITHER OF FOLLOW						
		CA 00 SD 4			831531-100	HIRSCHMANN Electronics GmbH & Co. KG	662285	BEJOKEN AB SWEDEN
		С16-1 ТҮРЕ			T6483-000	AMPHENOL GERMANY	4456455	ELFA SWEDEN
S1	£	SWITCH ASSEMBLY, DEAD MAN			XB4-BC21	SCHNEIDER ELECTRIC, SWEDEN	XB4-BC21	SCHNEIDER ELECTRIC, FRANCE
OP X1	16	TERMINAL CONTACT			1401019	PHOENIX CONTACT, SWEDEN	1401019	PHOENIX CONTACT, SWEDEN
	2	END STOP E/MBK			1401637	PHOENIX CONTACT, SWEDEN	1401637	PHOENIX CONTACT, SWEDEN
		TERMINAL MARKER, TML (EX5)R, 1-16			5503732	PHOENIX CONTACT, SWEDEN	5503732	PHOENIX CONTACT, SWEDEN
OP C1	.	CABLE OP C1	SG590495-301-01					
OP C8	-	CABLE OP C8	SG590495-302-01					
OP C10	.	CABLE OP C10	SG590495-303-01					
OP CS1	-	CABLE OP CS1	SG590495-304-01					
OP CP1	-	CABLE OP CP1	SG590495-305-01					
L	-	ALUMINIUM ENCLOSURE	SG590495-200-01					
2	-	CABLE GLAND, POLYAMID, M20, CABLE DIAMETER 8-13mm.			AHLSELL		14 761 13	AHLSELL, SWEDEN
3	-	JAM NUT, POLYAMID, M20			AHLSELL		14 765 33	AHLSELL, SWEDEN
4	4	STAND OFF, M3 X 20					DSS M3050X20	BIX, SWEDEN
5	4	SCREW, ISO 2009, M3 X 6, ZINC PLATED						
9	4	NUT, ISO 4032, M3						
7	4	WASHER, DIN 125, 3.2 X 6 X 0.5						

Page 1 of 2 File Name: SG590525-000-01_RVB

	-	-		-	1
	AHLSELL, SWEDEN				
	1470181				
			SG590495-300-01		SG590495-400-01
SCREW, ISO 1207, M3 X 10, STAINLESS STEEL	PLUG, GRAY, POLYETHYLEN, M20	SCREW, DIN 7985, M6 X12, ZINC PLATED	TERMINAL BLOCK MOUNTING RAIL	SCREW, CROSS RECESSED PAN, STEEL, M5X12, DIN 7500	CABLE TIE, 71X1,8, BLACK
2	2	1	1	2	12
8	6	10	11	12	13

Note: Part number refers to package of 100 pcs.









COOLING UNIT

REVISIONS A. Item 1, Part No. Changed. By: G.O. Date: 2005.09.14 B. Item 4, Quantity changed. By: G.O. Date 2007.08.06

SG590543-100-02





	ER. CLOSED CELL EPDM-S	
-	auantity Description/Ratings FOAM RUBBI	
	ltem	



	Jrawing No.	Safegate Product No.	Manufacturer's Part No.	Manufactu	rer	S	supplier's Stock Number	Supplier	
×									
	3G590553-100-01								
.LOW, 15x8mm, TEXT: K73 .LOW, 15x8mm, TEXT: K74							21302G 21302G	TECHNOTRADE SCANDINAVI/ TECHNOTRADE SCANDINAVI/	a ab, Sweden a ab, Sweden
				ELX L					
					0				
(-+-)									
					K14	COMPONET PLACEMENT DOCKING GUIDANCE UNI			
anged and K74 changed	201 201 bate	1.01.24 A.S. 1.11.17 A.S. 15.09.14 G.O.	y: Chetked by: Approve	Drawn by: App. by: Drawn by: D	SAFE SAFE G R (Safegate Inter MALMÖ, S MALMÖ, S MALMÖ, S 1005.008.17 late approved:	GATE A C U P national AB WEDEN Checked by:	Unless otherwise indicate tolerances are according Surface Coating COOL ING ASS COOL ING ASS CG590543-0	EMBLY, T3 (01-01 C 1 of	Sharp Edges Weight Scale





COOLING UNIT, FOR SAFEDOCK 3

REVISIONS

SG590553-100-02







	ER, CLOSED CELL EPDM-S	ER, LLOSED LELL EPUM-S	
-	Pescription/Ratings FOAM RUBB		
	Quantity		
	ltem		



SG590559-000-01

REVISIONS B. Item M2's drawing number changed. Quantity of items 15 and 16 changed By: A.S., Date: 2012-01-17

ASSMBLY LEVE	IL DOCUI	MENT LIST					
SG590559-000-01 SG590559-001-01 SG590559-004-01		PRODUCT CONFIGURATION FILE COMPONENT PLACEMENT CONNECTION DIAGRAM					
COMPONENT A	ND PART	S LIST					
	QUANTITY	DESCRIPTION/RATINGS	DRAWING NO. SAFEGATE PROD. NO.	MANU. PART NO.	MANUFACTURER	SUPPLIER'S. PART NC). SUPPLIER
K18	۲	TEMPERATURE SENSOR	SG590137-000				
K70	-	HEATING ELEMENT	SG590512-001-01				
M1	۲	HORIZONTAL SCANNING MOTOR	SG590559-101-01				
M2	4	VERTICAL SCANNING MOTOR	SG590559-101-01				
X3		CONNECTION HARDWARE AS FOLLOWS					
	20	UKK 3-MSTB-5,08		2770888	PHOENIX CONTACT, GERMANY	2770888	PHOENIX CONTACT, SWEDEN
		TERMINAL MARKERS, ZB5,08, NO.S51, 52, 54 - 72		3809803	PHOENIX CONTACT, GERMANY	0809803	PHOENIX CONTACT, SWEDEN
	۲	UKK 3-MSTB-5,08-PE		1876615	PHOENIX CONTACT, GERMANY	1876615	PHOENIX CONTACT, SWEDEN
ـــــ		TERMINAL MARKER, ZB5,08, NO. 53		3809803	PHOENIX CONTACT, GERMANY	0809803	PHOENIX CONTACT, SWEDEN
	9	UT 2,5		3044076	PHOENIX CONTACT, GERMANY	3044076	PHOENIX CONTACT, SWEDEN
·		TERMINAL MARKER, ZB5, NO.S 85 - 86, 91-94		1050017	PHOENIX CONTACT, GERMANY	1050017	PHOENIX CONTACT, SWEDEN
<u>هــــــ</u>	۲-	D-UKK 3-MSTB-5,08		2770891	PHOENIX CONTACT, GERMANY	2770891	PHOENIX CONTACT, SWEDEN
	۲	DP-UKK 3-MSTB-5,08		2770600	PHOENIX CONTACT, GERMANY	2770600	PHOENIX CONTACT, SWEDEN
<u> </u>	۲	DG-UKK 3-MSTB-5,08		2770613	PHOENIX CONTACT, GERMANY	2770613	PHOENIX CONTACT, SWEDEN
	-	D-UT 2,5/10		3047028	PHOENIX CONTACT, GERMANY	3047028	PHOENIX CONTACT, SWEDEN
	т	CLIPFIX 35-5		1201442	PHOENIX CONTACT, GERMANY	1201442	PHOENIX CONTACT, SWEDEN
-	٢	MOUNTING FIXTURE	AT 601462				
2	-	LARGE SCANNING MIRROR	AT 606323				
3	1	SMALL SCANNING MIRROR	AT 600794				
4	-	DIN MOUNTING RAIL, NX 35/7,5-AL, L = 215		3801704	PHOENIX CONTACT, GERMANY	0801704	PHOENIX CONTACT, SWEDEN
5	۲	TERMINAL BLOCK, MSTBU 2,5/4-STD-5,08		1824146	PHOENIX CONTACT, GERMANY	1824146	PHOENIX CONTACT, SWEDEN
Q	ω	SCREW, ALLEN HEAD, ISO 4762, M5 x 20H					
7	9	SCREW, ISO 4762, M5x12, ZINC PLATED					
8	ω	SCREW, ISO 4762, M4x8H, ZINC PLATED					
o	7	SCREW, ISO 7045, M2x6H, ZINK PLATED					

File Name: SG590559-000-01_RVB

POSITION	QUANTIT	Y DESCRIPTION/RATINGS	DRAWING NO.	SAFEGATE PROD. NO.	MANU. PART NO.	MANUFACTURER	SUPPLIER'S. PART NO.	SUPPLIER
10	9	LOCK WASHER, DIN 127, 9.2x5.1x1.2, ZINC PLATED						
11	4	LOCK WASHER, DIN 127, 7.6x4.1x0.9						
12	-	LABEL, YELLOW, Text: K18, 15x8					21302G	TECHNOTRADE SWEDEN
13	1	LABEL, YELLOW, Text: K19, 15x8					21302G	TECHNOTRADE SWEDEN
14	-	LABEL, YELLOW, Text: K70, 15x8					21302G	TECHNOTRADE SWEDEN
15	2	LABEL, YELLOW, Text:M1, 15x8					21302G	TECHNOTRADE SWEDEN
16	2	LABEL, YELLOW, Text:M2, 15x8					21302G	TECHNOTRADE SWEDEN
17	-	LABEL, YELLOW, Text: X3, 15x8					21302G	TECHNOTRADE SWEDEN



Standing Mark Mark Standing Standing Standing Standing Standing Standing
X3 5 5 5 5 5 5 5 5 5 5 5 5 5
X3 51 52 53 54 55 55 55 56 57 58 73 66 73 66 74 61 75 72 73 56 74 61 75 73 76 73 76 73 76 74 76 74 76 74 76 74 76 74 76 74 76 74 76 74 77 70 76 74 77 76 78 76 79 76 70 77 76 78 77 77 78 76 79 76 70 76 71 76 76
X3 51 52 52 53 54 54 54 54 55 55 56 57 56 57 56 77 73 60 73 60 73 74 61 74 76 63 76 63 76 63 76 63 76 63 76 63 76 63 76 76 77 76 63 76 77 76 63 76 76 77 76 63 76 76 77 76 63 76 76 77 76 63 76 76 77 76 63 76 76 77 76 77 76 77 76 77 76 77 76 77 76 77 76 77 76 77 76 77 76 77 76 77 76 77 77
X3 51 52 54 54 55 56 56 56 56 57 58 58 77 72 59 72 59 77 73 60 73 60 73 76 62 76 77 78 78 79 70 79 76 62 77 76 62 77 76 62 77 76 62 77 76 62 77 76 62 77 76 77 76 77 76 77 76 77 76 77 76 77 76 77 77
X3 51 52 53 54 55 56 56 56 58 72 58 72 58 72 58 73 70 81 66 73 72 73 72 73 70 81 66 81 74 76 65 77 76 60 70 70 80 81 64 71 70 70 70 70 70 70 70 70 70 70

Į							1		5	1 1	$\underline{\gamma}$	14	72	76		78	61	80	2	32	l C C	34						
ļ	L									- [L -						100		μω	ω						
ļ																										ļ		
l,																										1		
		 _	-	_	_	_	_	_				_			_			_	_				 _	 _	 _			


Description/Ratings	STEPPER MOTOR, P850	OPTICAL ENCODER CABLE	CABLE GUARD, L = 250 mm	CRIMP TERMINAL	CONTACT, MSTB2,5/13-ST-5,08	A Mumber for rabierer	Revision Description
Quantity	_	-	~	∞	_		
ltem		2	m	4	5		



bescription/Ratings CABLE, LIYY 5X0X0.34mm2	CONTACT CRIMP TERMINAL CRIMP TERMINAL SHRINK WRAP 1-20mm	GRAY GRAY MHITE GRAY MHITE	A Cable changed from 7 Revision Description
Quantity	- س س -		
ltem	ر ب م		

REVISIONS B. Item M2's drawing number changed. Quantity of items 15 and 16 changed By: A.S., Date: 2012-01-17

SG590560-000-01

ASSMBLY LEV	EL DOCUN	AENT LIST
SG590560-000-01 SG590560-001-01 SG590560-004-01		PRODUCT CONFIGURATION FILE COMPONENT PLACEMENT CONNECTION DIAGRAM
COMPONENT #	AND PART	S LIST
POSITION K18	QUANTITY 1	DESCRIPTION/RATINGS TEMPERATURE SENSOR
M1	٢	HORIZONTAL SCANNING MOTOR
M2	٢	VERTICAL SCANNING MOTOR
X3		CONNECTION HARDWARE AS FOLL
	20	UKK 3-MSTB-5,08
		TERMINAL MARKERS, ZB5,08, NO.S
	-	UKK 3-MSTB-5,08-PE
		TERMINAL MARKER, ZB5,08, NO. 53
	9	UT 2,5
		TERMINAL MARKER, ZB5, NO.S 85 -
	1	D-UKK 3-MSTB-5,08
	-	DP-UKK 3-MSTB-5,08
	-	DG-UKK 3-MSTB-5,08
	-	D-UT 2,5/10
	ю	CLIPFIX 35-5
-	-	MOUNTING FIXTURE
2	1	LARGE SCANNING MIRROR
3	1	SMALL SCANNING MIRROR
4	٢	DIN MOUNTING RAIL, NX 35/7,5-AL, I
5	1	TERMINAL BLOCK, MSTBU 2,5/4-STI
9	8	SCREW, ALLEN HEAD, ISO 4762, M5
7	9	SCREW, ISO 4762, M5x12, ZINC PLA
8	4	SCREW, ISO 4762, M4x8H, ZINC PLA
6	2	SCREW, ISO 7045, M2x6H, ZINK PL/
10	9	LOCK WASHER, DIN 127, 9.2x5.1x1.2

ASSMBLY LEV		MENI LISI					
SG590560-000-01 SG590560-001-01 SG590560-004-01		PRODUCT CONFIGURATION FILE COMPONENT PLACEMENT CONNECTION DIAGRAM					
COMPONENT A	ND PAR1	IS LIST					
POSITION	QUANTITY	DESCRIPTION/RATINGS	DRAWING NO. SAFEGATI	E PROD. NO. MANU. PART NO	. MANUFACTURER	SUPPLIER'S. PART NC	SUPPLIER
K18	-	TEMPERATURE SENSOR	SG590137-000				
M1	۲	HORIZONTAL SCANNING MOTOR	SG590559-101-01				
M2	۲	VERTICAL SCANNING MOTOR	SG590559-101-01				
X3		CONNECTION HARDWARE AS FOLLOWS					
	20	UKK 3-MSTB-5,08		2770888	PHOENIX CONTACT, GERMANY	2770888	PHOENIX CONTACT, SWEDEN
		TERMINAL MARKERS, ZB5,08, NO.S51, 52, 54 - 72		0809803	PHOENIX CONTACT, GERMANY	0809803	PHOENIX CONTACT, SWEDEN
	۲-	UKK 3-MSTB-5,08-PE		1876615	PHOENIX CONTACT, GERMANY	1876615	PHOENIX CONTACT, SWEDEN
		TERMINAL MARKER, ZB5,08, NO. 53		0809803	PHOENIX CONTACT, GERMANY	0809803	PHOENIX CONTACT, SWEDEN
	9	UT 2,5		3044076	PHOENIX CONTACT, GERMANY	3044076	PHOENIX CONTACT, SWEDEN
		TERMINAL MARKER, ZB5, NO.S 85 - 86, 91-94		1050017	PHOENIX CONTACT, GERMANY	1050017	PHOENIX CONTACT, SWEDEN
	-	D-UKK 3-MSTB-5,08		2770891	PHOENIX CONTACT, GERMANY	2770891	PHOENIX CONTACT, SWEDEN
	۲	DP-UKK 3-MSTB-5,08		2770600	PHOENIX CONTACT, GERMANY	2770600	PHOENIX CONTACT, SWEDEN
	4	DG-UKK 3-MSTB-5,08		2770613	PHOENIX CONTACT, GERMANY	2770613	PHOENIX CONTACT, SWEDEN
	-	D-UT 2,5/10		3047028	PHOENIX CONTACT, GERMANY	3047028	PHOENIX CONTACT, SWEDEN
	ς	CLIPFIX 35-5		1201442	PHOENIX CONTACT, GERMANY	1201442	PHOENIX CONTACT, SWEDEN
1	-	MOUNTING FIXTURE	AT 601462				
2	4	LARGE SCANNING MIRROR	AT 606323				
3	۲	SMALL SCANNING MIRROR	AT 600794				
4	۲	DIN MOUNTING RAIL, NX 35/7,5-AL, L = 215		0801704	PHOENIX CONTACT, GFRMANY	0801704	PHOENIX CONTACT, SWEDEN
5	-	TERMINAL BLOCK, MSTBU 2,5/4-STD-5,08		1824146	PHOENIX CONTACT, GFRMANY	1824146	PHOENIX CONTACT, SWEDEN
9	ω	SCREW, ALLEN HEAD, ISO 4762, M5 x 20H					
7	9	SCREW, ISO 4762, M5x12, ZINC PLATED					
8	4	SCREW, ISO 4762, M4x8H, ZINC PLATED					
6	2	SCREW, ISO 7045, M2x6H, ZINK PLATED					
10	9	LOCK WASHER, DIN 127, 9.2x5.1x1.2, ZINC PLATED					

File Name: SG590560-000-01_RVB

ER)TRADE N	DTRADE N	DTRADE N	DTRADE N	DTRADE N
SUPPLIER'S. PART NO. SUPPI	21302G TECHI SWED	21302G TECHI SWED	21302G TECHI SWED	21302G TECHI SWED	21302G TECH
SAFEGATE PROD. NO. MANU. PART NO. MANUFACTURER					
DRAWING NO.					
(DESCRIPTION/RATINGS	LABEL, YELLOW, Text: K18, 15x8	LABEL, YELLOW, Text: K19, 15x8	LABEL, YELLOW, Text:M1, 15x8	LABEL, YELLOW, Text:M2, 15x8	LABEL, YELLOW, Text: X3, 15x8
QUANTITY	4	1	7	2	-
POSITION	12	13	15	16	17



RIC Supplier RIC Supplier International Ant SELL I		Unless otherwise indicated, all Unless otherwise indicated, all tolerances are according to Surface Coarting Surface Coarting (GA TE SIGN GA TE SIGN GA TE SIGN GA TE SIGN GA TE SIGN FOR T1 D0CKING GUIDANCE SYSTEM FOR T1 D0CKING GUIDANCE SYSTEM
Kith Munderturer 24447 MERLIN GERIN/SCHNEIDER ELECT 108 0 700 THEBEN 2775456 PHOENIX CONTACT 3022276 PHOENIX CONTACT 3022276 PHOENIX CONTACT 2022776 PHOENIX CONTACT		SAFFGATE G R O U P G R O U P Safegate International AB MALMÖ, SWEDEN MALMÖ, SWEDEN App. by: Date drawn: Checked by: Approved: Project No.:
Draving No. Stegate Product EEL, OR EQUIV. SG590606-203-01 SG590606-203-01 SG590606-203-01 EEL, OR EQUIV. SG590606-204-01 AT 605283 AT 605283 O NGTH: 700 mm IAL LENGTH: 550 mm IAL LENGTH: 550 mm	ERONT VIEW, DOOR REMOVED	Tet I
bescription/Ratings CIRCUIT BREAKER, C60N, 6A-TYPE C TWILIGHT SWITCH, LUNA 108 TWILIGHT SWITCH, LUNA 108 CABINET ASSEMBLY REFLECTOR AND LAMP ASSEMBLY GROUND TERMINAL, UDK3.PE, OR EQUIV. DIN RAIL CLIPFIX 35-5 OR EQUIV. BLIND POP-RIVET, 3,2x8LF, ALUMINUM/STE LOCKNUT, DIN 982, M6, ZINC PLATED LOCKNUT, DIN 934, M6, ZINC PLATED LOCKNUT, DIN 934, M6, ZINC PLATED LOCKNUT, MON, NUT, M20, NYLON DAM NUT, M20, NYLON DAM NUT, M20, NYLON JAM NUT, M20, NYLON DAM NUT, M20, NYLON MUT, JOIN 934, M6, ZINC PLATED CLAMP CLAMP NUT, ISO 4032, M12, GAL VANIZED WIRING MATERIALS AS FOLLOWS ELECTRICAL WIRE, H05V-K, 0,5 mm2, BROWN, TOTAL LEF <		Revision
Quantity 0<		









	E SIGN									
								Unless otherwise indicated, all tolerances are according to	Sharp Edges	
								Surface Coating	Weight	
						Safegate Int MALMÖ	ernational AB SWEDEN	GATE SIGN FOR T1 DOCKING GUIDANCE SYSTEM CONNECTION DIAGRAM		
					Jrawn by: J.O.	Date drawn: 2009.04.03	Checked by:	SEE SG590606-001-01 FOR ASSEMBLY		
_	Date	Drawn by:	Checked by:	Approved	Арр. by:	Date approved:	Project No.:	Drawing No. Sheet Sheet Sheet Sheet Sheet Sheet Sheet SG590606-004-01 at 1 of 1	Scale	





NOTES:

Supplier	ELFA			ELFA						ELFA	ted, all Sharp Edges	ng to Weight
Supplier's Stock Number	33-551-53			<u> </u>						14-c00-cc 55-316-78	 Unless otherwise indicat 	tolerances are according Surface Coating
Manufacturer PHILIPS	OSRAM	VOSSLOH-SCHWABE	VOSSLOH-SCHWABE									SAFEGATE
te Product No. Manufacturer's Part No. 63147340		101647	101643									
Drawing No. Safega		SG590606-200-01 SG590606-201-01										
Pescription/Ratings FLUORESCENT LAMP, MASTER TL-D SUPER 80 16W/840 1SL, OR EQUIV.	HF CONTROL GEAR, QTi 2x14/24/21/39	kefel ur/muuninug plate LAMPHOLDER BRACKET LAMPHOLDER, 46101	LAMPHOLDER, 46100	KUBBEK UKUMMEI, JUX14 SCRFW DIN7985 MLV10 ZINC DI ATFD	LOCKNUT, DIN 985, M4, ZINC PLATED	SCREW, DIN7985, M3x25, ZINC PLATED	SCREW, DIN7985, M3x16, ZINC PLATED	LOCK WASHER, DIN 6798A, 3.7x7x0.5, ZINC PLATED	NUI, UN 934, M3, ZINC PLAIEU	ELECTRICAL WIRE, H05V2-U, 0,5mm2, T0TAL LENGTH = 8,8 m, 0R EQUIV.		
ltem luanriry L1-L4 4	K2-K3 2	2 8 4 4	4 4	2 8 C	7 20	8	9 8	10 16	11 16	7 7		

Note: The electrical wiring is to be run between the electronic control gear and the Lamp Holders on the Back surface of the reflector/mounting plate . Anchor the wires away from protruding screws/nuts with tape at several points to prevent the wires from being pinched when the assembly is installed in the Cabinet.

ان

 SEE SG590606-203-02 FOR CONNECTION DIAGRAM

 Drawing No.
 Rev.
 Sheet
 Scale

 SG590606-203-01
 Rev.
 I of 1
 1

⊕ ∏

Checked by:

: Date drawn: 2009.04.05 Date approved:

Drawn by: G.O. App. by:

Drawn by: Checked by: Approved

Date

Safegate International AB MALMÖ, SWEDEN Project No.:

		ıarp Edges	eight	~	Scale	
		less otherwise indicated, all Serances are according to	rface Coating	EFLECTOR AND LAMP ASSEMBL' NNECTION DIAGRAM	E SG590606-203-01 FOR ASSEMBLY awing No. Rev. Sheet 1.55 G 0 6 0 6 - 2 0 3 - 0 7 8 - 0 1 - 2 - 5 - 1 - 2 - 5 - 1 - 2 - 5 - 5 - 5 - 5 - 5 - 5 - 5 - 5 - 5	
				Safegate International AB MALMÖ, SWEDEN	awn by: Date drawn: Checked by: 0. 2009.04.05 Checked by: p. by: Date approved: Project No: C	2
					Dr G. Date Drawn by: Checked by: Anoroved Ap	Uzeren uy: Linecheu uy: Approveu
	REFLECTOR AND LAMP ASSEMBLY					

	STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
XT: K4	Option (NS)	AII					
XT: K10	Option (NS)	AII					
	Option (NS)	AII	SG590258-101-01				
	Option (NS)	AII		2891453	PHOENIX CONTACT		
	Option (NS)	AII		2881007	PHOENIX CONTACT		
	Option (NS)	AII		3053 RED	ALPHA WIRE	55-229-25	ELFA
	Option (NS)	AII		9026060000	WEIDMÜLLER		
	Option (NS)	AII		PA-02	PARTEX		
	Option (NS)	AII		3053 BLACK	ALPHA WIRE	55-229-09	ELFA
	Option (NS)	AII		9026060000	WEIDMÜLLER		
	Option (NS)	AII		PA-02	PARTEX		

						Basic material		
				Airfeed Leybing	SAFEGATE		Info	
				A SHOW		€		
				Drawn by:	Date drawn:	Description		
				e.C.	CZ-11-0002	NFTWOR	K SWITCH - OPTION	(SN)
				Annroved hv.	Date annroved:			
2014-09-16	V.N.		Filter (K10) now included in NS option.			T1/T1S/T2	2/T3	
2011-11-11	A.S.		Connection diagram removed.	Project No.	Drawing No.	Rev.	Scale Size	Sheet
ssue date Is	sue by I	ssue checked by	Issue text		SG590611-001-01	ш	NO SCALE A3	1(1)

E D Rev.

Surface treatment

Gen. tolerance

	LOW 15x8 mm, TEX	LOW 15x8 mm, TEX	EN 4TX/FX ST	AT.6+	L=400		:K, L=400		D D 53	3) 	 UU				, ,			0 mm
DESCRIPTION	COMPONENT IDENTIFIER LABEL, YE	COMPONENT IDENTIFIER LABEL, YE	PAICH CABLE CAIS NETWORK SWITCH EL SWITCH S	CAT6 TRANSIENT FILTER, D-LAN-	WIRE, UL1007/1569, AWG 20, RED CRIMP LUG H0.5/14	WIRE MARKERS, MARKING - 23	WIRE, UL1007/1569, AWG 20, BLAC CRIMP 11G H0 5/14	WIRE MARKERS, MARKING - 22	Wire numbering:		M3			X1	X2	X3	44 1	74	
QTY	~ ·	- c	v +		0		~	L											
POS	- (0 0	5 К4	K10	W3		W4												

ltem	Quantity	Description/Ratings
K71	-	HEATING ELEMENT, 110-230 V AC, 50
Ļ	1	Ölflex Control 3G1,0mm², L = 2300 m
 _		Ölflex Control 3G1,0mm², L = 2100 m
2	4	INSULATED FERRULE, E2512-BLUE
3	4	WIRE MARKERS, PARTEX PA02/3
		y
		<u>NOTE 1</u> MARK BOTH ENDS OF EACH WIRE AC
		NUTIBERING SHUWN ABUVE. SYMBOL MANF, PART NO. SUPP 1 11-0104,0101 2980
		5 11-01040105 2980 6 11-01040106 2980
		D BOM changed now vali
		C Unmounted cable adde B Unmounted cable adde
		Revision Description

Position	Quantity	Description	Drawing Number	Model	Manufacturer	Supplier's. Part No.	Supplier
K16	.	Light Sensor Assembly	SG590619-101-01	ALL			
K71	~	Heater Assembly	SG590616-001-01	ALL			
~	~	Mounting Plate	SG590619-200-01	ALL			
2	-	Cable Clamp		ALL		310018	Bejoken AB
3	7	Screw, ISO7049, ST2.9x13, zink plated		ALL			
4	2	1/4 Turn Fastener		ALL		316411190	Aero Material
5	N	Washer		ALL		326100040	Aero Material
9	5	Anchor, SCF1, Snap-On, For Quick Tie		ALL		1516442	Ahlsell
7	5	Quick Tie, T18R, Black, 104x2,5		ALL		1516055	Ahlsell
ω	~	Label, Yellow, Text: K16, 15x8		ALL		21302	Technotrade
6	-	Label, Yellow, Text: K71, 15x8		ALL		21302	Technotrade
10	4	Bolt, ISO 4017, M6x16, Zinc Plated		ALL			
11	4	Lock Nut, DIN 985, M6, Zinc Plated		ALL			
12	2	Lock Washer, DIN 6798A, AZ 6,4		ALL			
13	2	Ground Strap, A=16, L=200		ALL		55-097-57	ELFA
14	-	DIN RAIL, NS 35/7,5 PERF	SG590616-100-01	ALL			
15	5	Popnit BIG HEAD 3,2x7,9		ALL			
16	2	Back Plane PCB		ALL			
17	30	M3x8 DIN 7984, Zink Plated		ALL			
18	30	Lock Washer, M3 DIN 6798		ALL			
19	10	LED PCB Y-R, 16x16		ALL		SGA908-210656LF	
20	9	LED PCB Y, 16x16		Т2-18		SGA908-211289LF	
21	12	LED PCB, BLIND		T2-18		SGA908-211356LF	
20	12	LED PCB Y, 16x16		T2-24		SGA908-211289LF	
21	Q	LED PCB, BLIND		T2-24		SGA908-211356LF	

	50	5	
0			
	0 0		19
0			

5

DISPLAY T2

Uate drawn: 2011.10.1 Date approved

A.Stl

A.S K.J Issue

2011-02-10 2011-12-07 Issue date

BB PC State

awing No. 90619-

	Г П П П П П П П П П П П П П П П П П П П			┣━━━━┓
				⊩
			~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	
0				
			<i>~~~~~~~~~~~~~</i> <i>~~~~~~~~~~~~~~~~~~~</i>	
			~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	
			••••••••••••••••••••••••••••••••••••••	
			• • • • • • • • • • • • • • • • • •	
			• • • • • • • • • • • • • • • • • • <i>• • • • • • • • • • • • • • • • • • •</i>	
			••••••••••••••••••••••••••••••••••••••	
	<u> </u>	 		
			· · · · · · · · · · · · · · · · · · ·	
			· · · · · · · · · · · · · · · · · · ·	
			· · · · · · · · · · · · · · · · · · ·	
			· · · · · · · · · · · · · · · · · · ·	
			· · · · · · · · · · · · · · · · · · ·	
	• • • • • • • • • • • • • • • • • • •		· · · · · · · · · · · · · · · · · · ·	
			• • • • • • • • • • • • • • • • • • •	
			· · · · · · · · · · · · · · · · · · ·	
			• • • • • • • • • • • • • • • • • • •	
		• • • • • • • • • • • • • • • • • • •		
			• • • • • • • • • • • • • • • • • * * * * * * * * * * * * * * * * * * *	
			• • • • • • • • • • • • • • • • • •	
	/			
	/		* * * * * * * * * * * * * * * * * *	
	/			
			• • • • • • • • • • • • • • • • • •	
			[<i>~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~</i>	
	/		۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵۵	
	/		> > > > > > > > > > > > > > > > > >	
	/		<i>^ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~</i>	
0	/			
	/	f l	۲۰۰۰٬۰۰٬۰۰٬۰۰٬۰۰٬۰۰٬۰۰٬۰۰٬۰۰٬۰۰٬۰۰٬۰۰٬۰۰	
	· · · · · ·	/	អត់សត់សត់សត់សត់សត់សត់សត់សត់សត់សត់សត់សត់សត	11

T2-18

T2-24

ltem	Quantity Description/Ratings	Drawing No.	Safegate Product No. Ma	nufacturer's Part No.	Manufacturer	Supplier's Stock Number	Supplier	
_	1 CABLE, LIYY, 3x0.34mm ²				-	7852030	NOVUM, SWEDEN	
2	1 CONTACT, MC 1.5/3-ST-3.81		1	303581	PHOENIX CONTACT. GERMANY	1803581	PHOENIX CONTACT. SWEDEN	
m	1 CONTACT		0	-925366-3	AMP, USA			
t	1 LIGHT SENSOR			SL 235R	TADS, USA			
5	3 CRIMP TERMINALS			-141708-1	AMP, USA			
9	3 CRIMP TERMINALS, H 0.34/12		6	025790000	WEIDMULLER, GERMANY	9025790000	WEIDMULLER, SWEDEN	
7	2 SHRINK WRAP, L = 20					55-070-25	ELFA, SWEDEN	
	The second secon				5		35 GREN BROWN	
						Unless otherwise indicat tolerances are accordinc	ed, all Sharp Edges to	
					SAFEGATE	Surface Coating	Weight	
					G R O U P Safegate International AB MALMÖ, SWEDEN	LIGHT SENSO 12/13	R ASSEMBLY	
				Dra A.S	wn by: Date drawn: Checked by:			
	Revision Description	Date	Drawn by:	App Checked by: Approved	. by: Date approved: Project No.:	Drawing No. SG590619–1	01-01 Rev. Sheet Scale 1 of 1 NONE	

						RAL 9017			
						Basic material			
				NACHT		Aluminium She	et EN1050-H	14 t=2,5	
				Airfield Lighting	C R O U P	∎ <mark>u</mark> (
				NI-MAN		5 ₽ 1)	harp Edges F	2=0,5	
				Jrawn by:	Date drawn:	Description			
				A Ctrondborg	0011 07 00				
				A.Oualuberg	77.10.1107			í	
				unroved hv.	Date annroved:				
				. 6			- - - - - - - - - - - - - - - - - - -	1	
				Project No.	Drawing No	Rev	ale Si	26	Sheet
									,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
Issue date	Issue by	Issue checked by	Issue text		590619-200-01	PA	0,500	AO	1(1)

893

Position	Quantity	Description	Drawing Number	Model	Manufacturer	Supplier's. Part No.	Supplier
K16	~	Light Sensor Assembly	SG590619-101-01	ALL			
K71	~	Heater Assembly	SG590616-001-01	ALL			
~	~	Mounting Plate	SG590620-200-01	ALL			
2	~	Cable Clamp		ALL		310018	Bejoken AB
3	7	Screw,ISO7049, ST2.9x13, zink plated		ALL			
4	2	1/4 Turn Fastener		ALL		316411190	Aero Material
5	2	Washer		ALL		326100040	Aero Material
6	8	Anchor, SCFI, Snap-On, For Quick Tie		ALL		1516442	Ahlsell
7	8	Quick Tie, T18R, Black, 104x2,5		ALL		1516055	Ahlsell
8	~	Label, Yellow, Text: K16, 15x8		ALL		21302	Technotrade
6	. 	Label, Yellow, Text: K71, 15x8		ALL		21302	Technotrade
10	4	Bolt, ISO 4017, M6x16, zink plated		ALL			
11	4	Lock Nut, Din 985, M6, zink plated		ALL			
12	0	Lock Washer		ALL			
13	Ţ	Ground Strap, A=16, L=200		ALL			
14	~	DIN RAIL, NS 35/7,5 PERF	SG590616-100-01	ALL		55-097-57	ELFA
15	2	Popnit BIG HEAD, 3,2x7,9		ALL			
16	-	Back Plane, PCB		ALL			
17	15	M3x8, DIN 7984, Zink Plated		ALL			
18	15	Lock Washer, M3, DIN 6798		ALL			
19	-	LED PCB, Half Y Left, Half R Right, 8x8		ALL		SGA908-211291LF	
20	~	LED PCB, Half Y Right, Half R Left, 8x8		ALL		SGA908-211292LF	
21	2	LED PCB, Y, 8x8		T3-9		SGA908-210658LF	
22	9	LED PCB, BLIND		Т3-9		SGA908-211356LF	
21	13	LED PCB, Y, 8x8		Т3-15		SGA908-210658LF	

T3-15

			2							19																																		
, , , ,		0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0	0 0 0 0	0 0 0 0	•	0 0 0	0 0 0		0 0 0 0	0 0 0	0 0 0 0	0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0										
	0 0 0 0 0	0 0 0 0	0 0 0 0	0 0 0	0 0 0 0	0 0 0	0 0 0 0	0 0 0		0 0 0	° ° °	0 0 0	。 。 。 。	0 0 0	0 0 0	0 0 0	0 0 0	0 0 0	0 0 0	0 0 0	0 0 0 0	-																						
	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0		0 0 0 0	0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0			SCALE 0,500																
	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0	0 0 0 0	0 0 0	 	0 0 0	• • •	。 。 。 。	0 0 0 0	0	• • • •	0 0 0 0	0 0 0	0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0															
		。 。 	0 0 0	0 0	0 0	0 0	0 0	0 0	0	0 0	。 。 。	•	° 7 •	0 0		0 0	•	0 0	。 。	0 0	0 0	0 0	0 0	0 0	0 0	0	0 0	0 0	0 0	0 0 	0 0	0 0	0 0	0 0 0	0 0	0 0	0 0	0 0	0 0	0 0	0			
											50																																	
		3 3		0	*	0	0	0			19)	*	0		22	•																										╢	
(- (0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	. 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	•		。 。 。		,																							۲		
	0 0 0 0 0	0 0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0		0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	, , , ,	0 1 0 1 0 1	。 。 。	• • •	0 0 0	0 0 0	0 0 0	0 0 0	0 0 0	0 0 0	0 0	0		0 0 0	0 0 0	•	0 0 0	0 0 0	0 0 0	- - - - -	0 0 0	0 0 0	0 0 0	0 0 0		0 0 0	0 0 0			
	0 0	0 0 0	0 0 0	0 0 0	0 0 0	•	0 0 0	0 0 0	0 0	0 0 0	0 0 0	0 0 0	0 0 0	• • •			o o	0 0 0	0	0 0 0	•	0 0 0	0 0 0	0 0	0 0 0	0 0 0	0 0 0	0 0 0			SCALE 0,500													
	•	0	0	•	0	0	0	• •		0 0	0 0	0	0 0	0		0 0	•																				•	•	•	• 	• 			- /

Sheet 1(1)

P0

0,333

BISPLAY T3 Rev. PE 0,

> Drawing No. 590620-001-01

Date drawn: 2011.10.18 Date approved:

Drawn by: A.Stran Approved b

> BOM cha BOM cha Type of L Issue text

A.Strandberg K.Johansson A.Strandberg A.Strandberg

PE 2012-02-10 / PD 2011-12-08 / PC 2011-11-15 / PB 2011-10-21 // Issue No. issue date //

T3-9

5X

ltem B1 B2	Quantity 1	Description/Ratings UPS-BAT/NRLA/24DC/7,2AH QUINT-ADAPTER/4	standard/Option Dption (UPS) Dption (UPS)	T1/T1S/T2/T3 T1/T2/T3 T1/T2/T3	Drawing No.	Manufacturer's Part No. 2320319 2866857	Manufacturer PHOENIX CONTACT PHOENIX CONTACT	Supplier's Stock	No. Supplier
C11 C13	~ ~ ~	COMMUNICATION CABLE COMMUNICATION CABLE POWER CABLE ASSM., DISPLAY	standard Standard Standard	T1/T1S T2/T3 T1/T1S/T2/T3	SG590621-114-01 SG590621-119-01 SG590621-112-01				
C14 C1	<u></u>	POWER CABLE ASSM., DISPLAY CONTROL CABLE	standard standard standard	T1/T1S/T2 T1 T1S	SG590621-113-01 SG590621-125-01 SG590621-123-01				
C2 C19		CONTROL CABLE CONTROL CABLE	standard	T1 T1S	SG590621-126-01 SG590621-124-01				
C3 C26	~ ~ ~ ~	CONTROL CABLE CONTROL CABLE MILITICABLE	standard Standard	T1 T1S T1	SG590621-118-01 SG590621-131-01 SG500621-127_01				
C24	,	MULTI CABLE	standard	11 T1S	SG590621-127-01				
C2 C6		CONTROL CABLE CONTROL CABLE CONTROL CABLE	standard Standard Standard	12/13 T2/T3 T2/T3	SG590621-101-01 SG590621-102-01 SG590621-103-01				
C8 F1	~ ~	POWER CABLE CIRCUIT BREAKER	standard Standard	T2/T3 T1/T1S/T2/T3	SG590621-104-01	MG24522	SCHNEIDER ELECTRIC		
J11		WIRING ASSEMBLY WIRING ASSEMBLY	standard Standard	T1/T1S/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3	SG590621-105-01 SG590621-106-01 SC500624 407 04				
J17 J18	~	WIRING ASSEMBLY WIRING ASSEMBLY WIRING ASSEMBLY	otanuaru Standard Standard	T1/T1S/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3	SG590621-107-01 SG590621-108-01 SG590621-110-01				
J19 J29		WIRING ASSEMBLY WIRING ASSEMBLY	standard standard	T1/T1S/T2/T3 T1/T1S/T2/T3	SG590621-115-01 SG590621-120-01				
조		OVERVOLTAGE PROTECTOR VAL-MS-230/1+1-FM	standard	T1/T1S/T2/T3		2804432	PHOENIX CONTACT		
K2		OVERVOLIAGE PROTECTOR PT-IQ-PTB-PT END STOP EMAE TRUS NS35.GV	standard	T1/T1S/T2/T3 T1/T1S/T2/T3		2801296 2713780	PHOENIX CONTACT		
K3	-	DVERVOLTAGE PROTECTOR PT-IQ-5-HF-5DC-PT	standard	T1/T1S/T2/T3		2801291	PHOENIX CONTACT		
K4-K5	0	OVERVOLTAGE PROTECTOR PT-IQ-4X1-24DC-PT	standard	T1/T1S/T2/T3		2801271	PHOENIX CONTACT		
K12	~ ~	END STOP E/ME TBUS NS35 GY SAFEDOCK CONTROL UNIT	standard Standard	T1/T1S/T2/T3 T1/T1S/T2/T3	SG590587	2713780	PHOENIX CONTACT		
K14 K90		STEPPER MOTOR DRIVE CIRCUIT QUINT-UPS/24DC/24DC/40	Standard Dption (UPS)	T1/T1S/T2/T3 T1/T1S/T2 T0	SG590131-001-01	2320241	PHOENIX CONTACT		
	- ~	RELAYS PICRFIAY PIC-RSC-24DC/21HC	Jption (UPS) standard	13 T2/T3		2320238	PHOENIX CONTACT		
R0-R1		BRIDGE, FB ST 500-PLC RD TERMINAL MARKER, ZB 10, SO/CMS R0-R1	standard	T2/T3 T2/T3		2966786 1050525	PHOENIX CONTACT PHOENIX CONTACT		
R2-R3	N	RELAYS PLC RELAYS, PLC-RSC-24DC/21	standard	T2/T3		2966171	PHOENIX CONTACT		
		TERMINAL MARKER, ZB 6, SO/CMS R2-R3 RELAYS	standard	T2/T3		1050499	PHOENIX CONTACT		
R4-R5	7	PLC RELAYS, PLC-RSC-24DC/21 BRIDGE, FB ST 500-PLC RD	standard standard	T1/T1S/T2/T3 T1/T1S/T2/T3		2966171 2966786	PHOENIX CONTACT PHOENIX CONTACT		
		TERMINAL MARKER, ZB 6, SO/CMS R4-R5 END STOP, CLIPFIX 35-5	standard	T1/T1S/T2/T3 T1/T1S/T2/T3		1050499 3022276	PHOENIX CONTACT PHOENIX CONTACT		
R6	~	PLC RELAY, PLC-RSC-24DC/21 TERMINAL MARKER, ZB 6, SO/CMS R6	Dption (Heater) Dption (Heater)	T2/T3 T2/T3		2966171 1050499	PHOENIX CONTACT PHOENIX CONTACT		
E E	~ ~	END STOP, CLIPFIX 35-5 QUINT-PS/1AC/24DC/40	Dption (Heater) Standard	T2/T3 T1/T2		3022276 2866789	PHOENIX CONTACT PHOENIX CONTACT		
	<u> </u>	QUINT-PS/1AC/24DC/20	Standard	T3 T4/T4/C/T2/T2		2866776			
× X	~	TERMINAL CONTACT, UT 4-1 WIN TERMINAL CONTACT, UT 4-TWIN BU TERMINAL CONTACT, UT 4-TWIN PE	standard Standard Standard	T1/T15/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3		3044304 3044500 3044380	PHOENIX CONTACT PHOENIX CONTACT PHOENIX CONTACT		
	7 7	END, COVER, D-UT 2,5/4-TWIN END STOP, CLIPFIX 35-5	standard standard	T1/T1S/T2/T3 T1/T1S/T2/T3		3047141 3022276	PHOENIX CONTACT PHOENIX CONTACT		
		TERMINAL MARKER, ZB 6, LGS:L1, N, PE,PE TERMINAL CONTACT GROUP	standard	T1/T1S/T2/T3		1051414	PHOENIX CONTACT		
X2	4 - 0	TERMINAL CONTACT, UT 2,5 END, COVER, D-UT 2,5/10 END STOP CLIPELX 35-5	standard Standard	T1/T1S/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3		3044076 3047028 3022376	PHOENIX CONTACT PHOENIX CONTACT		
	J	TERMINAL MARKER, ZB 5, NOS, 1-14 TERMINAL CONTACT GROUP	standard	T1/T1S/T2/T3		1050017	PHOENIX CONTACT		
X4	7 17	TERMINAL CONNECTOR, DIKD 1,5-PV END STOP, CLIPFIX 35-5	standard Standard	T1/T1S/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3		2715092 3022276 4064444	PHOENIX CONTACT PHOENIX CONTACT		
	4	TERMINAL CONTACT GROUP TERMINAL CONTACT, UT 4-TWIN	standard	T1/T1S/T2/T3		3044364	PHOENIX CONTACT		
	c	TERMINAL CONTACT, UT 4-TWIN-PE END, COVER, D-UT 2,5/4-TWIN	standard Standard	T1/T1S/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3		3047141 3030326	PHOENIX CONTACT PHOENIX CONTACT		
X5	v	TERMINAL MARKER, ZB 6, NOS, 24-27 TERMINAL MARKER, ZB 6, LGS: PE	standard Standard Standard	T1/T1S/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3		3030330 1051016 1051414	PHOENIX CONTACT PHOENIX CONTACT		
	ლ .	TERMINAL CONNECTOR, DIKD 1,5-PV TERMINAL MARKER, ZB 6, NOS, 21-23	standard standard	T1/T1S/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3		2715092 1051016	PHOENIX CONTACT PHOENIX CONTACT		
		TERMINAL CONTACT GROUP TERMINAL CONTACT GROUP TERMINAL CONNECTOR, DIKD 1,5-PV	otandard Dotion (Heater)	T2/T3		3022270 2715092	PHOENIX CONTACT		
٥x	~	END STOP, CLIPFIX 35-5 TERMINAL MARKER, ZB 6, LGS:L1, N	Dption (Heater) Dption (Heater)	T2/T3 T2/T3		3022276 1051414	PHOENIX CONTACT PHOENIX CONTACT		
:		WIRING MATERIALS FOR ITEMS NOT SPECIFIED ELSEWHERE MAINS WIRE: UL 1007/1569, AWG 16, BROWN NFUTRAL WIRE: UL 1007/1569, AWG 16, BLUF	standard	T1/T1S/T2/T3 T1/T1S/T2/T3					
		GROUND WIRE: UL 1007/1569, AWG 16, YELLOW/GREEN WIRE WITH END MARKING: (22-24) UL 1007/1569, AWG 20, BLACK	standard	T1/T1S/T2/T3 T1/T1S/T2/T3					
		WIRES WITH END MARKINGS: (23-26), (115-115), (120-120), (129-129) UL 1007/1569, AWG 20, RED WIRES WITH FND MARKINGS: (125-125)	standard	T1/T1S/T2/T3					
		ELECTRICAL WIRE, UL 1007/1569, AWG 16, BLACK WIRES WITH END MARKINGS: (127-127), III 1007/1569 AMG 16, RED	standard Standard	T1/T15/12/13 T1/T1S/T2/T3					
		UL 1063, AWG 12, BLACK	standard	T1/T1S/T2/T3					
		WIRES WITH END MARKINGS: (27-27), (117-117), (119-119) UL 1063, AWG 12, RED	standard	T1/T1S/T2/T3					
		BOOTLACE FERRULE FOR AWG 20 WIRE: H 0,5/14 BOOTLACE FERRULE FOR AWG 16 WIRE: H 1,5/14	Standard Standard	T1/T1S/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3				9026060000 9026090000 90244400000	WEIDMÜLLER WEIDMÜLLER
		BOOTLACE FERRULE FOR AWG 10 WIRES. II 2X1,3 BOOTLACE FERRULE FOR AWG 12 WIRE: H 4/18 (WIRES FROM Power supple, ups and battery)	standard	Т1/Т1S/T2/T3				9019210000	WEIDMÜLLER
1005		WIRE MARKERS: PARTEX PA02 OR EQV. NUMBERS AS PER CONNECTION DIAGRAM CPOILIND WIPE	Standard	T1/T1S/T2/T3 T1/T1S/T2/T3	S.G.500.621_121_01				
GW2 1		GROUND WIRE CONTROL & POWER MOUNTING PLATE	standard Standard	T1/T1S/T2/T3 T1/T1S/T2/T3	SG590621-121-01 SG590621-122-01 SG590621-203-01				
- 0 0		CONTROL & POWER MOUNTING PLATE CU-COVER STEPDED MOTOD CADD LICITIED	Dption (SC) Standard	T3 T1/T1S/T2/T3 T1/T1S/T2/T3	SG590621-206-01 48000372 SC500621 200 01				
s SZ		DIN RAIL MOUNTING BRACKET	Diption (NS) Diption (NS)	T1/T15/T2/T3 T1/T1S/T2/T3 T1/T1S	SG590611-001-01	5503655	PHOENIX CONTACT	5503655	PHOENIX CONTACT, SWEDEN
UT(x)		FILTER, CAT6 UTILITY OUTLET	Dption (NS) Dption (UT)	T1/T1S/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3	SG590262-001-01 SG590266-001-01				
K52 IO R29	~ ~ ~	POE SWIICH, FL PSE 21X I/O MODULE RELAY, Z7-R230/SO	Dption (CM) Dption (IO) Dption (IO)	11/11S/12/13 T1/T1S/T2/T3 T1/T1S/T2/T3	SG590612-001-01 SG590623-001-01	FL PSE 21X 3290758	PHOENIX CONTACT GYCOM	FL PSE 21X	PHOENIX CONTACT, SWEDEN
K38	~	AUXILIARY CONTACT, C60 3A AT 415V CONNECTION HARDWARE AS FOLLOWS	Dption (IO)	T1/T1S/T2/T3		26924	SCHNEIDER ELECTRIC	26924	SCHNEIDER ELECTRIC
X7	12 2	TERMINAL CONNECTOR, KNIFE DISCONNECT TYPEUDMTK 5-P/P END STOP, CLIPFIX 35-5 TERMINAL MARKERS AR + NO S 201-224	Dption (IO) Dption (IO) Detion (IO)	T1/T1S/T2/T3 T1/T1S/T2/T3 T1/T1S/T2/T3		3101087 3022276 1051016	PHOENIX CONTACT PHOENIX CONTACT PHOFNIX CONTACT	3101087 3022276 1051016	PHOENIX CONTACT, SWEDEN PHOENIX CONTACT, SWEDEN PHOENIX CONTACT, SWEDEN
K6 K13		CONVERTER, RS232 - RS485, 10-30VDC FAN, DISPLAY CABINET ASSM.	Detion (PBB) Standard	T1/T1S/T2/T3 T2/T3	SG590585-001-01 SG590625-001-01	485LDRC9 3414NG	EBMPAPST		
	7 14 14	CONNECTION HARDWARE AS FOLLOWS TERMINAL CONTACT, UT 2,5-3L	standard	T1S		3214259	PHOENIX CONTACT	3214259	PHOENIX CONTACT, SWEDEN
X8	- 0	END COVER, D-UT 2,5-3L END STOP, CLIPFIX 35-5 TERMINAL MARKERS, ZB 5, 51-52, 56-84, 87-90, 110-111, 172-174 + SHIELDS.	standard standard standard	T1S T1S T1S		3214314 3022276 1050004	PHOENIX CONTACT PHOENIX CONTACT PHOENIX CONTACT	3214314 3022276 1050004	PHOENIX CONTACT, SWEDEN PHOENIX CONTACT, SWEDEN PHOENIX CONTACT, SWEDEN
	2 ROUTING	I OW VOI TAGE CABLES							
) - 1									Gen. tolerance Surface treatment
			4-10-22	<u> </u>	ables C1 and C2 chanced and updated v	th new drawing numbers. K13 removed for T1/T1S.	RIGHT DIGITAL	SAFEGATE -	Basic material
		8 20 8 20	4-03-07 K.Johansson 3-12-17 A Strandberg ~ 4 12 K.Johansson		ption (FI) removed and the filter is now in art number K2 changed	uded in Option (NS). מוווידי הייינייי א אוז איז איז איז איז איז איז איז איז איז אי	Drawn by: A. Strandberg	Date drawn: 2011-08-23	
		P 20	3-11-13 N.Junausour 3-09-30 K.Johansson		6 removed. Rearranging un uninpunum. 1 changed from MG24447 to MG24522 (* 4 Vr mmu Mition FC removed. Corre	Aounting bracket (NS) addeu. כט כטיפו עעימופע. 0A) נויד ברעד אמני מר	Approved by:	Date approved:	CONTROL_AND_POWER_ASSEMBL
				- 1 J.E		טוטיד טייד טייא היי.		DIAWIIY INU.	

						Basic material			
				NACHT					
				Arrison Lighting	C C O U P		nfo		
				Andaro		₽			
				Drawn by:	Date drawn:	Description			
				Approved by:	Date approved:	CONIKO	L_ANU_F	OWERA	SEMBLY
				Project No.	Drawing No.	Rev.	Scale	Size	Sheet
Issue date	Issue by	Issue checked by	Issue text		SG590621-001-01		0,700	AO	2(2)

CABINETS WITH SUPER COOLERS

Dae crintion (Damine	CABLE, CYLIYCY, 8 x 2 x 0.25	CONNECTOR, MC1.5/10-ST-3.81	CONNECTOR, MC1.5/6-ST-3.81	HEAT SHRINKABLE TUBING, Ø9.5, BI	CRIMP LUG, H 0.25/12	WIRF MARKFRS PARTFX PA07	LABEL, SK 3,81/2,8: SO, TEXT: J22	LABEL, SK 3,81/2,8: S0, TEXT: J13		Revision Description
Outstitv		-	-	2	26	_	-	-	I BROWN (59) I BROWN (59) I WHITE (60) I WHITE (60) I BLUE (62) I BLUE (62) I BLUE (62) I BLUE (62) I BLUE (63) I BLUE (64) I BLUE (65) I BLUE / RED (63) I BLUE / RED (63) I BLUE / RED (76)	
tem t		2	۲ ۲	4	ر ۲	0	8	6	N (70) (71)	

m Quantity Description/Ratings	1 CONNECTOR, MCI.5/6-ST-3.81 2 HEAT SHRINKABLE TUBING, Ø9.5, I 26 CRIMP LUG, H 0.25/12 1 CRIMP LUG, H 1.5/14 mile markers, partex pao2 1 LABEL, SK 3,81/2,8: S0, TEXT: J15 1 LABEL, SK 3,81/2,8: S0, TEXT: J20 1 LABEL, SK 3,81/2,8: S0, TEXT: J15 1 LABEL, SK 3,81/2,8: S0, TEXT: J15 1 LABEL, SK 3,8: S0,		
i connection, million, age, i i connection, age, i i label, so, i i connection, ade, i i connection, add, add, i </td <td></td> <td></td> <td>-</td>			-

ltem	Quantity	Description/Ratings	Drawing No. Safegat	te Product No. Manufacturer's Part No.	Manufacturer	Supplier's Stock Number	Supplier	
	-	CABLE, CYLIYCY, 8 × 2 × 0.25						
2	-	CONNECTOR, MC1.5/6-ST-3.81		1803617	PHOENIX CONTACT, GERMANY	1803617	PHOENIX CONTACT, SWE	EDEN
3	—	CONNECTOR, MC1.5/4-ST-3.81		1803594	PHOENIX CONTACT, GERMANY	1803594	PHOENIX CONTACT, SWE	EDEN
5	2	HEAT SHRINKABLE TUBING, Ø9.5, BLACK		FIT-221-3/8	ALPHA WIRE	5507108	ELFA, SWEDEN	
9	18	CRIMP LUG, H 0.25/12		9025780000	WEIDMÜLLER, GERMANY	9025780000	WEIDMÜLLER, SWEDEN	
L		WIRE MARKERS, PARTEX PA02		SEE NOTE	WEIDMÜLLER, GERMANY	SEE NOTE	WEIDMÜLLER, SWEDEN	
8		LABEL, SK 3,81/2,8: S0, TEXT: J12		0805056	PHOENIX CONTACT, GERMANY	0805056	PHOENIX CONTACT, SWE	EDEN
6	-	LABEL, SK 3,81/2,8: S0, TEXT: J8		0805056	PHOENIX CONTACT, GERMANY	0805056	PHOENIX CONTACT, SWE	EDEN
				1350			Ĩ	
						350		
						6		
						ĺ		
		BBT DOM/M/GDEEN (88)						
				•				
		SZT YELLOW (S6)]	_			DE O WHITE (52)	
		511 BROWN (51)		(-	(ı			
		-(9)						
)					$\left(2\left(8\right)\right)$	
		2002)	
		NOTE FOR WIRE MARI	<u>(ERS</u>					
		NO. PART NO.	QTY.					
		0 11-01044100	, ,					
		Z 11-0104410Z	7					
		CO144010-11 C 6 11-01044106	2			Unless otherwise inc	dicated, all	Sharp Edges
		7 11-01044107	4		SAFEGATE,	Surface Coating	ang ro	Weight
		8 11-01044108	10		4 7 0 8 0 8 0		L - -	
		9 11-01044109	4		Safegate International AB	LUNIKUL U Luzerra	.ABLE NGE FINDER - TEMP. SENSOR	2/13
					MALMO, SWEDEN			
					Drawn by: Date drawn: Checked by: E A.S. 2011–11–16 E	⊕		
					App. by: Date approved: Project No.:	Drawing No.	Rev. Sheet	Scale
		Revision Description	Date	Drawn by: Checked by: Approved		SG590621	-103-01 1 1 of	1 ND SCALF
			-	: - - -	-	- - - - - - - - - - - - - - - - - - -	; - - >	

			Z	Ν	Image: Normal state of the	⁻ AN, T2/T3		et Scale of 1 NO SCALE
Subplier	AB NOVUM, SWEDEN	ELFA, SWEDEN	WEIDMÜLLER, SWEDE	WEIDMÜLLER, SWEDE	Meluhuuutek, Sweuer 100 THIS WIRE END- ated, alt ing to	'L E A TER/ LASER COOLING F		.104 – 01 Rev. She
Supplier's Stock Number	7853060	5507108	9026060000	SEE NOTE	SEE NUTE Unless otherwise indic tolerances are accordi Surface Coating	PUWEK LAD DEFROSTER / HE		Drawing No. SG590621-
			١٢	١٢		ional AB DEN	ecked by:	oject No.:
ufacturer		PHA WIRE	EIDMÜLLER, GERMAN	EIDMÜLLER, GERMAN	SAFEO G R O	Safegate Internat MALMÖ, SWE	y: Date drawn: Ch 2011-11-16	Date approved: Pr
er's Part No. Man		21-3/8 AL	60000 WE	OTE WE			A.S.	by: Approved
luct No. Manufactu		FIT-2	90260	SEE N				Drawn by: Checked
Safegate Proc	,							Date
Drawing No.	,				MIRE MARKERS WIRE MARKERS T NO. QTY. 1044561 12 1044101 20 1044102 2 1044105 4 1044105 4 1044106 2 1044107 2 1044109 8 1044109 8			
					NOTE FOR NO. PAR NO. PAR 11-0 11-0 11-0 11-0 11-0 11-0			
		BING, Ø9.5, BLACK		EX PA02				
SI	YY, 6 x 0.5	RINKABLE TUI	G, H 0.5/14	RERS, PARTI				evision Description
Description/Rating	CABLE, LI	HEAT SHF	CRIMP LU	WIRE MAF				
ltem Quantity		2 2	3 11	ť				

ltem	Quantity	Description/Ratings
.	l	CONNECTOR, MC1.5/6-ST-3.81
2		ELECTRICAL WIRE, UL1007/1569, RED
e E	2	BOOTLACE FERRULE, H 0.5/14
4		WIRE MARKERS, PARTEX PA02
5	1	LABEL, SK 3,81/2,8: S0, TEXT: J11

132

Revision Description

ltem	Quantity	Description/Ratings
~	l	CONNECTOR, MSTB 2.5/3-ST-5.08
2	l	ELECTRICAL WIRE, UL1007/1569, AWG 16, F
3	l	ELECTRICAL WIRE, UL1007/1569, AWG 16, E
4	7	BOOTLACE FERRULE, H 1.5/14
2		WIRE MARKERS, PARTEX PA02
9	l	LABEL, SK 5.08/3,8: SO, TEXT: J16

Item	Quantity	Description/Ratings CONNECTOR, MC1.5/16–ST–3.81
3	10	ELECTRICAL WIRE, UL1007/1569, REC BOOTLACE FERRULE, H 0.5/14
4		WIRE MARKERS, PARTEX PA02 LABEL, SK 3.81/2.8: S0. TEXT: J17
9	. M	TWIN WIRE FERRULE, H 0.5/14 ZH 0F
		CItem (6) changed to twBWire (168) to K1 addeAWire (169) to K2 addeRevisionDescription

	MC1.5/6-ST-3.81	WIRE, UL1007/1569, RED FRRULE H 0.5/14	RS, PARTEX PA02	,81/2,8: SU, 1EX1: J18		n Decrintion
atings	TOR,	ALF F	ARKE	2 Y 3		Revisio
Description/R	CONNEC	ELECTR BOOTI	WIRE M	LABEL,	g ≅ ≅ ≅ ⊕ □ □ □ □ □ □	
Quantity	-	10				
ltem	1	23	- +	۲ ر		

· · ·		- ,	- 1	-						1		
								Sharp Edges	Weight			et Scale of 1 NN SCALE
lier		GA SWEDEN	LGA, SWEDEN	EA.SWEDEN	^F A, SWEDEN							- () 1 Rev. She
's Stock Number Supp		1837 CF	822 SE	162-41 ELI	303-78 ELI			ss otherwise indicated, al rances are according to	ace Coating	RING ASSEMB »Lay power		ving No. 590671–117.
Supplier'		60E0	020	55-0	48-3			Unle: toler	Surf			Draw SG
						SWEDEN			SAFEGAI	Safegate International AB MALMÖ, SWEDEN	drawn: Checked b – 11– 16	approved: Project N
Manufacturer	MOLEX	MOLEX				PARTEX,					Drawn by: Date (A.S. 2011	App. by: Date a
Manufacturer's Part No.	42816-0212	42815-0012				PA-1	1100				-	r: Checked by: Approv
Safegate Product No.											-	Date Drawn b
Drawing No.												
	nm PITCH,	2 REN	2, BLACK			ILLUSTRATION						
	G, MINI FIT SR.,10 п	SR., 10 mm PITCH 2K (H07V_K) /, mm	<u>KK (H07V-K), 4 mm</u>	8, BLACK, L = 1040	:, 4 mm2	ERING AS SHOWN ON						
Jescription/Ratings	RECEPTICLE HOUSIN	TERMINAL, MINI FIT	ELECTRICAL WIRE, F	ove tubing, i.d. 8.3	300TLACE FERRULI	WIRE MARKERS, NUMB					-	Revision Description
n Quantity C	-			<u> </u>	4 E	_						
Ter	-	2	t	പ	t-	\sim						

		1						1			T
							Sharp Edges	Weight	_		Sheet Scale
Supplier		SFLGA SWEDEN	SELGA, SWEDEN	ELFA.SWEDEN	ELFA, SWEDEN		icated, all ding to	'n	SEMBLY R, T1/T2		-113-01 Rev.
Supplier's Stock Number		0309832	0309822	55-062-41	48-303-78		Unless otherwise ind tolerances are accor	Surface Coating	WIRING ASS DISPLAY POWER	-	Drawing No.
							T	FATE +	ional AB DEN	ecked by:	oject No.:
schurer	EX	EX				RTEX, SWEDEN		SAFEG	G R O Safegate Internat MALMÖ, SWEI	Date drawn: Ch 2011-11-16	Date approved: Pr
irt No. Manufa	12 MOL	12 MOL				PAR				Drawn by: A.S	App. by:
Manufacturer's Pa	42816-02	4 2815-00				PA-1					by: Checked by:
Safegate Product No.											te
Drawing No.											
	R., 10 mm PITCH,	TCH 4 mm2 RFD	4 mm2, BLACK	: 1340		/N ON ILLUSTRATION					
	ousing, mini fit sr	NI FIT SR., 10 mm PI VIRF RK (H07V-K) v	VIRE, RK (H07V-K), /	I.D. 8.38, BLACK, L =	RRULE, 4 mm2	, NUMBERING AS SHOW					Description
ntity Description/Ratings	RECEPTICLE H	TERMINAL, MI FIFCTRICAL W	ELECTRICAL V	PVC TUBING,	B00TLACE FE	WIRE MARKERS					Revision
ltem Qua	<u>-</u>	2 1	4 1	5 1	4 4						

te t	Duantity	Decristion (Batime	Drawing No.	Cafanata Drudurt	Vo Manufactur.	r's Part No	Manufacturer		sumhiar's Stark Numhar	Cumliar		
		CABLE, LIYCY, 4 x 2 x 0.25, L = 1100		6								
2	<u> </u>	CABLE, LIYCY, 4 × 2 × 0.25, L = 750										
 ~	2	CONNECTOR, MC1.5/6-ST-3.81							1803617	PHOENIX CON	ITACT, SWEDEI	Z
4	-	LABEL, SK 3,81/2,8: SO, TEXT: J27							3805056	PHOENIX CON	ITACT, SWEDEI	Z
5	1	LABEL, SK 3,81/2,8: SO, TEXT: J24))805056	PHOENIX CON	ITACT, SWEDEI	Ν
9	2	CONNECTOR HOUSING, AMPMODU MOD. II, DOUBLE ROW			28051	~	FYCO ELECTRONICS					
7	24	CRIMP TERMINAL, 100 AMPMODU			18727()-1	FYCO ELECTRONICS					
8	4	HEAT SHRINKABLE TUBING, Ø9.5, BLACK			FIT-22	1-3/8	alpha wire		5507108	ELFA, SWEDEI	N	
6	8	B00TLACE FERRULE, H 0.25/12							9025780000	WEIDMÜLLER,	, SWEDEN	
10		WIRE MARKERS, NUMBERS AS SHOWN ON ILLUSTRATION			PA02		ARTEX					
					9					WHITE		
		10 1	7		WHITE 70 1 WHITE 71 2 BROWN 72 3 GREEN 73 4	WHITE BROWN GREEN YELLOW		-		BROWN		
		14. 5 WHTE 15. 6 GREEN 17. 8 YELLOW 18 9			YELLOW 14 5 GRAY 14 5 GRAY 15 6 PINK 16 7 BLUE 17 8 RED 18 9	GRAY PINK BLUE RED						
]	1		-)	/		0 0 0	
		POSITION 10 POSITION 1								-6		\bigcirc
							SAFE	GATE	Unless otherwise indicat tolerances are according Surface Coating	ed, all g to		Sharp Edges Veight
		ITEM 6, CONTACT ORIENTAION					2 2 3					,
		AND ILKI'IINAL FUSITIONS					Safegate Inte MALMÖ, S	rnational AB SWEDEN	LUTITIONILA I LED DISPLAY FOR	IUN LADLE T1		
				-	-	Drawn A.S.	by: Date drawn: 2011-11-06	Checked by:				
					- - -	App. b	y: Date approved:	Project No.:	Drawing No.	11 01 R	Rev. Sheet	Scale
		Revision Description		Date Dra	wn by: Checked t	y: Approved			<u> - 70/4CDC</u>	4 – U	1 of 1	NU SLALE

 auantity Description/Ratings 1 CONNECTOR, MC1.5/10–ST–3.81	8 ELECTRICAL WIRE, UL1007/1569, RED	16 BOOTLACE FERRULE, H 0.5/14 WIRF MARKFRS PARTFX PA07	1 LABEL, SK 3,81/2,8: SO, TEXT: J19	
1 Item	2	4	. 5	

Revision Description
ltem	Quantity	Description/Ratings	Drawing No.	Safegate Product No.	1anufacturer's Part No.	Manufact	urer		Supplier's Stock Number	Supplier	
	-	CABLE, CYLICYCY, 8 x 2 x 0.25									
2	-	CONNECTOR, MC1.5/10-ST-3,81			803659	PHOE	INIX CONTACT				
	-	CONNECTOR, MC1.5/6-ST-3,81			1803617	PHOE	INIX CONTACT				
4	2	HEAT SHRINKABLE TUBING, Ø9.5, BLACK			FIT-221-3/8	ALPF	ha wire		5507108	ELFA	
2	13	BOOTLACE FERRULE, H 0.12/12							9025780000	WEIDMÜLLER	
9	-	B00TLACE FERRULE, H 1,5/14							9026090000	WEIDMÜLLER	
L		WIRE MARKERS, PARTEX PA02							SEE NOTE	WEIDMÜLLER	
8	1	LABEL, SK 3,81/2,8: S0, TEXT: J22							SEE NOTE	WEIDMÜLLER	
6	—	LABEL, SK 3,81/2,8: S0, TEXT: J13							SEE NOTE	WEIDMÜLLER	
10	_	RECEPTICLE FOR PIN CONTACTS			1-77-1	AMP			4457909	ELFA	
11	-	CABLE CLAMP WITH STRAIN RELIEF			82655-1	AMP			4450433	ELFA	
12	13	PIN CONTACT			163086-1	AMP			4450714	ELFA	
13	Ţ	STAR-TEC FERRITE RING			14271221	WÜR'	TH ELEKTRONIK				
		<u>•</u>		880					170		Ĩ
			$\overline{}$				(-+)				
											GRAY/PINK (70) PINK (68) GRAY (69)
				_							WHITE/GREEN (71)
			•								BROWN (59)
				-							YELLOW (63) GREEN (64) WHITE (60)
		PIN NIJMBER ASSIGNMENT FOR WIRES	te for wirf markfi	SS							RED (61)
	I	BROWN (PIN 1) NO.	PART NO. Q	<u></u> .				ÿ	Kar Kar		BLACK (66)
		WHITE (PIN 2) RED (PIN 3)	11-01044100 2								BLUE (62)
		BLUE (PIN 4)	11-01044101 2								
		YELLOW (PIN 5) GREEN (PIN 6)	11-01044102 11-0107.1.102								G
		VIOLET (PIN 7)	11-01044104						2		
		BLUE/RED (PIN 9)	11-01044105 2						Unless otherwise indicate	ed, all	Sharp Edges
		PINK (PIN 10) 6	11-01044106 11				SAFE	GATE	tolerances are according Surface Coating	to	Weight
		GRAY/PINK (PIN 12)	11-01044107 6				0 2 5	X			
		WHITE/GREEN (PIN 13)	11-01044108 1				Safegate Intern	ational AB	VERTICAL SCANNIN	DLE 16 MOTOR T1	
		6	11-01044109 2			-	MALMÖ, SM	reden .		- - - - - -	
						Drawn by: A.S.	Date drawn: (0 2011-11-16	hecked by:			
						App. by:	Date approved:	Project No.:	Drawing No.	A / A Rev. Shee	et Scale
		Revision Description	Date	Drawn by:	Checked by: Approve				<u> 1 - 1 7 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7</u>	D-U 1	of 1



																34)									Jes				
														Ţ		GRAY/PINK (83 PINK (81) GRAY (82) WHITE/GREEN (1	BLUE/RED (80) BROWN (72)	YELLOW (76) GREEN (77) WHITE (73)	RED (74)	BLACK (79)	BLUE (75)]	G		Sharp Edi	Weight			
					R	R	R	R	R						6												H		
Supplier				ELFA	WEIDMÜLLE	WEIDMÜLLE	WEIDMÜLLE	WEIDMÜLLE	WEIDMÜLLE	ELFA	ELFA	ELFA					80	87 171 ET							d, all to			NING MULUH	
Number					000	000	1.1							170)	ierwise indicate are according	oating	ROL CAB	VI AL SLAN	
Supplier's Stock				5507108	9025780	90260900	SEE NOT	SEE NOTI	SEE NOTI	4457909	4450433	4450714									9				Unless off tolerances	Surface (CONT		
																									T		< L		
			 										NIK		(t_)											EGAT	O C ternational AR	i, SWEDEN	I Charkad h
rer		NIX CONTAC	NIX CONTAC	a wire									H ELEKTRO					ı								SAF	G R Safenate Ir	MALM	ated desire.
Manufactu		PHOEI	PHOEI	ALPH						AMP	AMP	AMP	WÜRT																
octurer's Part No.		3659	3617	-221-3/8						077-1	555-1	086-1	71221																
duct No. Manufa		180	180	-TIT						183(182(163(742					_											
Safegate Pro	,													1080			V		KERS	QTY.	—	~ (7	- 2	~	~ c	ס א	-	
j															(-)-				r wire mar	RT NO.	01044100	01044101	01044102 01044103	01044104	01044105	01044106	01044107 01044108	01044109	
Drawing N															(\underline{m})		•		NOTE FOR	NO. PAF	0 11-(1 11-(2 11-(0-11-(4 11-(5 11-(6 11-(7	8 11-(9 11-(
															(Ξ)		((
				, BLACK				5	20		EF								RES										
	: 2 x 0.25	-ST-3,81	ST-3,81	JBING, Ø9.5	H 0.12/12	H 1,5/14	FEX PA02	0, TEXT: J1	0, TEXT: J2	CONTACTS	TRAIN RELI		DNI				•		NT FOR WIF								(2) N 13)		
	LICYCY, 8 ×	R, MC1.5/10	2, MC1.5/6-	NKABLE TU	FERRULE, I	FERRULE, I	kers, part	3,81/2,8: S	3,81/2,8: S	E FOR PIN (MP WITH S	CT	FERRITE R						ASSIGNME	VN (PIN 1)	e (pin 2) (pin 3)	(PIN 4)	(2 NIY) WU (2 NIY 6)	et (pin 7) .K (pin 8)	./RED (PIN 9)	(PIN 10) Y (PIN 11)	Y/PINK (PIN 1 E/Green (PII		
Description/Ratings	CABLE, CY	CONNECT O	CONNECT O	HEAT SHRI	BOOTLACE	BOOTLACE	WIRE MARI	LABEL, SK	LABEL, SK	RECEPTICL	CABLE CLA	PIN CONTA	STAR-TEC						VIN NUMBER	BROV	RED	BLUE	Yeli Gree	VIOL BLAC	BLUE	PINK GRA'	gra Whit		[
Quantity		—	_	2	13	<u> </u>		~	_	~	—	13	<u> </u>						Ľ	I									
ltem								 	6	10	=	12	<u>۳</u>																



Supplier's Stock Number Supplier		5507108 ELFA	9025780000 WEIDMÜLLER	SEE NOTE WEIDMÜLLER		4457891 ELFA	4450425 ELFA	4450714 ELFA		0 GREAK (S) GREAK (S) GREAK (S) GREAK (S) GREAK (S) CLION (S	Unless otherwise indicated, all Sharp Edges to tolerances are according to	Surface Coating Weight	CONTROL CABLE LASER, T1	€ [
No. Manufacturer		8 ALPHA WIRE			PHOENIX CONTACT	AMP	AMP	AMP	WÜRTH ELEKTRONIK				GROCCO	Drawn by: Date drawn: Checked by:	
Safegate Product No. Manufacturer's Part	T1 STANDARD	FIT-221-3/			0805056	183079-1	182663-1	163086-1	74271221					2014.10.23 V.N.	
Description/Ratings Description/Ratings	CABLE, LIYCY, 5 x 0.25, L=1080	HEAT SHRINKABLE TUBING, Ø9.5, BLACK	BOOTLACE FERRULE, H 0.25/12	WIRE MARKERS, PARTEX PA02	LABEL, SK 3,81/2,8: S0, TEXT: J28	RECEPTICLE FOR PIN CONTACTS	CABLE CLAMP WITH STRAIN RELIEF	PIN CONTACT	STAR-TEC FERRITE RING	Provide the second seco				C Not valid for T1S. For T1S cable, see drw SG590621-130-01	
m Quantity				2	~	~	-	L							





ltem	Quantity	Description/Ratings
.	.	CABLE, LIYCY, 4 x 2 x 0.25, L = 1100
2		CABLE, LIYCY, 4 x 2 x 0.25, L = 750
m	2	CONNECTOR, MC1.5/6-ST-3.81
4	, _	LABEL, SK 3,81/2,8: S0, TEXT: J24
Ъ	Ļ	LABEL, SK 3,81/2,8: S0, TEXT: J27
9	2	CONNECTOR HOUSING, AMPMODU MOD
1	24	CRIMP TERMINAL, 100 AMPMODU
8	4	HEAT SHRINKABLE TUBING, Ø9.5, BL
6	8	BOOTLACE FERRULE, H 0.25/12
10		WIRE MARKERS, NUMBERS AS SHOWI
		(

c	
Descriptio	
Revision	



Description/Ratings	CONNECTOR, MC1.5/6-ST-3.81	ELECTRICAL WIRE, UL1007/1569, RED	BOOTLACE FERRULE, H 0.5/14	WIRE MARKERS, PARTEX PA02	LABEL, SK 3,81/2,8: SO, TEXT: J29	<u>1</u>	m
Quantity [8				
ltem		2	m	4	5		

ITEM	QTY DESCRIPTION/RATINGS	DRAWING NO.	SAFEGATE PRODUCT NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NUMBER	SUPPLIER
-	1 CABLE, LIYCY, 16x0.25, L=1200		T1				
2	1 STAR-TEC FERRITE RING		T1	74271221	WURTH ELEKTONIK		
ო	32 BOOTLACE FERRULE, h0.12/12		T1	9025780000	WEIDMULLER		
4	4 BOOTLACE FERRULE, h1.5/14		T1	9026090000	WEIDMULLER		
5	2 HEAT SHRINKABLE TUBING, Ø9.5, BLACK		T1	FIT-300-3/4	ALPHA WIRE	55-062-09	ELFA, SWEDEN
9	32 WIRE MARKERS, NUMBERING AS SHOWN IN ILLUSTRATION		T1	PA02	PARTEX		
7	1 CONNECTOR, MSTB 2,5/18-ST-5,08		T1	1757174	PHOENIX CONTACT		
8	2 CONNECTOR, MC 1,5/10-ST-3,81		T1	1803659	PHOENIX CONTACT		
6	1 LABEL, SK 3.81/2.8: SO, TEXT: J22		Τ1	0825122	PHOENIX CONTACT		
10	1 LABEL, SK 3.81/2.8: SO, TEXT: J15		T1	0825122	PHOENIX CONTACT		



Gen. tolerance
 Ğ

								Sheet	1(1
								Size	A3
		Info			CABLE C			Scale	AN
Surface treatment	Basic material	Ę	€	Description	CONTROL	, F	<u> </u>	Rev.	۷
		6 R O U P		Date drawn:	2014-05-20	Date approved:		Drawing No.	SG590621-125-01
	NACHT	Airfield Lighting		Drawn by:	V. NURELL	Approved by:		Project No.	
									lssue text
									Issue checked by
									lssue by
									Issue date

		Rev.

ITEM	QTY DESCRIPTION/RATINGS		DRAWING NO.	SAFEGATE PRODUCT NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NUMBER	SUPPLIER
-	1 CABLE, LIYCY, 10x0.25, L=1200			T1				
7	1 STAR-TEC FERRITE RING			T1	74271131	WURTH ELEKTONIK		
е	20 BOOTLACE FERRULE, h0.12/12			T1	9025780000	WEIDMULLER		
4	2 HEAT SHRINKABLE TUBING, Ø9.5, BL	ACK		T1	FIT-221-3/8	ALPHA WIRE	55-071-08	ELFA, SWEDEN
5	20 WIRE MARKERS, NUMBERING AS SHOWN	N ON ILLUSTRATION		T1	PA02	PARTEX		
9	1 CONNECTOR, MSTB 2,5/10-ST-5,08			T1	1757093	PHOENIX CONTACT		
7	2 CONNECTOR, MC 1,5/6-ST-3,81			T1	1803617	PHOENIX CONTACT		
ω	1 LABEL, SK 3.81/2.8: SO, TEXT: J13			T1	0825122	PHOENIX CONTACT		
6	1 LABEL, SK 3.81/2.8: SO, TEXT: J20			T1	0825122	PHOENIX CONTACT		





										110	Sheet	1(1)
											Size	A3
			Info				- CABLE U				Scale	NA
Surface treatment	Basic material		¢ G	€ }	Description				T1		Kev.	A
			C R O U P		Date drawn:	2014-05-20	0100-01	Date approved:			Drawing No.	SG590621-126-01
		THORN	Airfield Ughting		Drawn by:	V. NORFLL		Approved by:			Project No.	
												isue text
												Issue checked by Is
												Issue by
												Issue date

Gen. tolerance

	STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
	Standard	T1					
	Standard	T1		FIT-221-3/4BLACK 4	ALPHA WIRE	55-073-06	ELFA
	Standard	T1					
	Standard	T1					
	Standard	T1		1803594	PHOENIX CONTACT		
	Standard	T1		1803581	PHOENIX CONTACT		
	Standard	Т1		0825122	PHOENIX CONTACT		
	Standard	Т1		0825122	PHOENIX CONTACT		
STRATION	Standard	T1		PA02	PARTEX		



								Sheet	1(1)
								Size	A3
		Info			ARIF C21			Scale	1,000
Surface treatment	Basic material	¢	€	Description	MULTI D		T1	Rev.	A
		SAFEGATE		Date drawn:	2014-09-08	Date annroved:		Drawing No.	SG590621-127-01
		Arried Lighting	A SHOW	Drawn by:	V. NORELL	Annroved hv ⁻	. 6	Project No.	
									Issue text
									Issue checked by
									Issue by
									Issue date
		1		1					

Gen. tolerance

DESCRIPTION	CABLE, LI-YDYCYP 6x2x0.25, L=1700 mm	HEAL SHRINKABLE LUBING, Ø 19.1 mm, BLACK CRIMPTLIG H 0.25/12	CRIMP LUG, H 1.5/14	TERMINAL CONTACT, MC 1,5/4-ST-3,81	TERMINAL CONTACT, MC 1,5/3-ST-3,81	TERMINAL MARKER, SK 3,81/2,8: SO, TEXT: J8 TERMINAL MARKER SK 3,81/2 8: SO TEXT: J10	WIRE MARKERS, NUMBERING AS SHOWN ON ILLUS	Wire colour and number WHITE (87) BROWN (88) GREEN (99) GREEN (99) GREEN (173) BLUE (172) BLUE (173) BLACK (174) SHELD 0
QTΥ	- c	78	2 -	-	,			
SOc	- (\ \	10				

		Rev.
		2

	STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
	Standard	T1S					
	Standard	T1S		FIT-221-3/4BLACK 4	ALPHA WIRE	55-073-06	ELFA
	Standard	T1S					
	Standard	T1S					
TRATION	Standard	T1S					



								Sheet	1(1)
								Size	A3
			Info			ABLE C23		Scale	1,000
Gen. tolerance	Surface treatment	Basic material	C	€	Description	MULTIC	T1S	Rev.	۷
			G R O U P		Date drawn:	2014-10-23	Date approved:	Drawing No.	SG590621-128-01
		Nacht	Airfield Lighting	ANNUAL	Drawn by:	V. NURELL	Approved by:	Project No.	
									Issue text
									Issue checked by
									Issue by
									Issue date

DESCRIPTION		HEAL SHRINKABLE TUBING, Ø 19.1 MM, BLACK CRIMP LUG. H 0.25/12	CRIMP LUG, H 1.5/14 WIRF MARKERS, NUMBERING AS SHOWN ON ILLUS	Write colour and number WHITE (87) BROWN (88) GREW (113) PINK (111) PINK (111
QTY	- c	18	-	
POS	- c	N M	4 rc	

		Sev.

	STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
	Standard	T1S					
	Standard	T1S		FIT-221-3/8BLACK 4	ALPHA WIRE	55-071-08	ELFA
	Standard	T1S					
	Standard	T1S		1803594	PHOENIX CONTACT		
	Standard	T1S		1803581	PHOENIX CONTACT		
	Standard	T1S		0825122	PHOENIX CONTACT		
	Standard	T1S		0825122	PHOENIX CONTACT		
TRATION	Standard	T1S		PA02	PARTEX		



						Gen. tolerance			
						Surface treatment			
						Basic material			
				Airfield Lighting	G R O U F		nfo		
				New		€			
				Drawn by:	Date drawn:	Description			
				V. NURELL	2014-10-23	MULTI C/	NBLE C24		
				Approved by:	Date approved:	T1S, Plint	-MB		
				Project No.	Drawing No.	Rev.	Scale	Size	Sheet
Issue date	Issue by	Issue checked by	Issue text		SG590621-129-01	A	1,000	A3	1(1)

DESCRIPTION	CABLE, LIYCY, 10x0.25, L=1200 mm HEAT SHRINKABLE TUBING. Ø9.5 mm. BLACK	CRIMP LUG, H 0.25/12	TERMINAL CONTACT, MC 1,5/4-ST-3,81	TERMINAL CONTACT, MC 1,5/3-ST-3,81	TERMINAL MARKER, SK 3,81/2,8: SO, TEXT: J8 TERMINAL MARKER. SK 3,81/2,8: SO. TEXT: J10	WIRE MARKERS, NUMBERING AS SHOWN ON ILLUS	Write colour and number WHITE (87) BROWIT
QTΥ	- ~	18	~	. .			
POS	_ ~	. m	4	10 0	0 ~	m	

lier		FA	IDMÜLLER	IDMÜLLER	FA	FA	FA	ASER POWER S4.22 T(A) S4.22 T(B) S4.22 T(B) S4.22 T(B) S4.22 T(B)	l Sharp Edges	Weight			-01 Rev. Sheet Scale
Supplier's Stock Number Supp		5507108 ELF	9025780000 WE	SEE NOTE WE	4457891 ELF	4450425 ELF	4450/14 ELI	Connect to X8 Gener to X8 Mutric (5) A BROWN (56) C	Unless otherwise indicated, all	Surface Coating	CONTROL CABLE LASER, T1S C25	 	Drawing No. SG590621-130
turer's Part No. Manuf acturer		221–3/8 ALPHA WIRE			79-1 AMP	63-1 AMP	86–1 AMP 71221 WÜRTH ELEKTRONIK			SAFEGATE	Safegate International AB MALMÖ, SWEDEN	Drawn by: Date drawn: Checked by: V.N. 2014-10-23	App. by: Date approved: Project No.: ed by: Approved
wing No. Safegate Product No. Manufaci	T1 SPLIT				1830	1826	1630						2014.10.23 V.N. Date Drawn by: Checke
n Quantity Description/Ratings Draw	1 CABLE, LIYCY, 5 x 0.25, L=5000	1 HEAT SHRINKABLE TUBING, Ø9.5, BLACK	5 B00TLACE FERRULE, H 0.25/12	5 WIRE MARKERS, PARTEX PA02	1 RECEPTICLE FOR PIN CONTACTS	1 CABLE CLAMP WITH STRAIN RELIEF	1 PIN CUN IAL I 1 STAR-TEC FERRITE RING	Image: Constraint of the second se					A New drawing for T1S Revision Description





ltem	Quantity	Description/Ratings
~	—	CABLE, LIYCY, 5 × 0.25, L=1200
2	~	CONNECTOR, MC1.5/10-ST-3,81
£	2	HEAT SHRINKABLE TUBING, Ø9.5, BLACK
4	10	B00TLACE FERRULE, H 0.25/12
5	10	WIRE MARKERS, PARTEX PA02
9	Ļ	LABEL, SK 3,81/2,8: S0, TEXT: J28
		Connect to X8
		A New laser cable for T1S.
		Devicion Description



	EX IRAY II 361,5, L=1700 FX TRAY II 3615, L=5000	KABLE TUBING, 09.5, BLAC	ERRULE, H 1.5/16	RS, PARTEX PA02		New power cable for T1/T	Description
atings		SHRIN	ACE FI	ARKE		∢	Revisior
Description/R	LABLE, CABLF	HEAT S	BOOTL	WIRE M			
Quantity	. .	- 2	6				
ltem ,	<u> </u>	- 2	~ ~	4			

Position	Quantity	Description	Material	Drawing No.	Size	Manu. Part No.	Manufacturer	Supplier's Part	Supplier
	~	CABLE_CHANNEL_235MM	Plastic		L=235mm	T1-E 25x60 G	IBOCO	2990122	AHLSELL
5	2	CABLE_CHANNEL_467MM	Plastic		L=467mm	T1-E 25x60 G	IBOCO	2990122	AHLSELL
3	7	CABLE_CHANNEL_595MM	Plastic		L=595mm	T1-E 25x60 G	IBOCO	2990122	AHLSELL
4	2	DIN_RAIL_185MM	Steel	SG590621-200-01	NS35/7,5 L=185mm				
5	~	DIN_RAIL_240MM	Steel	SG590621-204-01	NS35/7,5 L=240mm				
9	7	DIN_RAIL_300MM	Steel	SG590621-201-01	NS35/7,5 L=300mm				
7	~	DIN_RAIL_450MM	Steel	SG590621-202-01	NS35/7,5 L=450mm				
ω	9	LOCK_WASHER_M3	Zinc Plated		3.2x6x1.2				
6	9	LOCK_WASHER_M5	Zinc Plated		5.1x9x1.5				
10	9	M3X8_DIN_7985	Zinc Plated		M3x8				
11	12	M5X10_DIN7984	Zinc Plated		M5x10				
12	~	MOUNTING_PLATE	Aluminum	NPP 912748					
13	80	POPNIT_BIG_HEAD_3_2	Zinc Plated		Ø 3.2x7.9 head=9.5				
14	9	WASHER_LARGE_M5			5.3x15x1.2mm				



Sheet 1(1)

AO

Mounting Plate

Date drawn: 2011.08.31 Date approved: Drawing No. SG590621-203-01

Drawn by: A.Strandberg Approved by: Project No.

ssue No.

Item No.	Quantity	Name	Description	Dimensions	Remark
		B-588VINYL FILM, WHITE	76576	80x30mm	BRADY

USE CU LABEL FILE, SG590254-205-01, FOR GLOBALMARK LABEL PRINTER TO CREATE LABEL

	- 08	
900	Laser Comm Aux1 Comm OP Comm Maint Comm GOS Comm Aux2 Comm LED-B Comm LED-B Comm Aux4 Comm	hdl hd2 Reset Mirror Motion Laser Power Status OK Power

					Surface treatment			
			THORN		Basic material			
			Airfield Lighting	G R O U P		0		
			Analogi		€ }			
				Date drawn:	Description			
				ZU 1Z-UQ-U1	IABFI			
			Approved by:	Date approved:	CU-BOARD LE	:D's		
			Project No.	Drawing No.	Rev. Sc	ale	ize	Sheet
Issue date Issue by	Issue checked by	Issue text		SG590621-205-01		1,000	A3	1(1)

Gen. tolerance



	STD/OPT	T1/T1S/T2/T3	DRW. NO.	MANUFACTURER'S PART NO.	MANUFACTURER	SUPPLIER'S STOCK NO.	SUPPLIER
	Standard	T1/T1S		2866381	PHOENIX CONTACT		
	Standard	T1/T1S	SG590621-207-01		PHOENIX CONTACT		
	Standard	T1/T1S					
	Standard	T1/T1S					
	Standard	T1/T1S		3022276	PHOENIX CONTACT		
	Standard	T1/T1S		3047141	PHOENIX CONTACT		
	Standard	T1/T1S		3044364	PHOENIX CONTACT		
	Standard	T1/T1S		3044500	PHOENIX CONTACT		
	Standard	T1/T1S		3044380	PHOENIX CONTACT		
	Standard	T1/T1S		2715092	PHOENIX CONTACT		
ILLUSTRATION	Standard	T1/T1S					



(e)

ſ

N



							:MBI Y		Sheet	1(1)
							OK ASSF		Size	A3
				Info			INAL BLO	-1S	Scale	1,000
Gen. tolerance	Surface treatment	Basic material		¢	€ }	Description	X9 TFRM	FOR T1/T	Rev.	A
			SAFEGATE	T A O A A		Date drawn:	2014-08-27	Date approved:	Drawing No.	SG590626-001-01
			THORN			Drawn by:	V. NORELL	Approved by:	Project No.	

DESCRIPTION POWER SUPPLY, TRIO-PS/1AC/24DC/20 DIN RAIL, 195 mm SCREW, M5x12, ISO7045, A2 WASHER, 5.3x15x1, ISO7089, A2 END BRACKET, CLIPFIX 35-5 END BRACKET, CLIPFIX 35-5 END COVER, D-UT 2,5/4-TWIN TERMINAL CONTACT, UT 4-TWIN BU TERMINAL CONTACT, UT 4-TWIN BU TERMINAL CONTACT, UT 4-TWIN PE TERMINAL CONTACT, UT 4-TWIN PE TERMINAL CONTACT, UT 4-TWIN PE TERMINAL CONTACT, DIKD 1,5-PV TERMINAL CONTACT, DIKD 1,5-PV TERMINAL MARKERS, NUMBERING AS SHOV	
QT 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	
POS P22 6 6 7 7 7 7 7 10 10	

		Rev.
		Ľ

				-
	USI 10	E THE SYSTEN DETERMINE	I'S CONFIGURAT THE SYSTEM AS	TION CODE SEMBLY.
Designation	Code (x)	ltem	Type	Drawing No.
T1-				
CB(x)	F	Cabinet	Standard	SG590253-002-01
CL(x)	٢	Cooling	Cooler Assembly	SG590259-001-01
CM(x)	٢	Camera	Axis M1144-L	SG590612-001-01
	٢	Control	w/o UPS	SG590621-001-01
CP(X)	Ν	& Power	w/ UPS	SG590621-001-01
D(x)	£	Display	1-42	SG590256-001-01
FN(x)	-	Vent. Assembly	Standard	SG590264-100-01
H(x)	1	Installation Hardware	For ø139.7 Pole	SG590221-001-01
NS(x)	٢	Network Switch & Filter	Standard	SG590611-001-01
SA(x)	۲	Scan. Assm.	Standard	SG590255-001-01
			DIN (Schuko)	SG590266-001-01
	7	Utility	British Standard	SG590266-001-01
	3	Outlet	U.S. Standard	SG590266-001-01
	4		French Standard	SG590266-001-01







CKING GUIDANCE SYSTEM NT PLACEMENT AND CONFIGURATION KEY ING SG590621-004-01 FOR CONNECTION DIAGRAM Scale Size Sient

T1 DOC COMPONEN

2009-03-Date approved

Drawn by: G.O. Approved

V.N. V.N. K.J. A.S. A.S.

2014-11-11 2014-09-18 2013-11-14 2011-11-17 2011-03-22 date

ssee No.

1(1)

0,200

FIG. 1, CABLE PLACEMENT, LED DISPLAY

FRONT VIEW, DOORS REMOVED

	CONF USE THE	TGURA system's - ermine the	TION KEY	DE ,
Designation	Code (x)	ltem	Type	Drawing No.
T1S-				
CA(x)	~	Cable Assembly	Standard	SG590270-000-01
CD(x)	~	Display Cabinet	Standard	SG590253-213-01
CL(x)	1	Cooling	Supercooler Assembly	SG590259-001-01
CM(x)	-	Camera	Axis M1144-L	SG590612-001-01
CP(x)	۲	Control & Power	Standard	SG590621-001-01
CS(x)	1	Scanner Cabinet	Standard	SG590253-217-01
D(x)	٢	Display	1-42	SG590256-001-01
NS(x)	-	Network Switch	Standard	SG590611-01-01
FN(x)	1	Vent. Assembly	Standard	SG590264-001-01
H(x)	1	Installation Hardware	For ø139.7 Pole	SG590253-218-01
SA(x)	1	Scanner Assembly	Standard	SG590255-001-01
	1		DIN (Schuko)	SG590266-001-01
117(~)	2	Utility	British Standard	SG590266-001-01
	3	Outlet	U.S. Standard	SG590266-001-01
	4		French Standard	SG590266-001-01





(X) H









* (ITIX)

FRONT VIEW, DOORS REMOVED

* Note: X3 Terminal Block: Drw. no. SG590263-001-01 X9 Terminal Block: Drw. no. SG590627-001-01 Standard Scanner Cabinet Ventilation Drw. no.: SG590255-200-01

	CONF USE THE S TO DETER	FIGURA	TION KEY UFIGURATION CODE STEM ASSEMBLY.	
Designation	Code (x)	ltem	Type	Drawing No.
Т2-				
	4	topiact	Standard	SG590281-001-01
(x)	2	Cabillet	Adapted for Supercooler	SG590282-001-01
CL(x)	-	Cooling	Supercooler Assembly	SG590543-001-01
CM(x)	1	Camera	Axis M1144-L	SG590612-001-01
CP(x)	÷	Control & Power	Standard	SG590621-001-01
	٢		2-18, w/heater	SG590466-000-01
	2	Display	2-18	SG590467-000-01
	3	-	2-24, w/heater	SG590468-000-01
	4		2-24	SG590469-000-01
	1		2-18, w/heater	SG590619-001-01
	2	Display	2-18	SG590619-001-01
	3	V2.0	2-24, w/heater	SG590619-001-01
	4		2-24	SG590619-001-01
DF(x)	1	Defroster Assembly	Heaters for scanning windows	SG590486-000-01
FN(x)	1	Vent. Assembly	Standard	SG590479-001-01
H(x)	1	Installation Hardware	For Ø 139,7 Pole	SG590483-001-01
L(x)	۲	Laser Range Finder	LE90-3AT/98	SG590114-000-01
LF(x)	-	Laser Cooling Fan	Standard	SG590405-000-01
M(x)	1	Calibration Mirror	Standard	SG590487-001-01
NS(x)	-	Network Switch	4 RJ45 ports and 1 fiber optic port with ST contact	SG590611-001-01
SA(x)	1	Scanning	w/heater	SG590559-000-01
	2	Assembly	w/o heater	SG590560-000-01
UPS(x)	٢	Uninterrupt- able Power Supply	Standard	SG590621-001-01
	-		DIN (Schuko)	SG590266-001-01
UT(x)	2	Utility	British Standard	SG590266-001-01
	З	Outlet	U.S. Standard	SG590266-001-01
	4		French Standard	SG590266-001-01



								Unless otherwise indicated, all tolerances are according to	Sha	rp Edges
							GALE /	Surface Coating	Wei	ght
ш	Camera M1144-L replaces M1113. Fl opt included in NS opt.	2014.11.11	V.N.					T2 DOCKING GUIDANCE SYS	STEM	
	Tibbo removed. New layout.	2013.11.15	К.J.			Saregare Inter M∆I MÖ S	national Ab WFNFN	COMPONENT PLACEMENT AND CONFIG	IURATION KE	≻
	Drawing number for connection diagram changed	2013.05.17	A.S.					SEE 20021-001-01 FUR CUNNELIIU	UN DIAGKAM	
В	Configuration key changed	2011.03.22	A.S.		Drawn by	: Date drawn: 2009 03 01	Checked by:			
A	Configuration key changed	2010.10.19	A.S.		App. by:	Date approved:	Project No.:	Drawing No.	Sheet Si	cale
Revision	Description	Date	Drawn by:	Checked by: Appr	oved			SG590982-001-01 E	1 of 1	



	CONFIG USE THE SYSTE TO DETERMINE	URATI M'S CONFIG	ON KEY URATION CODE M ASSEMBLY.	
Designation	Code (x)	ltem	Type	Drawing No.
	-		Standard	SG590360-001-01
CB(x)	2	Cabinet	Adapted for Supercooler	SG590361-001-01
CL(x)	-	Cooling	Supercooler Assembly	SG590553-001-01
CP(x)	-	Control & Power	Standard	SG590621-001-01
	1		3-9, w/heater	SG590472-000-01
	2	Dienlav	3-9 w/o heater	SG590503-000-01
	з	, viayay	3-15, w/heater	SG590473-000-01
	4		3-15, w/o heater	SG590504-000-01
(×)	1		3-9, w/heater	SG590620-001-01
	2	Display	3-9 w/o heater	SG590620-001-01
	e	V2.0	3-15, w/heater	SG590620-001-01
	4		3-15, w/o heater	SG590620-001-01
DF(x)	1	Defroster Assembly	Heaters for scanning windows	SG590486-000-01
FN(x)	1	Vent. Assembly	Standard	SG590479-001-01
H(x)	-	Install. Hardware	For Ø 139,7 Pole	SG590483-001-01
L(x)	1	Laser Range Finder	LE90-3AT/98	SG590114-000-01
LF(x)	٢	Laser Cooling Fan	Standard	SG590405-000-01
M(x)	-	Calibration Mirror	Standard	SG590487-001-01
NS(x)	1	Network Switch	4 RJ45 ports and 1 fiber optic port with ST contact	SG590611-001-01
SA(Y)	1	Scan.	w/heater	SG590559-000-01
(2)	2	Assm.	w/o heater	SG590560-000-01
UPS(x)	L	Uninterrupt -able Power Supply	Standard	SG590621-001-01
	-		DIN (Schuko)	SG590266-001-01
I IT (x)	2	Utility	British Standard	SG590266-001-01
() D	3	Outlet	U.S. Standard	SG590266-001-01
	4		French Standard	SG590266-001-01



							Unless otherwise indicated, all tolerances are according to	Sharp Edges
					SAFE	GAIE	Surface Coating	Weight
					а <u>ч</u>			
E Camera option removed. Fl option is now included in NS.	2014.11.11 V	N.					T3 DOCKING GUIDANCE SYSTEM	
D Tibbo removed. New layout.	2013.11.15 K				сатедате Intel МАІ МЙ С	rnarional ad Swenen	COMPONENT PLACEMENT AND CONFIGURATION	KET
C Drawing number for connection diagram changed	2013.05.17 A	نې					SEE UKAWING SU990621-004-01 FUR CUNNEC	IUN UIAGKAM
		5						
B Configuration key changed and updated	2011.11.17 A	.S.		0.0	2009-03-05			
A Configuration key changed and updated	2011.03.22 A	.S.		App. by	: Date approved:	Project No.:	Drawing No. Rev. Sheet	Scale
Revision Description	Date Dr	awn by: Ch	ecked by: Api	broved			SG590984-001-01 E 1 of 1	





Check in to the future

How many aircraft can your airport handle today? Can this number be increased without adverse effects on the airport's safety level? It is a known fact that traffic volume will rise in the foreseeable future. More movements will demand monitoring of the entire airport. Requirements will be sharpened and the development of an integrated system

controlling not only ground movements but also air traffic close to the airport is of the highest interest. The International Civil Aviation Organization (ICAO) already describes A-SMGCS, Advanced Surface Movement Guidance and Control System, as the answer to the future modern airport need to control the entire airport space in one superior system. To a larger extent than today's systems, A-SMGCS will rely on automated processes to give both pilots and traffic controllers exact information about positions and directions. Safegate Group delivers complete A-SMGCS solutions already, as well as all vital parts relating to it. Safegate Group can check your airport into the future – today!

Safegate Group HQ

Djurhagegatan 19 SE-213 76 Malmö, Sweden Phone: +46 (0)40 699 17 00 Fax: +46 (0)40 699 17 30 E-mail: market@safegate.com

Australia australia@safegate.com +61 (0)3 9720-3233

Austria office@avibit.com +43 316 429961 Brazil brazil@safegate.com +55 11 2137 4405

China china@safegate.com +8610-85275297

Dubai dubai@safegate.com +971 4 452 75 75 Finland finland@safegate.com +358 (0)20754 7700

France france@safegate.com +33 (0)1 42 99 60 40

Germany germany@safegate.com +49 (0)40 854 000 400 India india@safegate.com +91 11 4106 1545

Malaysia malaysia@safegate.com +60 32 011 3522

Oatar qatar@safegate.com +974 436 9628

Russia russia@safegate.com +7 495 917 4614 Singapore singapore@safegate.com +65 6289 6893

Spain spain@safegate.com +34 917 157 598

UK uk@safegate.com +44 (0)<u>208 573 0384</u>

USA usa@safegate.com +1 763 535 92 99



Safegate Group offers solutions for increased safety, efficiency and environmental benefits to airports worldwide. The company was founded in 1973 and has its headquarters in Malmö, Sweden. Safegate Group has more than 70 partners around the globe in order to be close to its customers. Earlier members of Safegate Group include Thorn AFL and Idman, who both have over 40 years of experience in airfield lighting solutions for airports and heliports. The latest member of Safegate Group is Avibit, a leading provider of next generation software applications and integration of efficient air traffic control systems. Safegate Group's complete range of products and services, a "one-stop shop", provides solutions to customers and airborne travellers around the globe.

www.safegate.com