



OPS Bulletin

Potable Water Cabinet (PWC) Amber Beacon On or Flashing

July 17, 2019



If the amber beacon is on, either the nozzle coupling is not connected to the air gap coupling or the nozzle ball valve is in the closed position.

Nozzle Coupling not Connected to the Air Gap Coupling:





OPS Bulletin

After use, ensure that the nozzle ball valve is in the open position. Keep in mind that this valve is a reverse handle valve.

Open Position



Closed Position

